

[Http://www.chinafuling.com](http://www.chinafuling.com)

E-mail:fuling@chinafuling.com



中国专用变频器制造商

DZB200 Series

High-performance General-purpose Inverter

DZB300 Series

Open-loop vector control inverter

usermanual

中外合资·台州富凌机电有限公司
SINO-FOREIGN JOINT VENTURE
TAIZHOU FULING ELECTROMECHANIC CO., LTD

CHINA

 **FULING** INVERTER

目 录

| | |
|---|------------|
| Chapter 1 Safety and Cautions | 1 |
| Chapter 2 Product Introduction | 6 |
| Chapter 3 Mechanical and Electrical Installation | 7 |
| Chapter 4 Operation and Display | 17 |
| Chapter 5 Function Parameters List | 22 |
| Chapter 6 Parameter Description | 34 |
| F0 Basic Function Parameters | 34 |
| F1 Motor Parameters | 42 |
| F2 Input and Output Terminal Function Parameters | 46 |
| F3 Human Machine Interface Parameters | 54 |
| F4 Application Function Parameters | 57 |
| F5 Protection Parameters | 66 |
| F6 Communication Parameters | 69 |
| Chapter 7 Fault Diagnosis and Countermeasures | 73 |
| Chapter 8 Quality Guarantee | 81 |
| Appendix A Standard Specifications | 82 |
| Appendix B Serial Communications | 85 |
| Appendix C Dimensions | 98 |
| Appendix D Accessories List | 100 |

Preface

Thank you for choosing **DZB Series** high-performance AC Motor Drives. **DZB200&300 Series** are manufactured by adopting high-quality components, material and incorporating the latest microprocessor technology available.

Getting Started

This manual will be helpful in the installation, parameter setting, troubleshooting, and daily maintenance of the AC motor drives. To guarantee safe operation of the equipment, read the following safety guidelines before connecting power to the AC drives. Keep this operating manual handy and distribute to all users for reference.



ATTENTION: Always read this manual thoroughly before using **DZB series** AC Motor Drives.

DANGER! AC input power must be disconnected before any maintenance.

WARNING! Do not connect or disconnect wires and connectors while power is applied to the circuit. Maintenance must be performed by qualified technicians.

WARNING! To avoid personal injury, do not remove the cover of the AC motor drive until all of the digital keypad "DISPLAY LED" lamps are off. The DC-link capacitor remains charged with a hazardous voltage even after input power is removed.

ATTENTION: Grounding the DZB100B drive is done by **connecting the Earth Ground to the drive ground terminal**.

CAUTION: There are highly sensitive components on the printed circuit boards. These components are especially sensitive to ESD (electrostatic discharge). **To avoid damage to the drive**, do not touch components or the circuit boards until static control precautions have been taken.

CAUTION: Never connect the main circuit output terminals U, V, and W directly to the AC main circuit power supply as **this will damage the drive**.


CAUTION: Do not apply the antirust to screws for fastening drives; Please clean the drives and screws with dry cloth or alcohol, not with synthetic cleaner. Fasten the screws with washers and rated torque lest the enclosure corners of drives be distorted.


This manual is for DZB200&DZB300 Series AC Motor Drive.

Chapter 1 Safety and Cautions

Safety Definition

There are two kinds of safety cautions in the manual:

 **Danger** Operations which are not performed according to the requirements may cause severe hurt or even death.

 **Note** Operations which are not performed according to requirements may cause moderate hurt or light hurt or equipment damage.

1.1 Safety Cautions

1. Before Installation


 **Danger**

Do not use the inverter that is damaged or has defect, or there will be danger of injury.

2. During Installation

 **Danger**

Mount the inverter on incombustible surface like metal, and keep away from flammable substances! Otherwise it may cause fire.


 **Note**

- ★ When more than two inverters are to be installed in one cabinet, please pay attention to the installation locations to ensure the cooling effect (refer to Chapter 3 Mechanical and Electrical Installation).
- ★ Do not drop the lead wire stub or screw in the inverter, or the inverter may be damaged.

3. Wiring

 **Danger**

- ★ Only the qualified electrical engineer can perform the wiring, otherwise there will be danger of electric shock.
- ★ A circuit breaker must be installed between the mains and the inverter, otherwise there will be danger of fire.
- ★ Wiring can only be done after the mains input is cut off, otherwise there will be danger of electric shock.
- ★ Please connect the inverter to the ground according to the standard, otherwise there will be danger of electric shock.


 **Note**

- ★ Do not connect the input terminals with the output terminals (U, V, W), otherwise the inverter may be damaged!
- ★ Ensure the wiring meet the EMC requirements and the local safety standard. The wire size shall be determined according to the manual, otherwise accident may occur!
- ★ Brake resistor must not be connected between the DC bus terminals (+) and (-), otherwise fire may occur!

4. Before Power-on

 **Danger**

- ★ Please confirm the mains voltage level is consistent with that of the inverter and the input and output wirings are correct, and check if there is any short circuit in peripheral circuit and if the wiring is fixed and fast, otherwise the inverter may be damaged!
- ★ Mount the cover plate properly before power-on the inverter, otherwise there will be danger of electric shock.

 **Note**

- ★ Dielectric strength test had been done at factory. Therefore, user needs not do this test again, otherwise accident may occur!
- ★ All the peripheral parts shall be connected correctly according to the manual, or accident may occur!

5. After Power-on

 **Danger**

- ★ Do not open the cover of the inverter after power-on, otherwise there will be danger of electric shock!
- ★ Do not touch the inverter and its circuit with wet hand, otherwise there will be danger of electric shock.
- ★ Do not touch the inverter terminals, otherwise there will be danger of electric shock.
- ★ At power-on, the inverter will perform the security check of the external heavy-current circuit automatically, so at this time please do not touch the terminals U, V and W, or the terminals of motor, otherwise there will be danger of electric shock.

 Note

- ★ If parameter identification is required, please pay attention that the rotating motor may injure people, otherwise accident may occur!
- ★ Do not change the factory settings, otherwise the inverter may be damaged!

6. Running

 Danger

- ★ Do not approach the equipment when restart function is enabled, otherwise there will be danger of injury.
- ★ Do not touch the fan and the discharging resistor to check the temperature, otherwise burning may occur!
- ★ Non-professional person shall not measure the signal of a running inverter, otherwise there will be danger of injury or damaging the inverter!

 Note

- ★ Do not let objects fall in a running inverter, otherwise the inverter may be damaged!
- ★ Do not start and stop the inverter by on/off of the contactor, otherwise the inverter may be damaged!

7. Maintenance

 Danger

- ★ Please do not repair or maintain the inverter with power on, otherwise there will be danger of electric shock!
- ★ Please repair or maintain the inverter after confirming the charge LED turns off, otherwise there may be human injury caused by the residual voltage of the capacitor!
- ★ Only qualified electrical engineer can repair or maintain the inverter, otherwise there will be danger of human injury or damaging the equipment.

1.2 Cautions

1. Check the Insulation of the Motor

When the motor is used for the first time, or reused after storing for a long time, or in regular checkup, the user must check the insulation of the motor to prevent the poor insulation of the windings of motor from damaging the inverter. The motor connection must be divided from the inverter during the insulation check. It is recommended to use a 500V Mega-Ohm-Meter to check and the insulation resistance shall not be less than 5M Ω .

2. Thermal Protection of Motor

If the rated capacity of the motor selected is not matching that of the inverter, especially when the rated power of the inverter is bigger than that of the motor, make sure to adjust the parameters for motor protection inside the inverter or to install a thermal relay to the motor to guarantee the protection to the motor.

3. Running at Frequency Above Rated Frequency

The output frequency of this inverter is 0-600Hz. Please consider the capability of the mechanical devices when the customer needs the inverter to run at the frequency higher than 50Hz.

4. Motor Heat and Noise

Since the output voltage of the inverter is in PWM wave with some harmonics, the temperature may rise, the noise and vibration may increase compared with the inverter running at main frequency.

5. Pressure-sensitive Device or Capacitor at the Output Side of the Inverter

Because the inverter outputs PWM wave, the capacitor used for improving power factor and pressure-sensitive resistor used for lightning-proof shouldn't be installed at the output side of the inverter, otherwise the inverter may have transient over-current and may be damaged.

6. Switches Used at the Input and Output terminal of the Inverter

If the contactor is required to be installed between the inverter and the power supply, it is prohibited to start or stop the inverter with the contactor. If the user has to use the contactor to start and stop the inverter, the interval between the start and stop shall be less than one hour. Frequent charging and discharging may reduce the life of the capacitor. If the switches like contactors are connected between the output terminal and the motor, make sure to start and stop the inverter when the inverter has no output, otherwise the modules in the inverter may be damaged.

7. Usage Outside the Range of Rated Voltage

The DZB series inverter shall not be used out of the specified range of operation voltage, otherwise the internal components of the inverter may be damaged. If needed, please use corresponding voltage regulation device to change the voltage.

8. 3-phase Input Modified Into 2-phase Input

The modification of DZB series inverter from 3-phase input to 2-phase input is not allowed, or fault may occur.

9. Lightning Strike Protection

There are lightning protection devices inside the inverter. But the user should install other lightning protection device at the front end of the inverter if lightning strike occurs frequently.

10. Altitude and Deration

When the altitude is higher than 1000m, the cooling effect of inverter is deteriorated because of the rarefaction of air, the deration must be used and please consult our company for detailed technical support.

11. Special Usages

The user can consult our company if he wants to use another method instead of the recommended connecting method provided in the manual, such as shared DC bus.

12. Cautions for Scrap of Inverter

The electrolytic capacitors in the main circuits and PCB may explode when they are burned and poisonous gas may be generated when the plastic parts are burned. Please dispose the inverter as industrial rubbish.

13. About Applicable Motor

- 1) The standard motor used is the 4-pole squirrel cage asynchronous induction motor. If other kind of motor is used, please be sure to select the applicable inverter according to the rated current of the motor, and please consult us if the user wants the inverter to drive the permanent magnetic synchronized motor.
- 2) The cooling fan of non-variable frequency motor is connected to the rotor in the same bearing, so the cooling effect is weakened if the speed is low, therefore use the variable-frequency motor or install a cooling fan in the overheat condition the motor.
- 3) The inverter has already been configured with the standard parameters for applicable motor, please be sure to modify the default values or perform the motor parameter identification according to the actual conditions, otherwise the operation effect or protection performance may be reduced.
- 4) Short-circuit in the cable or motor may cause the inverter alarm or even damage the inverter.

Therefore, please conduct the insulation short-circuit test to the cable and the motor installed for the first time. The short-circuit test shall also be carried out in routine maintenance. Pay attention that the inverter shall be separated from the unit during such test.

Chapter 2 Product Introduction

The purpose of this chapter is to provide specific, yet simple information to **unpack, install** the AC drive.

This chapter contains information on the following:

2.1 Receiving, Transportation, and Storage

2.2 Nameplate Information

2.1 Receiving, Storage and Transportation

The AC motor drive has gone through rigorous quality control tests at the factory before shipment.

After receiving the AC drive, check for the following.

● Receiving

1. Check to make sure that the package includes an AC drive, the User Manual, dust covers and rubber bushings.
2. Inspect the unit to insure it was not damaged during shipment.
3. Make sure that the part number indicated on the nameplate corresponds with the part number of your order.

● Storage

The AC Drive should be kept in the shipping carton before installation. In order to retain the warranty coverage, the AC drive should be stored properly when it is not to be used for an extended period of time. Some storage suggestions are:

1. Store in a clean, dry location.
2. Store within an ambient temperature range of -20°C to $+65^{\circ}\text{C}$.
3. If possible, store in an air-conditioned environment where the relative humidity is less than 95%, non-condensing.
4. Do not store the AC drive in places where it could be exposed to corrosive gases.
5. Please store the AC drive on a shelf or on a stable surface.

● Transportation

Temperature: -25°C to $+70^{\circ}\text{C}$; R.H.: 0% to 95%;


Air Pressure: 70kPa to 106kPa.

2.2 Nameplate Information


● Nameplate



● Description of AC Motor Drive Model:



● Description of Serial Number::




Chapter 3 Mechanical and Electrical Installation

3.1 Mechanical Installation

1. Installation Environment


- 1) Ambient temperature: Ambient temperature influences the inverter life greatly, so it should be within the range of -10℃~50℃.
- 2) Mount the inverter in a flame retardant surface and the clearance around the inverter shall be enough because the inverter will generate lots of heat during running, besides mount the inverter on the base vertically with screws.
- 3) Mount in the location where vibration is less than 0.6G; the inverter shall be far away from impacting lathe.
- 4) Please do not install the inverter in the place with direct sunlight, high humidity and water.
- 5) Mount the inverter in the location free of corrosive gas, explosive gas or combustible gas.
- 6) Mount the inverter in the location free of oil dirt, dust, and metal powder.

2. Installation Location



Note: No need to consider the dimension A for inverter of 22kW or below.
A shall be bigger than 50mm for the inverter of 22kW or above

Installation of single inverter



Note: Install an airflow- guidance plate for the up and down installation of inverters.

Up and down installation of inverters

Fig.3-1 DZB Series Inverter Installation Location

The user shall focus on the heat dissipation issues when installing the inverter, and pay attention to the following points:


- 1) Install the inverter vertically so that the heat may be expelled from the top, but do not install the inverter upside down. When two Variable Speed Drives are mounted up and down, an air flow diverting plate should be fixed in between as shown in Fig. 3-1.
- 2) Installation space is shown in Fig.3-1 so as to ensure the heat dissipation space, but consider the heat dissipation of other components when placing the inverter.
- 3) The installation bracket must be flame retardant.
- 4) Install the heat sink outside of the cabinet if the inverter is installed in the area with metal powder. And in this case, the space inside the sealing cabinet shall be big enough.

3.2 Electrical Installation

1. Applicable devices and recommendable wiring of main circuit:

| MODEL DZB300 Series | Applicable Motor (KW) | INPUT(RST) | | Wire Size(mm ²) | | | |
|---------------------------|-----------------------------|---------------------------------|-----------------------------|-----------------------------|---------------|---------------------|------------------|
| | | Air Circuit Breakers MCCB | Magnetic Contactor MC | Power Cable | DC Reactor | Braking Resistor | Control Cable |
| 0005L2 | 0.55 | DZ20-100(16A) | CJ20-16 | 1.5 | 4 | 1.5 | 0.5 0.75 |
| 0007L2 | 0.75 | | | 2.5 | | 2.5 | |
| 0015L2 | 1.5 | | | 4 | 4 | | |
| 0022L2 | 2.2 | DZ20-100(32A) | CJ20-40 | 4 | 6 | 4 | |
| 0037L2 | 3.7 | | | 4 | 4 | | |
| 0007L4 | 0.75 | DZ20-100(16A) | CJ20-16 | 1.5 | 4 | 1.5 | |
| 0015L4 | 1.5 | | | 2.5 | | 2.5 | |
| 0022L4 | 2.2 | | | 4 | 6 | | |
| 0037L4 | 3.7 | | | 6 | | 4 | |
| 0055L4 | 5.5 | DZ20-100(32A) | CJ20-40 | 6 | 8 | 4 | |
| 0075L4 | 7.5 | | | 8 | | | |
| 0110L4 | 11 | DZ20-100(50A) | CJ20-40 | 8 | 16 | 6 | |
| 0150L4 | 15 | | | 10 | | | |
| 0185L4 | 18.5 | | | 16 | | | |
| 0220L4 | 22 | DZ20-100(63A) | CJ20-63 | 16 | 16 | 6 | |
| 0300L4 | 30 | DZ20-100(80A) | | | | | |
| 0370L4 | 37 | DZ20-100(100A) | CJ20-100 | 25 | 25 | 10 | |
| 0450L4 | 45 | | | 35 | 25*2(50) | | |
| 0550L4 | 55 | DZ20-200(200A) | CJ20-160 | 25*2(50) | 35*2(70) | 16 | |
| 0750L4 | 75 | | | 35*2(70) | 50*2(95) | | |
| 0930L4 | 93 | DZ20-400(250A) | CJ20-250 | 50*2(95) | 70*2(150) | 25 | |
| 1100L4 | 110 | | | | | | |
| 1320L4 | 132 | | | DZ20-400(350A) | | | |
| 1600L4 | 160 | | | | | | |
| 1870L4 | 187 | DZ20-400(400A) | CJ20-400 | 70 2(150) | 70 2(150) | 16 2(35) | |
| 2000L4 | 200 | | | | | | |
| 2200L4 | 220 | DZ20-630(500A) | CJ20-630 | 95*2(185) | 95*2(185) | 25*2(50) | |
| 2500L4 | 250 | | | | | | |
| 2800L4 | 280 | DZ20-630(600A) | CJ20-800 | 120*2(240) | 120*2(240) | 35*2(70) | |
| 3150L4 | 315 | | | | | | |
| 4000L4 | 400 | DZ20-800(800A) | CJ20-800 | 150*2(300) | 150*2(300) | 50*2(100) | |
| 5000L4 | 500 | DZ20-1250(1000A) | CJ20-500*2 | 185*2(370) | 185*2(370) | 50*2(100) | |
| 6300L4 | 630 | DZ20-1250(1250A) | CJ20-630*2 | 185*2(370) | 185*2(370) | 50*2(100) | |

2. Wiring Diagram of Peripheral Equipment



3. Basic Wiring Diagram

Users must connect wires according to the following circuit diagram shown below.




Fig.3-3 Basic Wiring Diagram

Note: Braking resistor terminals (BR+/BR-) for the inverter of 15KW or below.
 Braking unit and DC Link Reactor terminals (P1/P2/DC-) for the inverter 18.5KW-30KW.
 Braking unit terminals(DC+/DC-)for the inverter above 37KW .

4. Main Circuit Terminals and Wiring

Danger

- ★ Wiring can only be done after the mains input is cut off, otherwise there will be danger of electric shock!
- ★ Only qualified and trained engineer can perform the wiring, otherwise there will be danger of electric shock!
- ★ Grounding cable must be grounded, otherwise there will be danger of electric shock or fire!

Danger

- ★ Please confirm the mains voltage level is same with that of the inverter, otherwise the inverter may be damaged!
- ★ Make sure the ratings of the driven motor are in compliance with the inverter, otherwise the motor may be damaged or the inverter may be in protection status!
- ★ Do not confuse the input terminals with the output terminals (U, V, W), otherwise there will be danger of damaging the inverter!
- ★ Brake resistor cannot be connected between the DC bus terminals (+) and (-), otherwise fire may occur!

1) Main Circuit Terminals of Inverter

| Terminals | Description |
|---------------|--|
| R, S, T(L, N) | AC input line terminals |
| U, V, W | Motor connection |
| BR+, BR- | Connection for the braking resistor (option) |
| P1 (DC+), DC- | Connection for the braking unit (option) |
| P1, P2 | Connection for the DC Link Reactor (option) |
| E | Ground |

2) Notes on Wiring

A. Input power supply L and N or R, S and T:

There is no phase-ration requirement for the input of inverter.

B. DC bus (DC+) and (DC-) terminals:

Pay attention that the DC bus terminals (DC+) and (DC-) still have voltage after power off, and the user can only touch the terminals after the CHARGE LED turns off and the voltage is below 36V, otherwise there is a danger of electric shock.

When selecting the brake unit for the inverter above 18.5kW, pay attention that the polarity of (DC+) and (DC-) cannot be reverse, otherwise the inverter may burn or be damaged. The cable length of brake unit shall be less than 10m and twisted pair cables shall be used.

Do not connect the brake resistor directly to the DC bus, otherwise the inverter may burn or be damaged.

C.Brake resistor terminals of (BR+)、(BR-)：

The brake resistor terminal is effective only for the inverter of 15kW or below and has a built-in brake unit. Select the recommended resistor with the cable length of less than 5m, otherwise the inverter may burn or be damaged.

D. Inverter output U、V and W:

Inverter output terminals cannot connect to capacitors or surge snub devices, otherwise the inverter may be in protective status or damaged.


If the cables between the motor and the inverter are too long, electrical resonance may occur due to the distributed capacitance, which may result in damaging the motor insulation or big leakage current, so if the cable length is longer than 100m, AC reactor must be installed.

E. Grounding Terminal⊕:

Grounding Terminal must be connected to earth reliably and the grounding resistance shall be less than 5Ω, otherwise the equipment may work abnormally or be damaged. Do not share the PE and neutral line of the mains supply.

5. Control Terminals and Wiring

1) Layout of Control Terminals(Fig.3-4, Fig3-5):



2) Function of Control Terminals:

| Terminal | Function | |
|----------------------|--|--|
| MO ₁ -MCM | Multi-function PHC output 1 | Refer to F2.19~F2.21 |
| MO ₂ -MCM | Multi-function PHC output 2 | |
| A-B | Multi-function indication output contact | |
| B-C | Multi-function indication output contact | |
| A1-B1 | Multi-function indication output contact | Refer to F2.00~F2.06 |
| S1-DCM | Multi-function input 1 | |
| S2-DCM | Multi-function input 2 | |
| S3-DCM | Multi-function input 3 | |
| S4-DCM | Multi-function input 4 | |
| S5-DCM | Multi-function input 5 | |
| S6-DCM | Multi-function input 6 | |
| EV-DCM | Auxiliary control power source | DC 24V (50mA Max.) |
| VI-ACM | Analog voltage input | 0-10 V (Max. output freq.) Input |
| CI-ACM | Analog current input | 4-20 mA (Max. output freq.) Input |
| FM-ACM | Analog frequency/current meter | 0-10 V (Max. output freq.) Output Refer to F2. 22 |
| SG+,SG- | Serial communication interface | RS-485 serial port |
| 10V-ACM | Power supply for speed setting | +10 V (20 mA max. output current) |

3) Notes on Control Terminals:

A) Analog input terminal:

Since the weak analog voltage signal is easily disturbed by external disturbance source, shielded cable shall be used and the cable shall be as short as possible and the length shall not exceed 20m, as shown in the figure 3-6:




Fig. 3-6 Analog Input Terminal of DZB Series Inverter

If the analog signal is severely disturbed, filter capacitor or ferrite core shall be installed at the analog signal source as shown in the Fig. 3-7:




Fig. 3-7 Analog Input Terminal With Filter devices

B) Digital input terminal:

The inverter judges the ON/OFF status of these terminals by receiving the digital signal. Hence, all the external contactors are those with high reliability of weak signal conduction.

If the open collector is employed to provide ON/OFF signal for the inverter digital input terminal, then it shall be considered that there is error operation caused by power supply interference.

It is recommended to use contact control mode.

C) Digital Output terminal:

When digital output terminal drives a relay, the coil of the relay shall be installed a snubbing diode, otherwise the DC 24V power supply may be damaged.

Note: Pay attention to the polarity of the diode as shown in the figure 3-8. Otherwise if the digital output terminal has output, the DC24V power supply will be damaged.




Fig. 3 -8 Digital Input Terminal of DZB Series Inverter

6. EMC Issues

6.1 Influence of Harmonics

- 1) The high frequency harmonics of mains supply will influence the rectifying circuit of the inverter. The harmonics will heat the rectifying circuit and even damage the circuit. So, it is recommended to install the filtering device in the environment where the power quality is poor.
- 2) Since the inverter output has high frequency harmonics, the output cannot be installed with capacitor or surge suppressing devices because the capacitor and surge suppressing device may resonate the circuit and damage the equipment.

6.2 EMI

- 1) Two kinds of EMI, one is the EMI around the inverter and disturbs the inverter. This kind of EMI is weak, besides the inverter has been designed with strong immunity. Another is the EMI from the inverter that may influence the equipment around the inverter. The inverter itself is a disturbance source because it outputs PWM wave through high carrier frequency, so solving the EMI issue is mainly to reduce the EMI of inverter.

Methods:

- A) Inverter and other equipment shall be well grounded and the grounding resistance shall be less than 5ohm.
- B) Inverter's power cables shall be vertical instead of parallel with the control cables.
- C) For the application with strong disturbance, the power cables from the motor to the inverter shall be shielded and the shielding layer shall be grounded.
- D) The cables of disturbed equipment shall be twisted shielded cables and the shielding layer shall be grounded.

- 2) Reducing the disturbance to the inverter from other equipment

The relay, contactor or electronic -magnetic braking device will disturb the inverter.

Take the following actions to solve this issue:

- A) Install surge suppressing devices to the disturbing device
 - B) Install filter to the input of the inverter
 - C) Inverter's control cables shall be shielded and the shielding layer shall be grounded
- 3) Method to reduce the disturbance from the inverter to the equipment

Two kinds of noises, one is the radiation from the inverter itself, and another is the radiation from the cable between the inverter and the motor. These two kinds of radiations induce the cables of the equipment and make the equipment work abnormally. Following method can be used:

- A) If the measuring meters, radio equipment and sensors and their signal cables are installed in a cabinet together with the drive, these equipment cables will be easily disturbed. Take the actions below to solve the problem: The equipment and the signal cables should be as far away from the inverter as possible; Signal cables and power cables shall not be routed in parallel or bound together; The signal and power cables should be shielded; Install radio noise filter and linear noise filter at the input and output sides of the inverter
- B) If the external equipment shares a same AC supply with the inverter, and the above cannot eliminate the disturbance, then the user should install a linear filter or a radio noise filter.
- C) Ground the external equipment and eliminate the disturbance of the leakage current from the inverter's grounding cable.

6.3 Leakage current

The inverter has two kinds of leakage current, one is the grounding leakage current and another is the leakage current between the lines:

- 1) Grounding leakage current:

The distributed capacitance exists between the cables and the ground, and the bigger the capacitance and the bigger the leakage current, so the motor cables should be as short as possible. Besides, the bigger the carrier frequency is, the bigger the leakage current is, so the user can also reduce the carrier wave frequency, but the motor noise may increase. Installing reactor can also reduce the leakage current. The leakage current is increased with the increase of the circuit current, so the leakage current is big if the motor power is big.

- 2) Leakage current between lines:

The distributed capacitance exists in the inverter's output cables, and resonance may occur if high frequency harmonics exist in the current, thus the leakage current occurs, which may result in the wrong action of relay.

The method to solve this issue is to reduce the carrier frequency or install the output reactor. It is recommended to use inverter's protection function instead of a thermal relay to protect the motor before using the inverter.

Chapter 4 Digital Keypad Operation

4.1 Description of the Digital Keypad

● Digital Keypad Parts and Functions

This digital keypad module includes two parts: display panel and a keypad. The display panel allows the user to program the AC drive, as well as view the different operating parameters. The keypad is the user interface to the AC motor drive. Refer to the following figure for a description of the different parts.




Fig. 4-1 Operation Panel Schematic Diagram

| Key | Description |
|-----|---|
| | Program / Reset First-stage menu entry or exit. |
| | Function / Data Displays information on the AC drive status such as the reference frequency, output frequency, or output current in the normal mode. While the drive is in the Program Mode, press this key once to display the current parameters. After changing the parameters, press this key again to store the new parameters. |
| | Forward / Reverse Used to toggle between forward and reverse operation. Pressing this key will cause the motor to ramp down to 0 Hz and then ramp up to the preset speed in the opposite direction. |
| | JOG/ >> Used to start the AC drive, then run at the jog frequency. When modify parameter, can select modified bit of the parameter. |










| | |
|--|--|
| | Run Used to start the AC drive operation. This key has no effect when the drive is set to terminal run. |
| | Stop Used to stop the AC drive operation. If the AC drive has stopped due to a fault, press this button to reset the drive. |
| | Up / Down Press the "Up" or "Down" button to change parameter settings. These keys may also be used to scroll through different operating values or parameters. |

● Explanation of Screen Display

1. Explanation of Displayed Messages on Running status (refer to F3.05):

| Displayed Symbol | Displayed Message | Operation |
|------------------|--|---------------|
| H | Setting frequency | Press " " key |
| P | Running frequency | Press " " key |
| C | Output current | Press " " key |
| d | Output voltage | Press " " key |
| n | Running speed | Press " " key |
| P | Output power | Press " " key |
| T | Output torque | Press " " key |
| U | DC bus voltage | Press " " key |
| R | PID setpoint | Press " " key |
| b | PID feedback | Press " " key |
| I | Input terminal status | Press " " key |
| o | Output terminal status | Press " " key |
| u | VI value | Press " " key |
| c | CI value | Press " " key |
| B | Current segment of multi-speed control | Press " " key |

2. Explanation of Displayed Messages on Stop status(refer to F3.05):

| Displayed Symbol | Displayed Message | Operation |
|------------------|--|---|
| H | Setting frequency | Press "  " key |
| U | DC bus voltage | Press "  " key |
| I | Input terminal status | Press "  " key |
| O | Output terminal status | Press "  " key |
| R | PID setpoint | Press "  " key |
| b | PID feedback | Press "  " key |
| v | VI value | Press "  " key |
| c | CI value | Press "  " key |
| B | Current segment of multi-speed control | Press "  " key |

4.2 Modify and Check the Function Codes

DZB300MD300 series inverter's operation panel uses 3-level menu to conduct parameter settings.

3-level menu: function parameter group (first level) → function code (second level) → setting of function code (third level). Operation procedure is shown in Fig. 4-2.




Fig. 4-2 Operation Procedures for 3-level Menu

Note: When operating 3-level menu, pressing PRG or DATA can return to second level menu. The difference is: pressing DATA will save the parameters and return to second level menu and then shift to the next function code, while pressing PRG will return to second level menu without saving the parameters.

Example: Change the setting of F1.02 from 10.00Hz to 15.00Hz. (Bold means flash bit.)




Fig. 4-3 Example for Parameter Changing

In third level menu, if the parameter has no flash bit, it means the function code cannot be changed and the possible reasons are:

- 1) This parameter of this function code cannot be changed, such as the actually detected parameter and running record parameter.
- 2) This function code cannot be changed in operating status and can only be changed when the inverter is stopped.

4.3 How to View Status Parameters

When DZB Series inverter is in the stop or running status, several status parameter of the inverter can be displayed on the LED nixie tube. Pressing the keyDATA can display the stop or running status parameters.

There are nine stop status parameters to be displayed in the stop status, Setting frequency, DC bus voltage, Input terminal status, Output terminal status, PID setpoint, PID feedback, VI value, CI value, Current segment of multi-speed control.

DZB Series inverter has fifteen running status parameters to be displayed in the running status, Setting frequency, Running frequency, Output current, Output voltage, Running speed, Output power, Output torque, DC bus voltage, PID setpoint, PID feedback, Input terminal status, Output terminal status, VI value, CI value, Current segment of multi-speed control.

If the inverter is powered on again after power-off, the parameters displayed are defaulted as those selected before the power-off.

4.4 Password Setting

DZB300 inverter provides password protection for users. When F3.00 is not zero, that is the user password, and the password protection function is valid once exiting the function code editing status. If the user presses PRG again, the inverter shall display "-----", and the user can only enter the menu after inputting the user password. Otherwise, the user cannot enter.

If the user wants to cancel the password protection function, F3.00 should be set 0.

4.5 Auto Tuning of Motor Parameters(Refer to F1.11):

Note: This function is invalid for DZB200 Series.

Before running the inverter that has selected the vector control mode, accurate motor nameplate parameters must be input to the inverter correctly. DZB300 inverter will configure the standard motor parameters according to the nameplate parameters. Vector control mode is highly dependent on the motor parameters and correct parameters must be acquired for achieving good control performance.

Motor auto tuning procedures:

Firstly set the command source (F0.01) as the operation panel command channel.

Then input the following parameters according to the actual parameters of motor:

- F1.01: Rated power of motor;
- F1.02: Rated frequency of motor;
- F1.03: Rated speed of motor;
- F1.04: Rated voltage of motor;
- F1.05: Rated current of motor.

If the motor is disconnected from the load completely, select '1' (complete tuning) in F1.11, and press RUN in keypad, the inverter will calculate the parameters below automatically:

- F1.06: Stator resistance;
- F1.07: Rotor inductance;
- F1.08: Leakage inductance;
- F1.09: Mutual inductance;
- F1.10: Excitation current with no load;

Motor tuning is finished automatically.

If the motor cannot disconnect from its load, set F1-11 to '2' (static tuning), and then press the RUN. The inverter will measure the stator resistance, rotor resistance and leakage inductance in sequence, but it will not calculate the mutual inductance and the excitation current with no load, and the user can use the nameplate parameters that are rated voltage U, rated current I, rated frequency f and power factor η to calculate these two parameters:

The calculation methods of the motor current with no load and the mutual inductance are described as follows.

$$\text{Excitation current with no load: } I_0 = I \cdot \sqrt{1 - \eta^2}$$

$$\text{Mutual inductance calculation: } L_m = \frac{U}{2\sqrt{3}\pi f \cdot I_0} - L_s$$

Where I_0 is the excitation current with no load, L_m is the mutual inductance and L_s is the leakage inductance.

Chapter 5 Function parameters list

DZB300series inverter function parameters, which are grouped by functions, have F0-F6 total 7 groups. Each function group includes a number of function codes, which adopts three-stage menu, for instance, "F4.08" means the 8th function code of F4th function.

For the convenience of setting function code by using operation panel, the function group number is corresponding to Stage 1 menu, the function code is corresponding to Stage 2 menu and the function code parameter is corresponding to Stage 3 menu.

1. The column of function table is described as follows:

The 1st column "Function Code" is the function parameter group and parameter code.

The 2nd column "Name" is the complete name of the function parameter.

The 3rd column "Setting Range" is the effective setting value range of the function parameter, shown on the operation panel LCD.

The 4th "Default" is the original factory setting value of this function parameter.

The 5th "Modification" is the modification performance of the function parameter (i.e. whether or not it is permitted to modify and the modification conditions), explained as follows,

"※": indicates that the setting value of this parameter can be modified when the inverter is either in stop or operating status;

"●": means that the setting value of this parameter cannot be modified when the inverter is in operating status;

"**": means that this parameter is a test value which cannot be modified.

(Inverter has done the automatic detection restriction to the modification performance of each parameter, helping user to prevent mis-modification.)

The 6th column "Serial No" is the number of function code at the storage inside.

2. "Default" indicates the value of the function code after it is refreshed while doing the manipulation of restoring the factory parameters; but the actually detected parameters or record values cannot be refreshed.

3. In order to effectively protect the parameters, the inverter provides the cryptoguard for the function code. After the user's password is set up (i.e. user's password F3.00 parameter is not 0), when the user press PRG button to enter function code edit status, the system first enters the user's password verification status, displaying "-----", and the operator must input correctly the user's password, otherwise it is impossible to enter. At the state that the cryptoguard is not locked, the user's password can be modified at any time, and the one finally input will be the user's password. If F3.00 is set as 0, the user's password can be cancelled; when the power is on, if F3.00 is not 0, parameters are protected by password.

4. When modify parameter using serial communication, usage of user password also abide above principle.

| Function Code | Name | Setting Range | Default Value | Modification | Serial No |
|-------------------------------------|---------------------------------------|---|---------------|--------------|-----------|
| F0 Basic Function Parameters | | | | | |
| F0.00 | Control mode | 0: Speed sensorless vector control (SVC) 1: V/F control | 1 | ● | 0. |
| F0.01 | Command source selection | 0: Keyboard 1: Terminal 2: Communication | 0 | ● | 1. |
| F0.02 | Keyboard and terminal UP/DOWN setting | 0: Valid, and inverter memorize when power down 1: Valid, and inverter does not memorize when power down 2: Invalid | 0 | ※ | 2. |
| F0.03 | Frequency command Selection | 0: Keyboard 1: VI 2: CI 3: VI+ CI 4: Multi-speed 5: PID control 6: Communication | 0 | ※ | 3. |
| F0.04 | Maximum output frequency | 10.00~600.00Hz | 50.00Hz | ● | 4. |
| F0.05 | Upper limit frequency | F0.06~F0.04 | 50.00Hz | ※ | 5. |
| F0.06 | Lower limit frequency | 0.00 Hz~F0.05 | 0.00Hz | ※ | 6. |
| F0.07 | Keyboard frequency setting | 0.00 Hz~F0.04 | 50.00Hz | ※ | 7. |
| F0.08 | ACCEL time 1 | 0.1~3600.0s | 10.0s | ※ | 8. |
| F0.09 | DECEL time 1 | 0.1~3600.0s | 10.0s | ※ | 9. |
| F0.10 | Operation direction selection | 0: Operating at default direction 1: Operating at reverse direction 2: NO inverse operating | 2 | ● | 10. |
| F0.11 | Carrier frequency setting | 1.0~15.0kHz | Set by model | ※ | 11. |
| F0.12 | Functional parameters restoration | 0: NO operation 1: Restore default value 2: Delete failure records | 0 | ● | 12. |
| F0.13 | AVR selection | 0: Invalid 1: Valid all the time | 1 | ※ | 13. |

| Function Code | Name | Setting Range | Default Value | Modification | Serial No |
|----------------------------|---|--|---------------|--------------|-----------|
| | | 2: Invalid during deceleration | | | |
| F0.14 | Start Mode | 0: Direct start 1: DC braking first and then start 2: Running speed pick-up and then start | 0 | ● | 14. |
| F0.15 | Start frequency | 0.00~10.00Hz | 0.50Hz | ※ | 15. |
| F0.16 | Hold time of start frequency | 0.0~50.0s | 0.0s | ※ | 16. |
| F0.17 | Braking current before starting | 0.0~150.0% | 0.0% | ※ | 17. |
| F0.18 | Braking time before starting | 0.0~50.0s | 0.0s | ※ | 18. |
| F0.19 | Stop Mode | 0: DECEL Stop 1: Free run Stop | 0 | ※ | 19. |
| F0.20 | Beginning Frequency of braking | 0.00~ F0.04 | 0.00Hz | ※ | 20. |
| F0.21 | Waiting time of braking | 0.0~50.0s | 0.0s | ※ | 21. |
| F0.22 | DC braking current | 0.0~150.0% | 0.0% | ※ | 22. |
| F0.23 | DC braking time | 0.0~50.0s | 0.0s | ※ | 23. |
| F0.24 | Dead time between forward and reverse | 0.0~3600.0s | 0.0s | ※ | 24. |
| F0.25 | Terminal command protection when power on | 0: Terminal command invalid when power on 1: Terminal command valid when power on | 0~1 | ※ | 25. |
| F1 Motor Parameters | | | | | |
| F1.00 | Inverter model | 0: B model 1: P model | Set by model | ● | 26. |
| F1.01 | Motor rated power | 0.4~900.0kW | Set by model | ● | 27. |
| F1.02 | Motor rated frequency | 0.01Hz~F0.04 | 50.00Hz | ● | 28. |
| F1.03 | Motor rated speed | 0~36000rpm | Set by model | ● | 29. |
| F1.04 | Motor rated voltage | 0~460V | Set by model | ● | 30. |
| F1.05 | Motor rated current | 0.1~1000.0A | Set by model | ● | 31. |
| F1.06 | Motor stator resistance | 0.001~65.535Ω | Set by model | ※ | 32. |
| F1.07 | Motor rotor resistance | 0.001~65.535Ω | Set by model | ※ | 33. |
| F1.08 | Motor stator/rotor inductance | 0.1~6553.5mH | Set by model | ※ | 34. |

| Function Code | Name | Setting Range | Default Value | Modification | Serial No |
|---|---|--|---------------|--------------|-----------|
| F1.09 | Mutual inductance of motor stator/rotor | 0.1~6553.5mH | Set by model | ※ | 35. |
| F1.10 | No-load current | 0.01~655.35A | Set by model | ※ | 36. |
| F1.11 | Self-learning of motor parameters (Invalid for DZB200) | 0: NO operation | 0 | ● | 37. |
| | | 1: complete tuning Self-learning | | | |
| | | 2: static tuning Self-learning | | | |
| F1.12 | Speed loop proportional gain1 | 0~100 | 30 | ※ | 38. |
| F1.13 | Speed loop integral time1 | 0.01~10.00s | 0.50s | ※ | 39. |
| F1.14 | Switching low point frequency | 0.00Hz~F1.17 | 5.00Hz | ※ | 40. |
| F1.15 | Speed loop proportional gain2 | 0~100 | 25 | ※ | 41. |
| F1.16 | Speed loop integral time 2 | 0.01~10.00s | 1.00s | ※ | 42. |
| F1.17 | Switching high point frequency | F1.14~F0.04 | 10.00Hz | ※ | 43. |
| F1.18 | VC slip compensating factor | 50%~200% | 100% | ※ | 44. |
| F1.19 | Upper torque limit setting | 0.0~200.0%(inverter rated current) | 150.0% | ※ | 45. |
| F1.20 | V/F curve setting | 0: Linear V/F curve | 0 | ● | 46. |
| | | 1: square torque V/F curve | | | |
| F1.21 | Torque boost | 0.0%: (auto) 0.1%~30.0% | 0 | ※ | 47. |
| F1.22 | Torque boost cut-off | 0.0%~50.0% (relative to motor rated frequency) | 20.0% | ● | 48. |
| F1.23 | V/F slip compensation limit | 0.0~200.0% | 100% | ※ | 49. |
| F1.24 | Energy Conservation Selection | 0:No Operation | 0 | ** | 50. |
| | | 1:Energy Conservation | | | |
| F2 Input and Output Terminal Function Parameters | | | | | |
| F2.00 | On-off signal filter times | 1~10 | 5 | ※ | 51. |
| F2.01 | S1 Terminal Function Selection | 0:No Function | 1 | ● | 52. |
| | | 1:Forward | | | |
| F2.02 | S2 Terminal Function Selection | 2:Reverse | 2 | ● | 53. |
| | | 3:three-wire control | | | |
| F2.03 | S3 Terminal Function Selection | 4:Forward Jogging | 4 | ● | 54. |
| | | 5:Reverse Jogging | | | |
| F2.04 | S4 Terminal Function Selection | | 7 | ● | 55. |

| Function Code | Name | Setting Range | Default Value | Modification | Serial No |
|-------------------------|---|--|---------------|--------------|-----------|
| F2.05 | S5 Terminal Function Selection | 6:Free run stop | 12 | ● | 56. |
| | | 7:Failure reset | | | |
| F2.06 | S6 Terminal Function Selection | 8:External fault input | 13 | ● | 57. |
| | | 9:Frequency setting(UP) | | | |
| | | 10:Frequency setting(DOWN) | | | |
| | | 11:Frequency up/down setting clear | | | |
| | | 12:Multi-Speed Terminal 1 | | | |
| | | 13:Multi-Speed Terminal 2 | | | |
| | | 14:Multi-Speed Terminal 3 | | | |
| | | 15:ACCEL/DECEL Time selection | | | |
| | | 16:PID control pause | | | |
| | | 17:Traverse pause at current frequency | | | |
| | | 18:Traverse reset | | | |
| | | 19:ACCEL/DECEL forbid | | | |
| | | 20~25:Reserved | | | |
| | | F2.07 | | | |
| 1: two-wire control 2 | | | | | |
| 2: three-wire control 1 | | | | | |
| 3: three-wire control 2 | | | | | |
| F2.08 | UP/DOWN frequency increment variable rate | 0.01~50.00Hz/s | 0.50Hz/s | ※ | 59. |
| F2.09 | VI lower limit | 0.00V~10.00V | 0.00V | ※ | 60. |
| F2.10 | VI lower limit corresponding setting | -100.0%~100.0% | 0.0% | ※ | 61. |
| F2.11 | VI upper limit | 0.00V~10.00V | 10.00V | ※ | 62. |
| F2.12 | VI upper limit corresponding setting | -100.0%~100.0% | 100.0% | ※ | 63. |
| F2.13 | VI input filtering time | 0.00s~10.00s | 0.10s | ※ | 64. |
| F2.14 | CI lower limit | 0.00V~10.00V | 0.00V | ※ | 65. |
| F2.15 | CI lower limit corresponding setting | -100.0%~100.0% | 0.0% | ※ | 66. |
| F2.16 | Clupper limit | 0.00V~10.00V | 10.00V | ※ | 67. |

| Function Code | Name | Setting Range | Default Value | Modification | Serial No |
|--|--------------------------------------|----------------------------------|---------------|--------------|-----------|
| F2.17 | CI upper limit corresponding setting | -100.0%~100.0% | 100.0% | ※ | 68. |
| F2.18 | CI input filtering time | 0.00s~10.00s | 0.10s | ※ | 69. |
| F2.19 | Mo1 output selection | 0: NO output | 1 | ※ | 70. |
| F2.20 | Mo2 output selection | 1: Frequency reached | 2 | ※ | 71. |
| F2.21 | Relay output selection | 2: FDT output | 3 | ※ | 72. |
| | | 3: Fault output | | | |
| | | 4: Motor running forward | | | |
| | | 5: Motor running reverse | | | |
| | | 6: Null speed operating | | | |
| | | 7: Upper limit frequency reached | | | |
| | | 8: Lower limit frequency reached | | | |
| | | 9~10: Reserved | | | |
| F2.22 | FM Analog output selection | 0: Setting frequency | 0 | ※ | 73. |
| | | 1: Running frequency | | | |
| | | 2: Output current | | | |
| | | 3: Output voltage | | | |
| | | 4: Running speed | | | |
| | | 5: Output power | | | |
| | | 6: Output torque | | | |
| | | 7: VI input value | | | |
| | | 8: CI input value | | | |
| | | 9~10: Reserved | | | |
| F2.23 | AO Lower limit | 0.0%~100.0% | 0.0% | ※ | 74. |
| F2.24 | Lower limit corresponding AO output | 0.00V~10.00V | 0.00V | ※ | 75. |
| F2.25 | AO Upper limit | 0.0%~100.0% | 100.0% | ※ | 76. |
| F2.26 | Upper limit corresponding AO output | 0.00V~10.00V | 10.00V | ※ | 77. |
| F3 Human Machine Interface Parameters | | | | | |
| F3.00 | User password | 0~65535 | 0 | ※ | 78. |
| F3.01 | Reserved | | | | 79. |
| F3.02 | Reserved | | | | 80. |

| Function Code | Name | Setting Range | Default Value | Modification | Serial No | |
|--|---|---|---------------|--------------|-----------|-----|
| F3.03 | STOP function option | 0: Keypad control valid | 0 | ※ | 81. | |
| | | 1: Keypad and terminal control valid | | | | |
| | | 2: Keypad and communication control valid | | | | |
| | | 3: All control modes valid | | | | |
| F3.04 | Keypad display option | 0: external keyboard preferential ENB | 0 | ※ | 82. | |
| | | 1: Local and external keyboard simultaneous display, only external key-press is valid. | | | | |
| | | 2: Local panel and external keyboard simultaneous display, only Local key-press is valid. | | | | |
| | | 3: Local and external keyboard simultaneous display, and all key-presses are valid (both are OR logical relation) | | | | |
| F3.05 | operation status display parameter option | Displayed Message | Code | 255 | ※ | 83. |
| | | 0: Setting frequency | 1 | | | |
| | | 1: Running frequency | 2 | | | |
| | | 2: Output current | 4 | | | |
| | | 3: Output voltage | 8 | | | |
| | | 4: Running speed | 16 | | | |
| | | 5: Output power | 32 | | | |
| | | 6: Output torque | 64 | | | |
| | | 7: DC bus voltage | 128 | | | |
| | | 8: PID setpoint | 256 | | | |
| | | 9: PID feedback | 512 | | | |
| | | 10: Input terminal status | 1024 | | | |
| | | 11: Output terminal status | 2048 | | | |
| | | 12: VI value | 4096 | | | |
| | | 13: CI value | 8192 | | | |
| 14: Current segment of multi-speed control | 16384 | | | | | |
| F3.06 | Stop status display parameter option | Setting frequency | 1 | 255 | ※ | 84. |
| | | DC bus voltage | 2 | | | |

| Function Code | Name | Setting Range | Default Value | Modification | Serial No |
|---------------|--|--|---------------|--------------|-----------|
| | | Input terminal status | 4 | | |
| | | Output terminal status | 8 | | |
| | | PID setpoint | 16 | | |
| | | PID feedback | 32 | | |
| | | VI value | 64 | | |
| | | CI value | 128 | | |
| | | Current segment of multi-speed control | 256 | | |
| F3.07 | operation status display preferential option | 0-14 (0:invalid) | 0 | ※ | 85. |
| F3.08 | IGBT module temperature | 0~100.0℃ | | ** | 86. |
| F3.09 | Software version | | | ** | 87. |
| F3.10 | Accumulative operating time | 0~65535h | 0 | ** | 88. |
| F3.11 | The fault before previous fault type | 0: No fault | | ** | 89. |
| | | 1:IGBT U phase protection(E009) | | ** | |
| F3.12 | Previous fault type | 2:IGBT V phase protection(E019) | | ** | 90. |
| F3.13 | Current fault type | 3:IGBT W phase protection(E029) | | ** | 91. |
| | | 4:Acceleration over-current(E004) | | | |
| | | 5:Deceleration over-current(E005) | | | |
| | | 6:Constant speed over-current (E006) | | | |
| | | 7:Acceleration over-voltage(E002) | | | |
| | | 8:Deceleration over-voltage(E00A) | | | |
| | | 9:Constant speed over-voltage (E003) | | | |
| | | 10:Bus under-voltage fault (E001) | | | |
| | | 11:Motor overload(E007) | | | |
| | | 12:Inverter overload(E008) | | | |
| | | 13:Input side phase failure(E012) | | | |
| | | 14:Output side phase failure(E013) | | | |
| | | 15:(Diode module overheat fault (E00E) | | | |
| | | 16:IGBT module overheat fault (E01E) | | | |
| | | 17:External fault(E017) | | | |

| Function Code | Name | Setting Range | Default Value | Modification | Serial No |
|---|--|--|---------------|--------------|-----------|
| | | 18:Communication fault(E018) | | | |
| | | 19:Current detect error(E015) | | | |
| | | 20:Motor self-learning error(E016) | | | |
| | | 21:EEPROM operation error (E00F) | | | |
| | | 22:PID feedback disconnect error (E02E) | | | |
| | | 23:Braking unit error (E01A) | | | |
| | | 24:Reserved | | | |
| F3.14 | Operating frequency at current fault | | 0.00Hz | ** | 92. |
| F3.15 | Output amperage at current fault | | 0.0A | ** | 93. |
| F3.16 | Bus voltage at current fault | | 0.0V | ** | 94. |
| F3.17 | Input terminal status at current fault | | 0 | ** | 95. |
| F3.18 | Output terminal status at current fault | | 0 | ** | 96. |
| F4 Application Function Parameters | | | | | |
| F4.00 | ACCEL Time 2 | 0.1~3600.0s | 10.0s | ※ | 97. |
| F4.01 | DECEL Time 2 | 0.1~3600.0s | 10.0s | ※ | 98. |
| F4.02 | Jogging frequency | 0.00~F0.04 | 5.00Hz | ※ | 99. |
| F4.03 | Jogging ACCEL time | 0.1~3600.0s | 10.0s | ※ | 100. |
| F4.04 | Jogging DECEL time | 0.1~3600.0s | 10.0s | ※ | 101. |
| F4.05 | Skip frequency | 0.00~F0.04 | 0.00Hz | ※ | 102. |
| F4.06 | Skip frequency range | 0.00~F0.04 | 0.00Hz | ※ | 103. |
| F4.07 | Traverse frequency range | 0.0~100.0% (relative to set frequency) | 0.0% | ※ | 104. |
| F4.08 | Kick frequency range | 0.0~50.0% (relative to traverse frequency range) | 0.0% | ※ | 105. |
| F4.09 | Traverse frequency up time | 0.1~3600.0s | 5.0s | ※ | 106. |
| F4.10 | Traverse frequency down time | 0.1~3600.0s | 5.0s | ※ | 107. |
| F4.11 | Fault auto-reset times | 0~3 | 0 | ※ | 108. |
| F4.12 | Interval time setting of automatic resetting fault | 0.1~100.0s | 1.0s | ※ | 109. |

| Function Code | Name | Setting Range | Default Value | Modification | Serial No |
|---------------|--|---|---------------|--------------|-----------|
| F4.13 | FDT level detection value | 0.00~F0.04 | 50.00Hz | ※ | 110. |
| F4.14 | FDTdelay detectionvalue | 0.0~100.0%(FDT level) | 5.0% | ※ | 111. |
| F4.15 | Frequency reaching detection range | 0.0~100.0%(maximum frequency) | 0.0% | ※ | 112. |
| F4.16 | Brake Threshold Value Voltage | 115.0~140.0%(standard DC bus voltage) 380V | 130.0% | ※ | 113. |
| | | 115.0~140.0%(standard DC bus voltage) 220V | 120.0% | | |
| F4.17 | Speed display ratio | 0.1~999.9% Speed=120×running frequency×F4.17/pole number | 100.0% | ※ | 114. |
| F4.18 | PIDsetpoint SourcesOption | 0: Given by Keyboard(F4.19) | 0 | ※ | 115. |
| | | 1: Given by Analog Channel VI | | | |
| | | 2: Given by Analog Channel CI | | | |
| | | 3: Given by Remote Communication | | | |
| | 4: Multi-segsetpoint | | | | |
| F4.19 | Preset PID setpoint | 0.0%~100.0% | 0.0% | ※ | 116. |
| F4.20 | PIDFeedback SourcesOption | 0: VI Feedback | 0 | ※ | 117. |
| | | 1: CI Feedback | | | |
| | | 2: VI+CI Feedback | | | |
| | | 3: Communication feedback | | | |
| F4.21 | PID Output Characteristics Option | 0: positive | 0 | ※ | 118. |
| | | 1: Pnegative | | | |
| F4.22 | Proportional gain (Kp) | 0.00~100.00 | 1.00 | ※ | 119. |
| F4.23 | Integral time (Ti) | 0.01~10.00s | 0.10s | ※ | 120. |
| F4.24 | Differential time (Td) | 0.00~10.00s | 0.00s | ※ | 121. |
| F4.25 | Sampling cycle time (T) | 0.01~100.00s | 0.10s | ※ | 122. |
| F4.26 | PIDcontrol discrepancy limit | 0.0~100.0% | 0.0% | ※ | 123. |
| F4.27 | Feedback disconnection detecting value | 0.0~100.0% | 0.0% | ※ | 124. |
| F4.28 | Feedback disconnection detecting time | 0.0~3600.0s | 1.0s | ※ | 125. |
| F4.29 | Multi-Speed 0 | -100.0~100.0% | 0.0% | ※ | 126. |
| F4.30 | Multi-Speed 1 | -100.0~100.0% | 0.0% | ※ | 127. |

| Function Code | Name | Setting Range | Default Value | Modification | Serial No |
|------------------------------------|--|------------------------------------|---------------|--------------|-----------|
| F4.31 | Multi-Speed 2 | -100.0~100.0% | 0.0% | ※ | 128. |
| F4.32 | Multi-Speed 3 | -100.0~100.0% | 0.0% | ※ | 129. |
| | Multi-Speed 4 | ~ | 0.0% | ※ | 130. |
| F4.33 | Multi-Speed 5 | -100.0~100.0% | 0.0% | ※ | 131. |
| F4.34 | Multi-Speed 6 | -100.0~100.0% | 0.0% | ※ | 132. |
| F4.35 | Multi-Speed 7 | -100.0~100.0% | 0.0% | ※ | 133. |
| F5 Protection Parameters | | | | | |
| F5.00 | Motor Overload ProtectionOption | 0: No protection | 1 | ● | 134. |
| | | 1: normal motor | | | |
| | | 2: Variable Frequency motor | | | |
| F5.01 | Motor Overload ProtectionCurrent | 20.0%~120.0% (motor rated current) | 100.0% | ※ | 135. |
| F5.02 | Power-down Frequency Drop Point | 70.0~110.0%(standard bus voltage) | 80.0% | ※ | 136. |
| F5.03 | Instant power-down Frequency drop rate | 0.00Hz~F0.04 | 0.00Hz | ※ | 137. |
| F5.04 | Over-voltage Stall Protection | 0: prohibit | 0 | ※ | 138. |
| | | 1: allow | | | |
| F5.05 | Over-voltage Stall ProtectionVoltage | 110~150%(380V) | 120% | ※ | 139. |
| | | 110~150%(220V) | 115% | | |
| F5.06 | Auto limit current level | 100~200% | 200% | ※ | 140. |
| F5.07 | Limit current frequency drop rate | 0.00~50.00Hz/s | 0.00Hz/s | ※ | 141. |
| F6 Communication Parameters | | | | | |
| F6.00 | Communication Address | 1~247,0 is the broadcast address | 1 | ※ | 142. |
| F6.01 | Baud rate setting | 0: 1200BPS | 3 | ※ | 143. |
| | | 1: 2400BPS | | | |
| | | 2: 4800BPS | | | |
| | | 3: 9600BPS | | | |
| | | 4: 19200BPS | | | |
| 5: 38400BPS | | | | | |
| F6.02 | Data pattern | 0:Nocheck (N,8,1) for RTU | 0 | ※ | 144. |
| | | 1:Oddcheck (E,8,1) for RTU | | | |
| | | 2:Evencheck (O,8,1) for RTU | | | |

| Function Code | Name | Setting Range | Default Value | Modification | Serial No | | | | | |
|---------------|-----------------------------|---|---------------|--------------|-----------|-----------------------------------|----------------------------|------|---|------|
| | | 3:No check (N,8,2) for RTU | | | | | | | | |
| | | 4:Odd check (E,8,2) for RTU | | | | | | | | |
| | | 5:Even check (O,8,2) for RTU | | | | | | | | |
| | | 6:No check (N,7,1) for ASCII | | | | | | | | |
| | | 7:Odd check (E,7,1) for ASCII | | | | | | | | |
| | | 8:Even check (O,7,1) for ASCII | | | | | | | | |
| | | 9:No check (N,7,2) for ASCII | | | | | | | | |
| | | 10:Odd check (E,7,2) for ASCII | | | | | | | | |
| | | 11:Even check (O,7,2) for ASCII | | | | | | | | |
| | | 12:No check (N,8,1) for ASCII | | | | | | | | |
| | | 13:Odd check (E,8,1) for ASCII | | | | | | | | |
| | | 14:Even check (O,8,1) for ASCII | | | | | | | | |
| | | 15:No check (N,8,2) for ASCII | | | | | | | | |
| | | 16:Odd check (E,8,2) for ASCII | | | | | | | | |
| | | 17:Even check (O,8,2) for ASCII | | | | | | | | |
| | | F6.03 | | | | Communication response delay | 0~200ms | 5ms | ※ | 145. |
| | | F6.04 | | | | Communication overtime fault time | 0.0 (invalid) , 0.1~100.0s | 0.0s | ※ | 146. |
| F6.05 | Communication error measure | 0: Alarm and free run stop | 1 | ※ | 147. | | | | | |
| | | 1: No alarm and keep running | | | | | | | | |
| | | 2: No alarm and stop according to stop mode (by communication) | | | | | | | | |
| | | 3: No alarm and stop according to stop mode (by all control mode) | | | | | | | | |
| F6.06 | Response measure | 0: Response when write | 0 | ※ | 148. | | | | | |
| | | 1: No response when write | | | | | | | | |

F0 Basic Function Parameters

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------|--|---------------|
| F0.00 | Control mode | 0: Speed sensorless vector control (SVC) | 1 |
| | | 1: V/F control | |

Selection of Speed Control Mode

0: Vector Control without PG: Open loop vector control

This control mode is suitable for the application requiring high torque at low speed and superior speed control. One inverter can drive only one motor. E.g. machine tool, wiring machine, plastic injection machine etc.

1: V/F Control Mode

V/F control mode is suitable for the application which does not require high control accuracy, e.g. pump and fans, and also suitable for cases with one inverter driving multiple motors.

Note: If vector control mode is selected, it is a must to correctly set up the nameplate parameters of motor, and accomplish self learning of motor parameters before operation to acquire correct motor parameters. Only obtaining correct motor parameters can exert the high performance of vector control mode.

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------------------|------------------|---------------|
| F0.01 | Command source selection | 0: Keyboard | 0 |
| | | 1: Terminal | |
| | | 2: Communication | |

Path Selection for the inverter Control Command

0: Keyboard Command Path

The buttons RUN and STOP on the keyboard are for operation control.

1: Terminal Command Path

Multifunction input terminals of forward, reverse, forward jogging, reverse jogging and so on, perform the operation command control.

2: Communication Command Path

Operation command control is performed through communication pattern by upper level machine.

| Function Code | Name | Setting Range | Default Value |
|---------------|---------------------------------------|--|---------------|
| F0.02 | Keyboard and terminal UP/DOWN setting | 0: Keyboard and terminal UP/DOWN setting | 0 |
| | | 1: Valid, and inverter does not memorize when power down | |
| | | 2: Invalid | |

DZB200&300series inverter can set up the frequency though "▲" and "▼" buttons on the keyboard and terminal UP/DOWN (Frequency setting increase /Frequency setting decrease), and as it has the highest priority, it can combine with any other frequency setting path to mainly accomplish the fine adjustment of inverter output frequency during control system commissioning.

0: Valid, and the inverter memorizes when power down. Able to set up frequency command, and memorize this set frequency when the inverter is power down. When the power is back, automatically combine it with current frequency setting.

1: Valid, and the inverter does not memorize when power is down. Able to set up frequency, but when the inverter power is down, this frequency setting is not memorized.

2: Invalid. The frequency set through keyboard and terminal UP/DOWN is automatically cleared, and the settings through keyboard and terminal UP/DOWN are invalid.

Note: After the user restores the default values of inverter function parameters, the frequency value, set through keyboard and terminal UP/DOWN, is automatically cleared.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------|------------------|---------------|
| F0.03 | Frequency command Selection | 0: Keyboard | 0 |
| | | 1: VI | |
| | | 2: CI | |
| | | 3: VI+ CI | |
| | | 4: Multi-speed | |
| | | 5: PID control | |
| | | 6: Communication | |

Selection of inverter frequency command input channels. There are 7 main frequency setting channels:

0: Keyboard

Accomplish keyboard frequency setting by means of modifying the value of function code F0.07 "Keyboard frequency setting".

1: VI

2: CI

3: VI+ CI

This means that the frequency is set up through analog input terminals. DZB series inverter provides 2 analog input channel. VI is 0-10V voltage input mode, while CI can be 0-10V input or 0(4)-20mA input.

The 100.0% setting of analog input is corresponding to the maximum frequency (Function Code F0.04), and -100.0% is corresponding to maximum reverse frequency (Function Code F0.04).

4: Multi-speed operation

The inverter is operated in the mode of multi-speed once this frequency setting mode is chosen. It is needed to set up the parameters of F2 Group and F4 Group "Multi-speed control group" to determine the coincidence relation between given percentage and given frequency.

5: PID control

Selection of this parameter means that the operation mode of inverter is PID control mode. In this case, it is required to set up F4 Group "PID control group". The operation frequency of inverter is the frequency value which PID gives. Please refer to the description of F4 Group "PID functions" for the definition of PID setpoint source, assigned value, feedback source and so on.

6: Remote communication

The frequency command is given in the communication mode by upper position machine. For details, please refer to "DZB Series inverter ModBus Communication Protocol".

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------------------|----------------|---------------|
| F0.04 | Maximum output frequency | 10.00~600.00Hz | 50.00Hz |

It is used to set up the maximum output frequency of inverter. Please note that, it is the basis of frequency setting and acceleration/deceleration speed.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------|---------------|---------------|
| F0.05 | Upper limit frequency | F0.06~F0.04 | 50.00Hz |

It is the upper limit of inverter output frequency, which should be less than or equal to the maximum output frequency.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------|---------------|---------------|
| F0.06 | Lower limit frequency | 0.00 Hz~F0.05 | 0.00Hz |

The lower limit of inverter output frequency.

If setpoint frequency is lower than lower limit frequency when startup, inverter can not run. operate at the lower limit frequency, stop or be dormant. Therein, Maximum output frequency \geq upper limit frequency \geq lower limit frequency.

| Function Code | Name | Setting Range | Default Value |
|---------------|----------------------------|---------------|---------------|
| F0.07 | Keyboard frequency setting | 0.00 Hz~F0.04 | 50.00Hz |

When Frequency Command is chosen as "keyboard Setting", this function code value is the initial set value of inverter frequency.

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------|---------------|---------------|
| F0.08 | ACCEL time 1 | 0.1~3600.0s | 10.0s |
| F0.09 | DECEL time 1 | 0.1~3600.0s | 10.0s |

Acceleration time means the time t1 required for inverter to accelerate to the maximum output frequency (F0.04) from 0Hz.

Deceleration time is the time t2 required for inverter to decelerate to 0Hz from the maximum output frequency (F0.04).

It is indicated by following figure




Fig 6-1 Acceleration and Deceleration time diagram

When the set frequency is equal to the maximum frequency, the actual Acceleration/Deceleration time are equal to the set Acceleration/Deceleration time.

When the set frequency is less than the maximum frequency, the actual Acceleration/Deceleration time are less than the set Acceleration/Deceleration time.

Actual Acceleration/Deceleration time = set Acceleration/Deceleration time \times (set frequency/max. frequency)

DZB200&300 series inverter has 2 groups of Acceleration/Deceleration time.

1st group: F0.08, F0.09;

2nd group: F4.00, F4.01;

The Acceleration /Deceleration time can be chosen through multifunction digital input terminal (F2 Group).

| Function Code | Name | Setting Range | Default Value |
|---------------|-------------------------------|-----------------------------------|---------------|
| F0.10 | Operation direction selection | 0: Operating at default direction | 2 |
| | | 1: Operating at reverse direction | |
| | | 2: NO inverse operating | |

0: Operating at default direction. When the inverter is power connected, it operates at the actual direction.

1: Operating at reverse direction. By means of changing the function code, the motor rotating direction can be changed without changing any other parameters, which is equivalent to change the motor rotating direction by exchanging any two of motor cables (U, V, W).

Note: After the parameters are initialized, the motor operating direction can be restored to be its original state. Be caution to use it in the case that changing motor rotating direction is forbidden after the system commissioning is completed.

2: Forbid inverse operating. Forbidding inverter inverse operation is suitable to specific application that inverse operating is forbidden.

| Function Code | Name | Setting Range | Default Value |
|---------------|---------------------------|---------------|---------------|
| F0.11 | Carrier frequency setting | 1.0~15.0kHz | Set by model |

| Carrier frequency | Electromagnetic noise | Cacophony, Leakage current | Heat radiation |
|-------------------|-----------------------|----------------------------|----------------|
| 1KHz | ↑ large | ↑ small | ↑ small |
| 10KHz | ↕ | ↕ | ↕ |
| 15KHz | ↓ small | ↓ large | ↓ large |

Fig 6-2 Relationship between environment and Carrier frequency

Relationship between Model and Carrier frequency

| Carrier frequency / Model | Max carrier frequency (KHz) | Min carrier frequency (KHz) | Factory setting (KHz) |
|---------------------------------|-----------------------------|-----------------------------|-----------------------|
| B: 0.4kW~11KW P: 0.75kW~15KW | 15 | 1 | 8 |
| B: 15kW~55KW P: 18.5kW~75KW | 8 | 1 | 4 |
| B: 75kW~300KW P: 90kW~315KW | 6 | 1 | 2 |

This function is mainly used to improve the motor operating noise and inverter interference to external. The advantages of using high carrier frequency: relatively ideal current wave shape, less harmonic current wave and low motor noise;

The disadvantages of using high carrier frequency: increased switch loss and inverter temperature rises, affecting inverter output capacity so that it should be operated at derating under high carrier frequency conditions; in the mean time, inverter leakage current and its electromagnetic interference to external are increased.

The situations of using low carrier frequency is on the contrary. Too low carrier frequency can cause operation unstable, torque reduced and even oscillation at low frequency.

When inverter is factory released, its carrier frequency has been set properly. Generally the user does not need to modify this parameter.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------------|---------------------------|---------------|
| F0.12 | Functional parameters restoration | 0: NO operation | 0 |
| | | 1: Restore default value | |
| | | 2: Delete failure records | |

1: The inverter restores all parameters to their default value.

2: The inverter deletes recent failure records.

After the chosen function operation is completed, this function code is automatically restored to 0.

| Function Code | Name | Setting Range | Default Value |
|---------------|---------------|--------------------------------|---------------|
| F0.13 | AVR selection | 0: Invalid | 1 |
| | | 1: Valid all the time | |
| | | 2: Invalid during deceleration | |

AVR means output voltage auto regulation. When AVR is invalid, output voltage will change according to the change of input voltage (or DC bus voltage); When AVR is valid, output voltage will remain constant within output capacity.

| Function Code | Name | Setting Range | Default Value |
|---------------|------------|---|---------------|
| F0.14 | Start Mode | 0: Direct start | 0 |
| | | 1: DC braking first and then start | |
| | | 2: Running speed pick-up and then start | |

0: Direct start: start from the starting frequency.

1: DC braking first and then start: First perform DC braking (pay attention to set up parameters F0.17 and F0.18), and then start and run the motor at the start frequency. It is suitable for small inertia loading which can cause reverse rotation at starting.

2: Running speed pick-up and then start: the inverter first calculates motor rotating speed and direction, and then start running to its set frequency from current speed, performing a smooth no-shock start to moving motor. This mode is applicable to momentary power-down start when the inertia loading is big.

| Function Code | Name | Setting Range | Default Value |
|---------------|------------------------------|---------------|---------------|
| F0.15 | Start frequency | 0.00~10.00Hz | 0.50Hz |
| F0.16 | Hold time of start frequency | 0.0~50.0s | 0.0s |

Setting proper starting frequency can increase the starting torque. Within the hold time of the starting frequency (F0.16), the inverter output frequency is the starting frequency, and then, from the starting frequency, running to the target frequency. If the target frequency (frequency command) is less than the

starting frequency, inverter does not operate and is at stand-by state. The starting frequency value is not restricted by the lower limit frequency.

During FWD/REV switching, the starting frequency is inactive.

| Function Code | Name | Setting Range | Default Value |
|---------------|---------------------------------|---------------|---------------|
| F0.17 | Braking current before starting | 0.0~150.0% | 0.0% |
| F0.18 | Braking time before starting | 0.0~50.0s | 0.0s |

When it is being started, the inverter first performs DC braking according to the set prior-to-starting DC braking current, and after the set prior-to-starting DC braking time is passed then begins to perform acceleration. If the set DC braking time is 0, DC braking is invalid.

The bigger the DC braking current, the greater the braking force. The prior-to-starting DC braking current is the percentage of the rated inverter current.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------|------------------|---------------|
| F0.19 | Stop Mode | 0: DECEL Stop | 0 |
| | | 1: Free run Stop | |

0: Deceleration stop

After the stop command is enabled, the inverter decreases the output frequency according to the Deceleration mode and the defined Acceleration /Deceleration time, and the motor is stopped when the frequency is 0.

1: Free-run stop

Once the stop command is valid, the inverter immediately ends the output. The loading is freely stopped by its mechanical inertia.

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------------------------|---------------|---------------|
| F0.20 | Beginning Frequency of braking | 0.00~ F0.04 | 0.00Hz |
| F0.21 | Waiting time of braking | 0.0~50.0s | 0.0s |
| F0.22 | DC braking current | 0.0~150.0% | 0.0% |
| F0.23 | DC braking time | 0.0~50.0s | 0.0s |

Beginning frequency of DC brake when stopping. During the Deceleration stop, when this frequency is reached, the DC brake is started.

Waiting time of DC brake when stopping: Prior to the DC brake, the inverter blocks the output, and after this delay time, the DC braking is started. It is used to prevent over-current fault caused by DC braking at high speed.

DC brake current when stopping: indicates the applied DC brake energy. The bigger the current, the stronger the DC brake energy should be.

DC brake time when stopping: the durative time that the DC brake energy is applied. If the time is 0, DC brake is invalid, and the inverter stops the motor based on the set Deceleration time.




Fig. 6-3 DC Brake Diagram

| Function Code | Name | Setting Range | Default Value |
|---------------|---------------------------------------|---------------|---------------|
| F0.24 | Dead time between forward and reverse | 0.0~3600.0s | 0.0s |

It is to set the transient time during which the output frequency is 0 in the FWD/REV transient process of inverter.

It is shown as following figure:




Fig. 6-4 FWD/REV Dead Time Diagram

| Function Code | Name | Setting Range | Default Value |
|---------------|---|--|---------------|
| F0.25 | Terminal command protection when power on | 0: Terminal command invalid when power on 1: Terminal command valid when power on | 0~1 |

If operating command channel is set to terminal control, system will detect terminal status automatically during inverter power on.

0: Terminal command invalid when power on. Inverter will not run if it detect operating command terminal is valid. When the operating command terminal is invalid and enable this terminal again, inverter will run.
1: Terminal command valid when power on. Inverter will startup automatically after initialization is finished if it detect operation command terminal is valid.

Note: Customer should be careful when you select this function, it may cause severe consequence.

F1 Motor Parameters

| Function Code | Name | Setting Range | Default Value |
|---------------|----------------|---------------|---------------|
| F1.00 | Inverter model | 0: B model | Set by model |
| | | 1: P model | |

0: suitable for constant torque load of designated nominal parameter.

1: suitable for variable torque load (such as fan and pump).

Constant torque(B model) inverter can drive larger variable torque(P model) load directly.

Forexample, 'DZB300B0220L4' inverter is set 22KW B model as default, if you want to drive 30KW fan, you should

- Set F1.00 as 1
- Set F1 group motor parameter again

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------|---------------|---------------|
| F1.01 | Motor rated power | 0.4~900.0kW | Set by model |
| F1.02 | Motor rated frequency | 0.01Hz~F0.04 | 50.00Hz |
| F1.03 | Motor rated speed | 0~36000rpm | Set by model |
| F1.04 | Motor rated voltage | 0~460V | Set by model |
| F1.05 | Motor rated current | 0.1~1000.0A | Set by model |

Note: please set these codes according to motor nameplate parameters. The superior performances of vector control require precise motor parameters.

DZB series inverter provides parameter self-learning function. Accurate parameter self-learning comes from correct setting of motor nameplate parameters.

In order to ensure the control performances, please do the motor setting based on the inverter standard adaptive motor. If the motor rated power has a too big difference to the standard adaptive motor, the inverter control performances will be deteriorated distinctly.

Note: resetting of motor rated power (F1.01) can initialize motor parameter F1.02-F1.10.

| Function Code | Name | Setting Range | Default Value |
|---------------|---|----------------|---------------|
| F1.06 | Motor stator resistance | 0.001~65.535 Ω | Set by model |
| F1.07 | Motor rotor resistance | 0.001~65.535 Ω | Set by model |
| F1.08 | Motor stator/rotor inductance | 0.1~6553.5mH | Set by model |
| F1.09 | Mutual inductance of motor stator/rotor | 0.1~6553.5mH | Set by model |
| F1.10 | No-load current | 0.01~655.35A | Set by model |

After the motor self-learning is normally ended, F1.06-F1.10 setting values are automatically replaced. These parameters are the basis of high performance vector control and have direct effect on the control performance.

Important: users DO NOT change this group parameters at will.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------------|----------------------------------|---------------|
| F1.11 | Self-learning of motor parameters | 0: NO operation | 0 |
| | | 1: complete tuning Self-learning | |
| | | 2: static tuning Self-learning | |

Note: This function is invalid for DZB200Series.

0: NO operation, forbidding self-learning.

1: self-learning of parameters

Prior to parameters self-learning, the motor must be disconnected with its load-ensuring the motor at no-load condition, and confirming the motor is at static state.

Prior to parameters self-learning, it is a must to correctly input the motor nameplate parameters (F1.01~F1.05), otherwise what is self learned about motor parameters may be not correct.

Prior to parameters self-learning, the Acceleration and Deceleration time (F0.08 and F0.09) should be set properly based on the motor inertia, otherwise over current fault may happen during motor parameters self-learning.

When the self-learning of motor parameters is started by setting F1.11 as 1 and then pushing the button FUNC/DATA, LED displays “-TUN-” and flickering, then push the button RUN to begin the procedure of the motor parameters self-learning. At this time, “TUN-0” is displayed. After the motor is started, “TUN-1” is shown and “RUN” light is flickering.

When the self-learning of parameters is finished, “-END-” is displayed, and finally back to the stop state interface.

When “-TUN-” is blinking, the process of parameters self-learning can exit by pushing the button PRGM/RESET.

During the process of parameters self-learning, it can be stopped by pressing the button STOP.

Please note, the start and stop of the parameters self-learning can only be done through keypad. Once the parameter self-learning is finished, this function code automatically restores to 0.

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------------------------|---------------|---------------|
| F1.12 | Speed loop proportional gain1 | 0~100 | 30 |
| F1.13 | Speed loop integral time 1 | 0.01~10.00s | 0.50s |
| F1.14 | Switching low point frequency | 0.00Hz~F1.17 | 5.00Hz |
| F1.15 | Speed loop proportional gain 2 | 0~100 | 25 |
| F1.16 | Speed loop integral time 2 | 0.01~10.00s | 1.00s |
| F1.17 | Switching high point frequency | F1.14~F0.04 | 10.00Hz |

Above parameters are valid only to vector control, but invalid to V/F control. When the frequency is less than the switching frequency point 1 (F1.14), the speed loop PI parameters are F1.12 and F1.13. When frequency is higher than the switching frequency point 2 (F1.17), the speed loop PI parameters are F1.15 and F1.16. Between the switching points, PI parameter is acquired according to the line type variation of the two group parameters, as shown in following figure




Fig. 6-5 PI Parameter Diagram

By means of setting the proportion factor and integration time of the speed regulator, the speed dynamic response of vector control can be regulated. Increasing the proportional gain, and reducing the integration time, can equally quicken the dynamic response of speed loop, but either the proportional gain being too much or the integration time being too short can easily cause system oscillation and too big overshoot. The proportional gain being too small also can lead to system steady state oscillation and possibility of speed steady-state error occurring

Speed loop PI parameters have an intimate relation with the inertia of motor system, and therefore based on the default PI parameter the user needs to make adjustment for different loading character in order to meet different requirement.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------|---------------|---------------|
| F1.18 | VC slip compensating factor | 50%~200% | 100% |

The slip compensating factor is used to adjust the slip frequency of vector control and improve the system speed control accuracy. Properly regulating this parameter can effectively restrain the speed steady-state error.

| Function Code | Name | Setting Range | Default Value |
|---------------|----------------------------|------------------------------------|---------------|
| F1.19 | Upper torque limit setting | 0.0~200.0%(inverter rated current) | 150.0% |

The setting 100.0% is corresponding to the rated output current.

The function code below (F1.20~F1.24) are valid to V/F control (F0.00=1), but invalid to vector control.

| Function Code | Name | Setting Range | Default Value |
|---------------|-------------------|----------------------------|---------------|
| F1.20 | V/F curve setting | 0: Linear V/F curve | 0 |
| | | 1: square torque V/F curve | |

0: Linear V/F curve. It is applicable to constant torque load.

1: 2.0 exponential V/F curve. It is applicable to variable torque load, such as blower, pump etc.




Fig. 6-6 V/F curve diagram

| Function Code | Name | Setting Range | Default Value |
|---------------|----------------------|--|---------------|
| F1.21 | Torque boost | 0.0%: (auto) 0.1%~30.0% | 0 |
| F1.22 | Torque boost cut-off | 0.0%~50.0% (relative to motor rated frequency) | 20.0% |

Torque Boost is mainly applied to less than cut-off frequency (F1.22). The V/F curve after boost is shown in following figure. Torque boost can improve the low frequency torque performance of V/F control.

Based on the load, a torque should be chosen properly. For heavy load, increase the torque boost, but the torque boost should not be set too big, which will result in the motor operating at overexcitation and that it could be overheated, and also the inverter output current is big, reducing efficiency.

When the torque boost is set as 0.0%, the inverter is at automatic torque boost.

Torque boost cut-off frequency: below this frequency, torque boost is valid, and above this frequency setting, torque boost is invalid.




Fig. 6-7 Manual torque boost diagram

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------|---------------|---------------|
| F1.23 | V/F slip compensation limit | 0.0~200.0% | 100% |

Setting this parameter can compensate the motor speed change produced because of undertaking loading while on V/F control, to increase the rigidity of motor mechanical performance. This value should be set as the motor rated slip frequency.

| Function Code | Name | Setting Range | Default Value |
|---------------|-------------------------------|----------------------|---------------|
| F1.24 | Energy Conservation Selection | 0:No Operation | 0 |
| | | 1:EnergyConservation | |

When the motor is running in no-load or lower-load during, the inverter can adjust output voltage by automatically current kf the load.

Note: This function is especially valid for variable torque load (such as fan and pump).

F2 Input and Output Terminal Function Parameters


| Function Code | Name | Setting Range | Default Value |
|---------------|----------------------------|---------------|---------------|
| F2.00 | On-off signal filter times | 1~10 | 5 |

It sets up S1-S6, VI and CI terminals sample filtering time. In big interference situation, this parameter should be increased in order to prevent mal operation.

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------------------------|---------------|---------------|
| F2.01 | S1 Terminal Function Selection | 0~25 | 1 |
| F2.02 | S2 Terminal Function Selection | 0~25 | 2 |
| F2.03 | S3 Terminal Function Selection | 0~25 | 4 |
| F2.04 | S4 Terminal Function Selection | 0~25 | 7 |
| F2.05 | S5 Terminal Function Selection | 0~25 | 12 |
| F2.06 | S6 Terminal Function Selection | 0~25 | 13 |

These parameters are used to set up the corresponding functions of digital multifunction input terminals.

| setting value | Function | Description |
|---------------|------------------------------|---|
| 0 | No Function | Even if there is a signal input, the inverter does not run. Terminals which are not used can be set to be no function in order to prevent malfunction |
| 1 | Forward | The inverter's forward or reverse running can be control by external terminals. |
| 2 | Reverse | |
| 3 | three-wire operation control | By means of this terminal the inverter's operation mode can be defined to be three-wire control mode. For details, please refer to the function code description of F2.07 three-wire control mode. |
| 4 | Forward Jogging | At Jogging operation, the frequency and Jogging Acceleration/Deceleration time can be found in detail descriptions of F4.02, F4.03 and F4.04 function codes. |
| 5 | Reverse Jogging | |
| 6 | Free-run stop | The inverter turns off output, and the motor stop process is not controlled by the inverter. It is often applied when the inertia loading is big and there is no requirement on stop time. This mode has the same definition as F0.19 does. |
| 7 | Failure reset | This is external failure reset. It has the same function as STOP button on the keyboard. Using this function can perform long-distance failure reset. |
| 8 | External fault input | When external fault signal is input, the inverter reports it and stops. |

| 9 | Frequency up setting | When the frequency is set by external terminal, modify the frequency up and down command. When the frequency source is set as digital setting, the set frequency can be regulated up and down.  | | | | | | | | | |
|----------|-----------------------------------|--|--|------------------------|-----------|-----|-------------|--------------|----|-------------|--------------|
| 10 | Frequency down setting | | | | | | | | | | |
| 11 | Frequency up/down setting clear | | Using terminal can clear UP/DOWN set frequency so that set frequency can be restored the frequency setting given by frequency command channel. | | | | | | | | |
| 12 | Multi-speed terminal 1 | 8 stages speed can be set up via these 3 terminals digital state combination. Note: multi-speed 1 is the low position, and multi-speed 3 is the high position. | | | | | | | | | |
| 13 | Multi-speed terminal 2 | | | | | | | | | | |
| 14 | Multi-speed terminal 3 | | | | | | | | | | |
| 15 | ACCE/DCCE time selection terminal | 2 kinds of ACCE/DCCE time can be chosen via these two terminals digital state combination. <table border="1" data-bbox="1579 598 2072 726"> <thead> <tr> <th>Terminal</th> <th>ACC/DCC time selection</th> <th>Parameter</th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>ACCE time 0</td> <td>F0.08, F0.09</td> </tr> <tr> <td>ON</td> <td>ACCE time 1</td> <td>F4.00, F4.01</td> </tr> </tbody> </table> | Terminal | ACC/DCC time selection | Parameter | OFF | ACCE time 0 | F0.08, F0.09 | ON | ACCE time 1 | F4.00, F4.01 |
| Terminal | ACC/DCC time selection | Parameter | | | | | | | | | |
| OFF | ACCE time 0 | F0.08, F0.09 | | | | | | | | | |
| ON | ACCE time 1 | F4.00, F4.01 | | | | | | | | | |
| 16 | PID control pause | PID is temporarily out of work, and the inverter keeps its current frequency output. | | | | | | | | | |
| 17 | Traverse pause | The inverter pauses at its current output frequency. After this function is cancelled, continue to start its traverse operation at its current frequency. | | | | | | | | | |
| 18 | Traverse reset | The inverter is back to its center frequency output. | | | | | | | | | |
| 19 | Acceleration/Deceleration forbid | Ensure the inverter is not interfered by external signals (excluding stop command), maintaining its current output frequency. | | | | | | | | | |
| 20~25 | Reserved | Reserved | | | | | | | | | |

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------|-------------------------|---------------|
| F2.07 | Terminal control mode | 0: two-wire control 1 | 0 |
| | | 1: two-wire control 2 | |
| | | 2: three-wire control 1 | |
| | | 3: three-wire control 2 | |

This parameter defines four different control modes which controls the inverter operation through external terminals.

0: Two-wiretype control, integrate Enable with direction. This mode is the most often used two-wire control mode. The motor forward and reverse operations are determined by the defined FWD and REV terminal command.




Fig. 6-8 Two-wire operation mode 1

1: Two-wire control, separate Enable from direction. When this mode is used, the defined FWD is enable terminal. The direction is determined by the defined REV state.




Fig. 6-9 Two-wire operation mode 2

2: Three-wire control 1, integrate Enable with direction. At this mode, EN is the Enable terminal with the direction controlled by the defined FWD. REV define the direction.




Fig. 6-10 Three-wire operation mode 1

K: FWD/REV switch SW1: RUN button SW2: STOP button

EN is defining the corresponding terminal function as Function 3 “Three-wire operation control”.

3: Three-wire control, separate Enable from direction. At this mode EN is the Enable terminal, SW1 or SW2 define operating command and control direction at the same time. Stop command is defined by SW2.




Fig. 6-11 Three-wire operation mode 2

SW1: FWD operating button SW2: STOP button K: REV operating button
EN is defining the corresponding terminal function as Function 3 “Three-wire operation control”.

Note: For two-wire operation mode, when FWD/REV terminal is enabled and the stop command produced by other sources stops the equipment, the inverter does not start to operate after the stop command disappears even if the control terminal FWD/REV is still valid. If the inverter needs to operate, it is required to trigger FWD/REV again.

| Function Code | Name | Setting Range | Default Value |
|---------------|---|----------------|---------------|
| F2.08 | UP/DOWN frequency increment variable rate | 0.01~50.00Hz/s | 0.50Hz/s |

Terminal UP/DOWN regulates the change rate of frequency setting.

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------------------------------|----------------|---------------|
| F2.09 | VI lower limit | 0.00V~10.00V | 0.00V |
| F2.10 | VI lower limit corresponding setting | -100.0%~100.0% | 0.0% |
| F2.11 | VI upper limit | 0.00V~10.00V | 10.00V |
| F2.12 | VI upper limit corresponding setting | -100.0%~100.0% | 100.0% |
| F2.13 | VI input filtering time | 0.00s~10.00s | 0.10s |

Above function codes define the relationship between analog input voltage and the setting value that analog input is corresponding to. When the analog input voltage exceeds the range of the set maximum or minimum input, the beyond portion should be calculated with maximum input or minimum input.

When analog input is amperage input, 0mA-20mA is corresponding to 0V-10V.

For different applications, the corresponding nominal value of analog setting 100.0% is different. For details, please refer to each application description.

Following figures shows several settings. Note: VI lower limit must be less or equal to VI upper limit.




Fig. 6-12 Relationship between analog input and setting value

VI input filtering time determines analog input sensitiveness. Increasing this parameter, in order to prevent malfunction caused by interference to the analog, can strengthen the anti-interference ability, but reduce the analog input sensitiveness.

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------------------------------|----------------|---------------|
| F2.14 | CI lower limit | 0.00V~10.00V | 0.00V |
| F2.15 | CI lower limit corresponding setting | -100.0%~100.0% | 0.0% |
| F2.16 | Clupper limit | 0.00V~10.00V | 10.00V |
| F2.17 | CI upper limit corresponding setting | -100.0%~100.0% | 100.0% |
| F2.18 | CI input filtering time | 0.00s~10.00s | 0.10s |

CIfunction settings are similar to VI setting method.

DZB Series inverter provides 2 paths of analog input port.

DZB Series inverter standard unit has two multifunction digital output terminal, one (or two) multifunction relay output terminals and one analog output terminal.

| Function Code | Name | Setting Range | Default Value |
|---------------|------------------------|---------------|---------------|
| F2.19 | Mo1output selection | 0~10 | 1 |
| F2.20 | Mo2output selection | 0~10 | 2 |
| F2.21 | Relay output selection | 0~10 | 3 |

Open collector output functions are indicated as following table:

| Setting Value | Function | Description |
|---------------|-------------------------------|--|
| 0 | Zero Output | Output terminal has no function |
| 1 | Frequency reached | please refer to the detail description of function code F4.15 |
| 2 | FDT reached | please refer to the detail description of function code F4.13,F4.14 |
| 3 | Fault output | Once inverter fault happens, output ON signal |
| 4 | Inverter is running forward | ON signal Indicates the inverter is running forward with output frequency. |
| 5 | Inverter is running reverse | ON signal Indicates the inverter is running reverse with output frequency. |
| 6 | Null speed operation | When the inverter output frequency is less than the starting frequency, output ON signal |
| 7 | Upper limit frequency reached | When the operating frequency reaches the upper frequency limit, output ON signal. |
| 8 | Lower limit frequency reached | When the operating frequency reaches the lower frequency limit, output ON signal. |
| 9~10 | Reserved | Reserved |

| Function Code | Name | Setting Range | Default Value |
|---------------|----------------------------|---------------|---------------|
| F2.22 | FM Analog output selection | 0~10 | 0 |

The standard analog output is 0-20mA (or 0-10V). Current or voltage output can be selected by Jumper S2. Its corresponding value range is shown as following table:

| Setting Value | Function | Range |
|---------------|---------------------|---------------------------------|
| 0 | Setting frequency | 0-maximum output frequency |
| 1 | Operating frequency | 0-maximum output frequency |
| 2 | Output current | 0-double rated inverter current |
| 3 | Output voltage | 0-double rated inverter voltage |
| 4 | Motor speed | 0-double rated motor speed |
| 5 | Output power | 0-double rated power |
| 6 | Output torque | 0-double rated motor current |
| 7 | Analog VI input | 0~10V |
| 8 | Analog CI input | 0~10V/0~20mA |
| 9~10 | Reserved | Reserved |

| Function Code | Name | Setting Range | Default Value |
|---------------|-------------------------------------|---------------|---------------|
| F2.23 | AO Lower limit | 0.0%~100.0% | 0.0% |
| F2.24 | Lower limit corresponding AO output | 0.00V~10.00V | 0.00V |
| F2.25 | AO Upper limit | 0.0%~100.0% | 100.0% |
| F2.26 | Upper limit corresponding AO output | 0.00V~10.00V | 10.00V |

Above function codes define the relationship between output value and analog output corresponding output value. When the output value exceeds the maximum output or the minimum output range, the beyond portion should be calculated with maximum output or minimum output.

When analog output is current output, 1mA is equivalent to 0.5V

For different applications, the analog output corresponding to 100% output value is different. For details, please refer to the instruction of each application.

Following figures explain several setting circumstances:




Figure 6-13 The coincidence relationship between assigned value and analog output

F3 Human Machine Interface Parameters

| Function Code | Name | Setting Range | Default Value |
|---------------|---------------|---------------|---------------|
| F3.00 | User password | 0~65535 | 0 |

User password is applied to prevent non-authorized person to look and modify parameter. Input a nonzero five digit number as password, then press DATA/ENT to confirm, if there is no button operation in one minute, password function becomes effective.

After password becomes effective, customer can not access parameter list if password input is incorrect. Please remember the password. If it is not necessary to set password, just set 00000 to clear password.

| Function Code | Name | Setting Range | Default Value |
|---------------|----------|---------------|---------------|
| F3.01 | Reserved | | |
| F3.02 | Reserved | | |

| Function Code | Name | Setting Range | Default Value |
|---------------|----------------------|---|---------------|
| F3.03 | STOP function option | 0: Keypad control valid | 0 |
| | | 1: Keypad and terminal control valid | |
| | | 2: Keypad and communication control valid | |
| | | 3: All control modes valid | |

This function code is to define the STOP stop function validity options.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------|---|---------------|
| F3.04 | Keypad display option | 0: external keyboard preferential ENB | 0 |
| | | 1: Local and external keyboard simultaneous display, only external key-press is valid. | |
| | | 2: Local panel and external keyboard simultaneous display, only Local key-press is valid. | |
| | | 3: Local and external keyboard simultaneous display, and all key-presses are valid (both are OR logical relation) | |

This function is to set up the logical relationship between Local and external keyboard key-press.

Note: No. 3 function should be used cautiously. Maloperation may cause serious consequences.

| Function Code | Name | Setting Range | Default Value |
|---------------|--|-------------------|---------------|
| F3.05 | operation status display parameter option | 0-32767 | 255 |
| F3.06 | Stop status display parameter option | 0-1023 | 255 |
| F3.07 | operation status display preferential option | 0-14 (0: invalid) | 0 |

operation status display

| Displayed Message | Code |
|---|-------|
| 0:Setting frequency | 1 |
| 1:Running frequency | 2 |
| 2:Output current | 4 |
| 3:Output voltage | 8 |
| 4:Running speed | 16 |
| 5:Output power | 32 |
| 6:Output torque | 64 |
| 7:DC bus voltage | 128 |
| 8:PID setpoint | 256 |
| 9:PID feedback | 512 |
| 10:Input terminal status | 1024 |
| 11:Output terminal status | 2048 |
| 12:VI value | 4096 |
| 13:CI value | 8192 |
| 14:Current segment of multi-speed control | 16384 |

Stop status display

| Displayed Message | Code |
|--|------|
| Setting frequency | 1 |
| DC bus voltage | 2 |
| Input terminal status | 4 |
| Output terminal status | 8 |
| PID setpoint | 16 |
| PID feedback | 32 |
| VI value | 64 |
| CI value | 128 |
| Current segment of multi-speed control | 256 |

Option: setting parameter=the sum total of display code, for example:

require to display at operation status: Output current, Running speed, Output power 4+16+32=52, then setting F3.05 to 52, its corresponding parameter can be viewed at operation through pressing button "DATA".

This I/O terminal status is displayed in decimal system, S1 (MO1) corresponding to the lowest digit. For instance, input status displays 3 is indicating that terminal S1 and S2 are closed and others are open. For details, please see F3.17 and F3.18 description.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------|---------------|---------------|
| F3.08 | IGBT module temperature | 0~100.0℃ | |
| F3.09 | Software version | | |
| F3.10 | Accumulative operating time | 0~65535h | 0 |

These functions only can be viewed but can not be modified.

IGBT module temperature: indicates the temperature of the inverter IGBT module.

Over-temperature protection value of different inverter may be different.

Software version: software version number.

Inverter accumulative operating time: displays current inverter accumulative operation time.

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------------------------------|---------------|---------------|
| F3.11 | The fault before previous fault type | | |
| F3.12 | Previous fault type | | |
| F3.13 | Current fault type | | |

Record three recent fault types: 0 is no fault; 1~22 is 22 different kinds of fault. For details, please see fault analysis.

| Function Code | Name | Setting Range | Default Value | | | | | | | | |
|---------------|---|---|---------------|------|------|------|----|-----|-------|-----|---|
| F3.14 | Operating frequency at current fault | The output frequency when current fault happens | 0.00Hz | | | | | | | | |
| F3.15 | Output amperage at current fault | The output amperage when current fault happens | 0.0A | | | | | | | | |
| F3.16 | Bus voltage at current fault | The bus voltage when current fault happens | 0.0V | | | | | | | | |
| F3.17 | Input terminal status at current fault | This value is decimal numbers, displaying all digital input terminal status at recent fault. The sequence is: <table border="1" style="margin-left: 20px;"> <tr> <td>BIT3</td> <td>BIT2</td> <td>BIT1</td> <td>BIT0</td> </tr> <tr> <td>S4</td> <td>S3</td> <td>S2</td> <td>S1</td> </tr> </table> If the input terminal of the time is ON, it is corresponding to 1, while OFF is 0. Through this value, the digital input signal conditions at the time can be acknowledged. | BIT3 | BIT2 | BIT1 | BIT0 | S4 | S3 | S2 | S1 | 0 |
| BIT3 | BIT2 | BIT1 | BIT0 | | | | | | | | |
| S4 | S3 | S2 | S1 | | | | | | | | |
| F3.18 | Output terminal status at current fault | This value is decimal numbers, displaying all digital input terminal <table border="1" style="margin-left: 20px;"> <tr> <td>BIT3</td> <td>BIT2</td> <td>BIT1</td> <td>BIT0</td> </tr> <tr> <td></td> <td>MO2</td> <td>RELAY</td> <td>MO1</td> </tr> </table> If the input terminal of the time is ON, it is corresponding to 1, while OFF is to 0. Through this value, the digital output signal conditions at the time can be acknowledged. | BIT3 | BIT2 | BIT1 | BIT0 | | MO2 | RELAY | MO1 | 0 |
| BIT3 | BIT2 | BIT1 | BIT0 | | | | | | | | |
| | MO2 | RELAY | MO1 | | | | | | | | |

F4 Application Function Parameters

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------|---------------|---------------|
| F4.00 | ACCEL Time 2 | 0.1~3600.0s | 10.0s |
| F4.01 | DECEL Time 2 | 0.1~3600.0s | 10.0s |

Acceleration/Deceleration time can be chosen to be F0.08, F0.09 or above three time settings. Their meanings are all the same; please refer to F0.08 and F0.09 related description.

The Acceleration/Deceleration time 0-1 at inverter operation can be chosen through different combination of multifunction digital input terminals.

| Function Code | Name | Setting Range | Default Value |
|---------------|--------------------|---------------|---------------|
| F4.02 | Jogging frequency | 0.00~F0.04 | 5.00Hz |
| F4.03 | Jogging ACCEL time | 0.1~3600.0s | 10.0s |
| F4.04 | Jogging DECEL time | 0.1~3600.0s | 10.0s |

It is to define the inverter set frequency and Acceleration/Deceleration time at Jogging operation. Jogging operation is performed by direct start mode and deceleration stop mode.

The Jogging Acceleration time is the time required for inverter to accelerate from 0Hz to the maximum output frequency (F0.04).

The Jogging Deceleration time is the time required for inverter to decelerate from the maximum output frequency (F0.04) to 0Hz.

| Function Code | Name | Setting Range | Default Value |
|---------------|----------------------|---------------|---------------|
| F4.05 | Skip frequency | 0.00~F0.04 | 0.00Hz |
| F4.06 | Skip frequency range | 0.00~F0.04 | 0.00Hz |

When the set frequency is within the skip frequency range, the actual operating frequency will be operated near the boundary of skip frequency range.

By means of setting skip frequency, the inverter can keep away from the mechanical resonance point of the load.

This inverter has one skip frequency point available. If these two skip frequencies are both set to 0, this function will be inactive.




Fig. 6-14 Skip frequency schematic diagram

| Function Code | Name | Setting Range | Default Value |
|---------------|------------------------------|---|---------------|
| F4.07 | Traverse frequency range | 0.0~100.0% (relative to set frequency) | 0.0% |
| F4.08 | Kick frequency range | 0.0~50.0%(relative to traverse frequency range) | 0.0% |
| F4.09 | Traverse frequency up time | 0.1~3600.0s | 5.0s |
| F4.10 | Traverse frequency down time | 0.1~3600.0s | 5.0s |

Traverse frequency function is suitable to industries such as textile, fiber and so on, and to applications which require traversing and winding functions.

Traverse frequency function means that the inverter output frequency is traversing up and down around the set frequency. The operating frequency locus with time axis is shown as following diagram, in which the amplitude of traverse is set by F4.07. When F4.07 is set to be 0, i.e. traverse range is 0, the traverse frequency function will be inactive.




Fig. 6-15 Traverse Frequency Operation Diagram

Traverse frequency range: traverse operation frequency limits by upper and lower limit frequency.
 Traverse range relative to the center frequency: amplitude of traverse $AW = CF \times AW$ range F4.07
 Kick frequency = amplitude of traverse $AW \times$ Kick Frequency Range F4.08. I.e. the kick frequency is the value relative to amplitude of traverse at traverse-frequency operation.

Traverse frequency rising time: the time required to rise from the lowest traverse frequency to the highest traverse frequency.
 Traverse frequency fall time: the time required to fall from the highest traverse frequency to the lowest traverse frequency.

| Function Code | Name | Setting Range | Default Value |
|---------------|--|---------------|---------------|
| F4.11 | Fault auto-reset times | 0~3 | 0 |
| F4.12 | Interval time setting of automatic resetting fault | 0.1~100.0s | 1.0s |

Fault auto-reset times: used to set the auto-reset times when inverter chooses fault auto-reset. If this value is exceeded, inverter will wait for trouble shooting.
 Interval time setting of fault auto-reset: chose the interval time between fault occurring and automatic resetting actuated

| Function Code | Name | Setting Range | Default Value |
|---------------|---------------------------|-----------------------|---------------|
| F4.13 | FDT level detection value | 0.00~ F0.04 | 50.00Hz |
| F4.14 | FDT delay detection value | 0.0~100.0%(FDT level) | 5.0% |

Set output frequency detection value and the delay value of output action dismissed, as shown by following figure:




Fig.6-16 FDT Level Diagram

| Function Code | Name | Setting Range | Default Value |
|---------------|------------------------------------|-------------------------------|---------------|
| F4.15 | Frequency reaching detection range | 0.0~100.0%(maximum frequency) | 0.0% |

When the inverter output frequency reaches the set frequency value, this function can regulate its detection range value, as shown by following figure:




Fig.6-17 Frequency Reaching Detection Range Diagram

| Function Code | Name | Setting Range | Default Value |
|---------------|-------------------------------|--|---------------|
| F4.16 | Brake Threshold Value Voltage | 115.0~140.0%(standard DC bus voltage) 380V | 130.0% |
| | | 115.0~140.0%(standard DC bus voltage) 220V | 120.0% |

This function is to set up the initiative bus voltage of dynamic braking, and properly regulating this value can result in an effective brake to the load.

| Function Code | Name | Setting Range | Default Value |
|---------------|---------------------|---|---------------|
| F4.17 | Speed display ratio | 0.1~999.9% Speed=120×running frequency×F4.17/pole number | 100.0% |

$$\text{Speed}=120 \times \text{running frequency} \times F4.17 / \text{pole number}$$

This function is used to calibrate speed display error, it has no impact on actual speed.

PID control is one method normally used to process control, holding the control value to the target value by the negative feedback system which regulates the inverter output frequency by means of proportion, integration and differential operations on the difference between the control value feedback signal and the target value signal. It is applicable to the process controls such as flow control, pressure control and temperature control and so on. The control functional block diagram is shown as follows:




Fig.6-18 Process PID Functional Block Diagram

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------|----------------------------------|---------------|
| F4.18 | PID setpoint Sources Option | 0: Given by Keyboard(F4.19) | 0 |
| | | 1: Given by Analog Channel VI | |
| | | 2: Given by Analog Channel CI | |
| | | 3: Given by Remote Communication | |
| | | 4: Multi-seg setpoint | |

When frequency source is chosen to be PID, i.e. F0.05 is chosen to be 3, these group functions are active. This parameter is to determine the assignment channel of the process PID target value. The set target value of process PID is a relative value, and the set 100% is corresponding to the 100% feedback signal of the system being controlled. The system always performs the calculation according to relative value (0-100%)
Note: If multistage input, it can be accomplished by means of setting F4 group parameters.

| Function Code | Name | Setting Range | Default Value |
|---------------|---------------------|---------------|---------------|
| F4.19 | Preset PID setpoint | 0.0%~100.0% | 0.0% |

When F4.08=0 is chosen, i.e. the target source is the keyboard, it is required to set this parameter. The reference value of this parameter is the system feedback value.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------|---------------------------|---------------|
| F4.20 | PID Feedback Sources Option | 0: VI Feedback | 0 |
| | | 1: CI Feedback | |
| | | 2: VI+CI Feedback | |
| | | 3: Communication feedback | |

The PID feedback channel is chosen by this parameter.

Important: The assignment channel and feedback channel can not be in coincidence, otherwise PID is unable to control effectively.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------------|---------------|---------------|
| F4.21 | PID Output Characteristics Option | 0: positive | 0 |
| | | 1: Pnegative | |

PID output is positive characteristic: when the feedback signal is bigger than the PID given signal, it is required for the inverter output frequency to decrease to counterbalance the PID, for instance, the winding tension PID control.

PID output is negative characteristic: when the feedback signal is bigger than the PID giver signal, it is required for the inverter output frequency to increase to counterbalance the PID, for instance, the unreeling tension PID control.

| Function Code | Name | Setting Range | Default Value |
|---------------|------------------------|---------------|---------------|
| F4.22 | Proportional gain (Kp) | 0.00~100.00 | 1.00 |
| F4.23 | Integral time (Ti) | 0.01~10.00s | 0.10s |
| F4.24 | Differential time (Td) | 0.00~10.00s | 0.00s |

the adjusting strength is. This parameter being 100 means that when the difference between the PID feedback value and the assigned value is 100%, the adjusting range of PID adjustor to the output frequency command is the maximum frequency (ignore integral action and derivative action).

Integrating time (Ti): determines the speed at which PID adjustor performs integral regulation to the discrepancy between the PID feedback value and the assigned value. The Ti is indicating the period of time that integral controller (ignore proportional action and derivative action), when the discrepancy between the PID feedback value and the assigned value is 100%, continuously regulates to make the regulating amount to reach the maximum frequency (F0.047). The shorter the integrating time, the stronger the adjusting strength is.

Differential time (Td): determines the controlling strength at which PID adjustor performs adjustment to the variance ratio of discrepancy between the PID feedback value and the assigned value. The Td is indicating the period of time within which if the feedback value is changed 100%, the regulating amount of integral controller is the maximum frequency (F0.04) (ignore proportional action and integral action). The longer the Td, the bigger the controlling strength is. PID is the most popularly used control mode in process control, with each part playing different role. Following simply introduces the operational principle and the controlling method:

Proportion control (P): when there is discrepancy between feedback and the assignment, output the regulating amount in proportion to the discrepancy. If the discrepancy is constant, the regulating amount keeps constant. Proportion control can response quickly to the feedback variation, but only using proportion control is unable to perform noncorresponding control. The bigger the proportional gain, the faster the system regulating speed, but being too big may cause oscillation. The control method is first to set a long integrating time and a zero differential time, and then run the system only by using proportion control. Change the assigned value, and watch the stable discrepancy (steady-state error) of feedback signal and assigned value. If the steady-state error is at the varying direction of assigned value (for instance, increase the assigned value, the feedback value after the system is steady is always less than the assigned value), continue to increase the proportional gain, otherwise decrease it. Repeat the above until the steady-state error is relatively small (it is very difficult to do no steady-state error).

Integral time (I): when there is a discrepancy between the feedback and assignment, continuously accumulate the output regulation amount. If the discrepancy still exists, continue to increase the regulation amount until there is no discrepancy. Integral controller can effectively eliminate the steady-state error.

Integral controller being too strong can cause repeated overshooting, system unstable and up till oscillating. The characteristic of oscillation caused by too strong integral action is that the feedback signal is swinging up and down around the assigned value, and the amplitude of swing increases gradually till the oscillation happens. Normally the integral time is adjusted from big to small, gradually regulate the integral time, and watch the effect, until the system stable speed meets requirements.

Differential time (D): when the discrepancy between feedback and assignment varies, output a regulation amount in proportion to the variance ratio of discrepancy. The regulation amount is related to the direction and magnitude of discrepancy variation, but irrelevant to the direction and value of the discrepancy itself. The differential control action is to perform the control according to the varying trend when the feedback signal variation happens, and thereby to restrain the feedback signal variation. It should be caution to use differential controller as the differential control have a trend to magnify the system interference, especially the high varying frequency interference.

| Function Code | Name | Setting Range | Default Value |
|---------------|-------------------------------|---------------|---------------|
| F4.25 | Sampling cycle time (T) | 0.01~100.00s | 0.10s |
| F4.26 | PID control discrepancy limit | 0.0~100.0% | 0.0% |

Sampling time (T): is the time to sample the feedback value. In each sampling period the controller runs one time. The longer the sampling time, the slower the responding.

PID control discrepancy limit: the allowable maximum discrepancy of PID system output value relative to the closed-loop assigned value. As shown in following diagram, within the discrepancy limit, PID controller stops adjustment. Properly setting this function code can improve the accuracy and stability of PID system.




Fig. 6-19 Coincidence relation of discrepancy limit and output frequency

| Function Code | Name | Setting Range | Default Value |
|---------------|--|---------------|---------------|
| F4.27 | Feedback disconnection detecting value | 0.0~100.0% | 0.0% |
| F4.28 | Feedback disconnection detecting time | 0.0~3600.0s | 1.0s |

Feedback disconnected detecting value: this detecting value is relative to the full range (100%). The system detects the PID feedback value all the time. When the feedback value is less or equal to the feedback disconnected detecting value, the system starts to time the detection. When the detecting time exceeds the feedback disconnected detecting time, the system will send an alert of feedback disconnecting failure(E02E).

| Function Code | Name | Setting Range | Default Value |
|---------------|---------------|---------------|---------------|
| F4.29 | Multi-Speed 0 | -100.0~100.0% | 0.0% |
| F4.30 | Multi-Speed 1 | -100.0~100.0% | 0.0% |
| F4.31 | Multi-Speed 2 | -100.0~100.0% | 0.0% |
| F4.32 | Multi-Speed 3 | -100.0~100.0% | 0.0% |
| F4.33 | Multi-Speed 4 | -100.0~100.0% | 0.0% |
| F4.34 | Multi-Speed 5 | -100.0~100.0% | 0.0% |
| F4.35 | Multi-Speed 6 | -100.0~100.0% | 0.0% |
| F4.36 | Multi-Speed 7 | -100.0~100.0% | 0.0% |

| S1 | S2 | S3 | Current segment of multi-speed control |
|-----|-----|-----|--|
| OFF | OFF | OFF | Multi-Speed 0 |
| ON | OFF | OFF | Multi-Speed 1 |
| OFF | ON | OFF | Multi-Speed 2 |
| ON | ON | OFF | Multi-Speed 3 |
| OFF | OFF | ON | Multi-Speed 4 |
| ON | OFF | ON | Multi-Speed 5 |
| OFF | ON | ON | Multi-Speed 6 |
| ON | ON | ON | Multi-Speed 7 |

Note: The multi-speed symbol defines the operation direction. If it is negative, the operation direction is reverse. Frequency setting 100.0% is corresponding to maximum frequency(F0.04).




Fig.6-20 multi-speed logic Diagram

F5 Protection Parameters

| Function Code | Name | Setting Range | Default Value |
|---------------|----------------------------------|-----------------------------|---------------|
| F5.00 | Motor Overload Protection Option | 0: No protection | 1 |
| | | 1: normal motor | |
| | | 2: Variable Frequency motor | |

0: no protection. There is no motor overloading protection characteristic (caution to use), and thereby the inverter has no protection to the overloaded motor.

1: normal motor (with low speed compensation). As general motor has a poor heat emission at low speed, the relevant electronic thermal protection should be regulated properly. The low speed compensation characteristic here mentioned is to switch down the overloading protection threshold for the motor with an operation frequency lower than 30 Hz.

2: Variable frequency motor (without low speed compensation). As the heat emission of special variable frequency motor is not affected by speed, it is not required to regulate the protection value for low speed operation.

| Code | Name | Setting Range | Value |
|-------|-----------------------------------|------------------------------------|--------|
| F5.01 | Motor Overload Protection Current | 20.0%~120.0% (motor rated current) | 100.0% |




Fig.6-21 Motor Overload Protection Current

The value can be determined by following equation:

$$\text{Motor overload protection current} = (\text{maximum current}/\text{rated current}) \times 100\%$$

It is mainly applied to the cases that big inverter drives small motor, requiring to correctly set up this function to protect the motor.

| Function Code | Name | Setting Range | Default Value |
|---------------|--|-----------------------------------|---------------|
| F5.02 | Power-down Frequency Drop Point | 70.0~110.0%(standard bus voltage) | 80.0% |
| F5.03 | Instant power-down Frequency drop rate | 0.00Hz~F0.04 | 0.00Hz |

If the instant power-down drop rate is set to be 0, the instant power-down restart function is invalid.

Instant power-down frequency drop point: it is indicating when the bus voltage, after the power network is down and drops to the instant power-down frequency drop point, the inverter starts to decrease the operation frequency based on the instant power-down frequency drop rate, enabling the motor to generate electricity which is fed back to keep the bus voltage, and thus ensuring the inverter is operating normally till inverter power is on again.

Important: Adjusting these two parameters properly can magnificently achieve the power network switching instead of causing inverter protection and thus causing production shutdown.

| Code | Name | Setting Range | Value |
|-------|---------------------------------------|----------------|-------|
| F5.04 | Over-voltage Stall Protection | 0: prohibit | 0 |
| | | 1: allow | |
| F5.05 | Over-voltage Stall Protection Voltage | 110~150%(380V) | 120% |
| | | 110~150%(220V) | 115% |

During the inverter deceleration, the load inertia may cause the actual motor speed drop rate lower than the output frequency drop rate, and thereby the motor generates electricity and feeds it back to the inverter, causing the inverter bus voltage going up and even bus over-voltage breakdown which then can cause inverter tripping if no provision is made.

Over-voltage stall protection function is to detect the bus voltage and compare it with the stall over-voltage point defined by F5.05 (relative to the standard bus voltage). If it exceeds the over-voltage stall point, inverter output frequency stop going down, and when the next bus voltage detected is lower than the over-voltage stall point, the inverter continues to decelerate, as shown by following figure:




Fig.6-22 Over-voltage Stall Function

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------------|----------------|---------------|
| F5.06 | Auto limit current level | 100~200% | 200% |
| F5.07 | Limit current frequency drop rate | 0.00~50.00Hz/s | 0.00Hz/s |

When inverter is running, the actual climbing rate of motor speed is lower than climbing rate of output frequency because load is too big. If you don't take any action, it will cause over current fault in acceleration then inverter will trip.

Over-current stall protection function is to detect output current and compare it with the current limit defined by F5.06. If it exceeds the current limit, output frequency drop down according to F5.07. When it show that output current is lower than limit current, inverter will remain normal operation.

| Function | Name | Setting Range | Default |
|----------|------|---------------|---------|
|----------|------|---------------|---------|





Fig. 6-23 Limit current protection

| Code | Name | Setting Range | Value |
|-------------------------------|--------------|-------------------------------|-------|
| F6.02 | Data pattern | 0:No check (N,8,1) forRTU | 0 |
| | | 1:Odd check (E,8,1) forRTU | |
| | | 2:Evencheck (O,8,1) forRTU | |
| | | 3:Nocheck (N,8,2) forRTU | |
| | | 4:Odd check (E,8,2) forRTU | |
| | | 5:Evencheck (O,8,2) forRTU | |
| | | 6:Nocheck (N,7,1) forASCII | |
| | | 7:Odd check (E,7,1) forASCII | |
| | | 8:Evencheck (O,7,1) forASCII | |
| | | 9:Nocheck (N,7,2) forASCII | |
| | | 10:Odd check (E,7,2) forASCII | |
| | | 11:Evencheck (O,7,2) forASCII | |
| | | 12:Nocheck (N,8,1) forASCII | |
| | | 13:Oddcheck (E,8, 1) forASCII | |
| | | 14:Evencheck (O,8,1) forASCII | |
| | | 15:Nocheck (N,8,2) forASCII | |
| | | 16:Odd check (E,8,2) forASCII | |
| 17:Evencheck (O,8,2) forASCII | | | |

The data pattern set by inverter must be the same as data pattern set by master machine. Otherwise, communication can not accomplish.

11-bits(for RTU)



F6 Communication Parameters

| Function Code | Name | Setting Range | Default Value |
|---------------|----------------------|----------------------------------|---------------|
| F6.00 | CommunicationAddress | 1~247,0 is the broadcast address | 1 |

When master machine plan to transmit a frame, slave communication address is set to be 0, it is also broadcast address. All slave machine in MODBUS will receive this frame but not response.


Note: slave address is not allowed to set 0.

Local communication address is unique for every slave machine within communication network. This is basis of utilization of point to point communication between master machine and inverter.


| Function Code | Name | Setting Range | Default Value |
|---------------|-------------------|---------------|---------------|
| F6.01 | Baud rate setting | 0: 1200BPS | 3 |
| | | 1: 2400BPS | |
| | | 2: 4800BPS | |
| | | 3: 9600BPS | |
| | | 4: 19200BPS | |
| | | 5: 38400BPS | |

This parameter is used to set transmission rate.

| Function Code | Name | Setting Range | Default Value |
|---------------|------|---------------|---------------|
|---------------|------|---------------|---------------|




DATA Frame: 8-0-1




10-bits(forASCII)


DATA Frame: 7-N-2



DATA Frame: 7-E-1



DATA Frame: 7-0-1



| Code | Name | Setting Range | Default Value |
|-------|------------------------------|---------------|---------------|
| F6.03 | Communication response delay | 0~200ms | 5ms |

Response delay: means the interval time from the end of data receive to transmitting response data to upper level machine. If response delay time is smaller than system operation time, response delay time should be system operation time. If response delay time is longer than system operation time, inverter can not transmit data to upper level machine until response delay time reached.

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------------|----------------------------|---------------|
| F6.04 | Communication overtime fault time | 0.0 (invalid) , 0.1~100.0s | 0.0s |

When this parameter is set to be 0.0s, this function is invalid.

When this function is valid, if the interval time between two communications exceeds communication overtime time, it will cause communication fault (E018).

| Function Code | Name | Setting Range | Default Value |
|---------------|-----------------------------|--|---------------|
| F6.05 | Communication error measure | 0: Alarm and free run stop | 1 |
| | | 1: No alarm and keep running | |
| | | 2: No alarm and stop according to stop mode(by communication) | |
| | | 3: No alarm and stop according to stop mode(by all control mode) | |

| Function Code | Name | Setting Range | Default Value |
|---------------|------------------|---------------------------|---------------|
| F6.06 | Response measure | 0: Response when write | 0 |
| | | 1: No response when write | |

When this parameter is set to be 0, Response when write.

When this parameter is set to be 1, No Response when write. This function can improve communication speed.

DZB300 has 25 pieces of alarm information and protection functions in total. Once the fault occurs, the protection function starts, the inverter stops inputting, the fault relay contact point is activated, and the fault code will be displayed on the display panel of the inverter. Before seeking services, the subscriber may conduct the self-check according to the prompt given in this section, analyze the fault causes, and find out the solutions. If the fault belongs to the causes described in the broken line box, please seek the service by contacting the inverter agent or directly contacting our corporation.

Common Faults and the Fault Diagnosis

The following faults may probably occur during the using of the inverter, please refer to the methods described below to perform the fault analysis.

1. No Electricity Display

- 1) Check with multimeter if the input power supply of the inverter is consistent with its rated voltage. If there is something wrong with the power supply, please check and remove it.
- 2) Check if the three-phase rectifying bridge is intact. If the rectifying bridge has been exploded, please seek technical service.
- 3) Check if the CHARGE indicator is on. If the indicator is off, the fault will be on the rectifying bridge or the buffering resistance. If the indicator is on, then the fault may probably lies in the switch on/off part, please seek for help.

2. The air Switch Trips off After Power-on


- 1) Check if the earthing or short circuit occurs between the input power supplies and remove the problem.
- 2) Check if the rectifying bridge has been broken down. If so, seek for the service.

3. The Motor Does not Run After the Inverter Starts to Run


- 1) Check if there is equalizing three-phase input between U, V and W. If yes, the motor circuit or itself may be damaged, or the motor stops turning for mechanical reason. Please remove it.
- 2) If there is input but the three phases are not equalizing, the inverter drive board or the output module may be damaged. Please seek for the service.
- 3) If there is no output voltage, the drive board or output module may be damaged. Please seek for the service.


4. When the Power-on Inverter Displays Normally, the Air Switch Trips off After the Operation.

- 1) Check if the short circuit occurs between the output modules. If yes, please seek the service.
- 2) Check if the short circuit or earthing occurs between the motor lead wires. If yes, please remove it.
- 3) If the tripping occurs only occasionally and the distance between the motor and the inverter is big, then the adding of an output AC reactor shall be considered.





2. Over voltage during acceleration(E002)







4. Over current during acceleration(E004)




6. Over current during running(E006)








8. InverterOver Load(E008)




9. Inverseunit protection(E009、E019、E029)



11. External Failure(E00D)




12. Diode Module Over Heat(E00E)






Seek technical support




Seek technical support

14. Input phase failure(E012)




Seek technical support


17. Motor self-learning failure(E016)



18. Communication Failure(E018)



15. Output phase failure(E013)



Seek technical support

8.1 Responsibility of manufacturer:

A: Interior

- ★ One month goods exchanging ,maintenance, and return after delivery
- ★ Three months goods exchanging ,maintenance after delivery
- ★ Twelve months goods maintenance after delivery

B:Abroad

- ★ Three months goods maintenance after delivery

8.2 Whenever and wherever use our product, users have the rights to take our service with payment.

All distributors, manufacturers and agents in the whole country can provide the service.
Our company has the right to entrust maintenance to others.

8.3 Responsibility immunity:

- ★ Abuse producing or inducing failure is out of our responsibility
- ★ The damage or referred,secondary damage caused by the fault of the equipment will not be compensated.

8.4 The equipment is guaranteed for twelve months from the date of exporting.

8.5 However the remedy of faults caused by the following reasons will be at user's cost, even though it happens during the guarantee period.

- ★ Improper operation, unauthorized repair or modification;
- ★ Operation beyond the standard specifications;
- ★ Falling down , barbarous transport;
- ★ Device ageing and failure caused by unsuitable environment;
- ★ Damage caused by earthquake, fire, windstorm, flood, lightning ,abnormal voltage and other natural disaster, or effect hereof.

1.1 Technical Specification

| Series | | DZB300 | DZB200 | |
|---------------------------------------|--|--|---|--|
| Item | | Specification | | |
| Input | Rated Voltage | 1AC220V ± 15%, 3AC220V ± 15%, 3AC380V ± 15%, 3AC660V ± 10%, 3AC1140V ± 15% | | |
| | Frequency Range | 47~63Hz | | |
| Output | Output Voltage | Proportional to Input Voltage | | |
| | Output Frequency | 0~600Hz | | |
| Control Characteristics | Control mode | Open loop vector control (SVC) V/F control | V/F control | |
| | V/F curve | 2 modes: Line, square v/f curve | | |
| | Command channel | operation panel, control terminal, serial port | | |
| | Frequency source | digital frequency reference, analog voltage reference, analog current reference, pulse reference, communication ports reference. These frequency sources can be selected through different methods. | | |
| | Overload Capacity | B:150% rated current 60 seconds; 180% rated current 10 seconds; | | |
| | | P:120% rated current 60 seconds; 150% rated current 10 seconds | | |
| | Start torque | 0.5Hz/150% (SVC) | 1.5Hz/150%(V/F) | |
| | Speed control range | 1:100(SVC) | 1:100(V/F) | |
| | Speed accuracy | ±0.5% (SVC) | ±0.5% | |
| | Carrier frequency | 1.0~15.0KHz | | |
| | frequency resolution | Digital setting: 0.01Hz Analog setting: Maximum frequency × 0.1% | | |
| | Torque boost | Auto Torque boost; | 0~10.0% | |
| | | Manual Torque boost 0~30.0% | | |
| | Accel/decel Mode | Two accel/decel curve, range:0.1-3600sec | | |
| | DC brake | Start DC break, Stop DC break | | |
| Jog control | Jog frequency range: 0.00Hz~ Maximum output frequency; Jog Acc/Dec time:0.0~3600.0s | | | |
| Multi-Speed Function | Internal PLC operation;8-speed Control | | | |
| Internal PID | Realize product-line automatic control system | | | |
| Automatic Voltage Adjustment Function | Keep static output voltage automatically when mains voltage fluctuating. | | | |
| Shared DC bus | Several motors can share one DC bus. | | | |
| Input/output characteristic | Input terminal | Six digital input terminals . Two analog input terminals, one can be inputted voltage and the other can be inputted voltage or current. | Eight digital input terminals and one of them can input high speed pulse. Two analog input terminals, one can be inputted voltage and the other can be inputted voltage or current. | |
| | Output terminal | One digital output terminal(Two for 7.5kw below) Two relay output terminal(One for 7.5kw below) One analog output terminal | | |

1.2 AC220V Series Rating:

Voltage classification AC 220V 0005 0007 0015 0022 0037 0005 0007 0015 0022 0037 0055 0075 0110 0150

| Series | DZB300 | DZB200 |
|--------|---------------|--------|
| Item | Specification | |

| | | |
|-------------|------------------------|---|
| Display | LCD Display | pre-set frequency;operate frequency;output current;motor speed;input voltage; output voltage;input/output terminals'status;fault information,etc |
| | LED Status indication | Operation/Stop,FWD/REV,Function indication,etc |
| | External meter display | Output frequency,Output current (0~10VDC) |
| Environment | Protectionfunction | input/output phase failure protection; Over current protection;Overvoltage protection;Under voltage protection; Over heat protection; overload protection,etc |
| | Applicable Situation | Indoor in which there is no direct sunlight, dust, erosive gas,combustible gas, oil smoke, water vapor, dripping, salt, etc. |
| | Altitude | Lower than 1,000 meters |
| | Ambient temperature | -10℃~+40℃ |
| | Humidity | 20%~90%RH, without condensation |

| | | | | | | | | | | | | | | | | |
|---------------|--------------------------|------------------------------------|------|-----|-----|-----|----------------------|------|-----|-----|-----|-----|-----|----|----|--|
| Output Rating | motor rating (KW) | 0.5 | 0.75 | 1.5 | 2.2 | 3.7 | 0.5 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | |
| | Inverter output(KVA) | 0.7 | 1.0 | 2.0 | 3.0 | 5.0 | 0.7 | 1.0 | 2.0 | 3.0 | 5.0 | 7.5 | 10 | 15 | 20 | |
| | Output current(A) | 2.5 | 4.0 | 7.0 | 10 | 17 | 2.5 | 4.0 | 7.0 | 10 | 17 | 25 | 34 | 50 | 68 | |
| | Output voltage(V) | Adjustable from 0 to input voltage | | | | | | | | | | | | | | |
| Input Rating | Input current(A) | 4.0 | 5.2 | 10 | 15 | 25 | 3.0 | 5.0 | 7.7 | 11 | 18 | 26 | 35 | 51 | 69 | |
| | Input voltage /frequency | Single 220V,50/60Hz | | | | | 3 phase 220V,50/60Hz | | | | | | | | | |
| | Operational range (V) | ±15% | | | | | | | | | | | | | | |
| | Operational range (Hz) | 47~63Hz | | | | | | | | | | | | | | |

AC380V Series Rating:

| | | | | | | | | | | | | | | | | |
|--------------------------------|-------------------------|------------------------------------|------|------|------|------|------|------|------|------|------|------|------|------|------|--|
| Voltage classification AC 380V | | 0007 | 0015 | 0022 | 0037 | 0055 | 0075 | 0110 | 0150 | 0185 | 0220 | 0300 | 0370 | 0450 | 0550 | |
| Output Rating | motor rating(KW) | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | |
| | Inverter output(KVA) | 1.0 | 2.0 | 3.0 | 5.0 | 7.5 | 10 | 15 | 20 | 25 | 30 | 40 | 50 | 60 | 75 | |
| | Output current(A) | 2.5 | 3.7 | 5.0 | 8.5 | 13 | 18 | 24 | 30 | 39 | 46 | 58 | 75 | 90 | 110 | |
| | Output voltage(V) | Adjustable from 0 to input voltage | | | | | | | | | | | | | | |
| Input Rating | Input current(A) | 3.2 | 4.8 | 6.5 | 11 | 16 | 23 | 31 | 39 | 50 | 58 | 75 | 97 | 110 | 140 | |
| | Input voltage/frequency | 3 phase 380V, 50/60Hz | | | | | | | | | | | | | | |
| | Operational range (V) | ±15% | | | | | | | | | | | | | | |
| | Operational range (Hz) | 47~63Hz | | | | | | | | | | | | | | |
| Voltage classification AC 380V | | 0750 | 0930 | 1100 | 1320 | 1600 | 1870 | 2000 | 2200 | 2500 | 2800 | 3150 | 4000 | 5000 | 6300 | |
| Output Rating | motor rating(KW) | 75 | 93 | 110 | 132 | 160 | 187 | 200 | 220 | 250 | 280 | 315 | 400 | 500 | 630 | |
| | Inverter output(KVA) | 100 | 125 | 150 | 175 | 220 | 250 | 270 | 300 | 330 | 370 | 420 | 575 | 710 | 890 | |
| | Output current(A) | 150 | 170 | 210 | 250 | 300 | 340 | 380 | 430 | 470 | 520 | 620 | 754 | 930 | 1180 | |
| | Output voltage(V) | Adjustable from 0 to input voltage | | | | | | | | | | | | | | |
| Input Rating | Input current(A) | 190 | 220 | 260 | 320 | 350 | 390 | 450 | 480 | 520 | 590 | 700 | 830 | 1023 | 1300 | |
| | Input voltage/frequency | 3 phase 380V, 50/60Hz | | | | | | | | | | | | | | |
| | Operational range (V) | ±15% | | | | | | | | | | | | | | |
| | Operational range (Hz) | 47~63Hz | | | | | | | | | | | | | | |

Appendix B Communication Protocol

communication protocol for master/slave communications. The user can use PC/PLC or control upper computer to implement centralized control (setting inverter control command, operating frequency, modification of related functional code parameters, working status of inverter, and fault message monitoring), to meet special application requirement.

1. Protocol Content

The Modbus serial communication protocol defines frame content and use format of asynchronous transmission in serial communications. Including: polling and broadcast frame of the master, and reply frame format of the slave. The frame content of the master includes: address (broadcast address) of the slave, execution command, data, error check, and so on. The response of the slave also adopts the same structure. Its content includes: action confirmation, return data, error check, and so on. If an error occurs when the slave is receiving a frame or the slave cannot complete the action required by the master, the slave will organize a fault frame and send it to the master as a response message.

2. Application Mode

The DZB300 series inverters access to the "single-master multi-slave" control network with RS232/RS485 bus.

3. Bus Structure

(1)Interface mode

RS232/RS485 hardware interface

(2)Transmission mode

Asynchronous serial and half-duplex transmission mode. At the same moment, only one of the master and slave sends data, while the other receives data. Data is sent frame by frame in form of packets during asynchronous serial communications.

(3)System topology: "single master multi-slave". The addresses of the slaves range from 1 through 247.

Where "0" is the broadcast communication address. The address of each slave over the network is a unique one. This is the basis for ensuring ModBus serial communications.

4. Protocol Description

The communication protocol for DZB300 inverters is a asynchronous serial master/slave ModBus communication protocol. Only one device (the master) can establish a protocol (called "query/command") over the entire network. Other devices (the slave) can only provide data to make response to the "query/command" of the master or take the corresponding actions according to the "query/command" of the master. The master here refers to a PC, industrial control device or programmable logic controller (PLC), and the slave refers to DZB300 inverters or other control devices running the same communication protocol. The master can conduct independent communications with a single slave or can advertise broadcast messages to all slaves. For the "query/command" of the master who makes independent access, the slave should return a message (called response); for the broadcast messages advertised by the master, the slave does not need to make a response to the master.

5. Communication Frame Structure

There are two kinds of communication data format: one is RTU (Remote Terminal Unit) mode, the other is ASCII (American Standard Code for Information International Interchange).

hexadecimal characters.

In the ASCII mode, format for each byte is as follows:

Coding system: hexadecimal notation,

| | | | | | | | | | | |
|------------|------|------|------|------|------|------|------|------|------|------|
| Character | '0' | '1' | '2' | '3' | '4' | '5' | '6' | '7' | '8' | '9' |
| ASCII CODE | 0x30 | 0x31 | 0x32 | 0x33 | 0x34 | 0x35 | 0x36 | 0x37 | 0x38 | 0x39 |
| Character | 'A' | 'B' | 'C' | 'D' | 'E' | 'F' | | | | |
| ASCII CODE | 0x41 | 0x42 | 0x43 | 0x44 | 0x45 | 0x46 | | | | |

Every byte includes start bits, seven or eight data bits, parity check bits and stop bits.

The description of byte fram is as follow:


11 bit byte frame:

| | | | | | | | | | | |
|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----------------------|----------|
| START | Bit 1 | Bit 2 | Bit 3 | Bit 4 | Bit 5 | Bit 6 | Bit 7 | Bit 8 | Odd parity check bit | Stop bit |
| | | | | | | | | | Even parity check bit | |
| | | | | | | | | | No parity check bit | |

10 bit byte frame:

| | | | | | | | | | |
|-------|-------|-------|-------|-------|-------|-------|-------|-----------------------|----------|
| START | Bit 1 | Bit 2 | Bit 3 | Bit 4 | Bit 5 | Bit 6 | Bit 7 | Odd parity check bit | Stop bit |
| | | | | | | | | Even parity check bit | |
| | | | | | | | | No parity check bit | |

In RTU mode, new frames always become silent at a transmission time of at least 3.5 bytes, as the start. Over a network using baud rate to calculate the transmission rate, the transmission time of 3.5 bytes can be controlled easily. The subsequently transmitted data fields are in turn: slave address, operation command code, data, CRC check word, the transmission bytes of each field are 0 through 9 and A through F in hexadecimal notation. The network device monitors the activities of the communication bus all the time, even during the silent interval. Once receiving the first field (address message), each network device will confirm the byte. After the completion of the transmission of the last byte, another transmission time interval similar to that of 3.5 bytes is used to indicate the end of the frame. After that, the transmission a new frame starts.



The information of a frame should be transmitted in consecutive data streams. If there is an interval over 1.5 bytes before the completion of the transmission of the entire frame, the receiving device will

ASCII frame standard structure

| | | | | | |
|-------|---------------|------------------------|------|----------------|-----|
| START | slave address | operation command code | data | CRC check word | END |
|-------|---------------|------------------------|------|----------------|-----|


clear the incomplete information, and mistake that the last byte is the address field part of the new frame. Likewise, if the interval between the start of a new frame and the previous frame is less than 3.5 bytes, the receiving device will regard it as the subsequent part of the previous frame. Due to frame disorder, the final CRC value is incorrect, which will lead to communication failure.

Standard Structure of RTU Frame:

| | |
|---|---|
| Frame header (START) | T1-T2-T3-T4 (transmission time of 3.5 bytes) |
| Slave address field (ADDR) | Communication address: 0~247 (decimal) ("0" stands for the broadcast address) |
| Function field (CMD) | 03H: Read slave parameters; 06H: Write slave parameters |
| Data field DATA (N-1) ⋮ DATA (0) | Data of 2*N bytes: this part is the main content of communications, and is also the data exchange core in communications. |
| CRC CHK lower bit | Detection value: CRC value (16BIT). |
| CRC CHK higher bit | |
| Frame tail END | T1-T2-T3-T4 (transmission time of 3.5 bytes) |

In ASCII mode, frame header is ":" ("0x3A"), frame tail is "CRLF" ("0x0D" "0x0A"). Except frame header and frame tail, all other bytes are transmitted by ASCII coding system. It will transmit high 4 bits first, then transmit low 4 bits. The data length is 8 bit. Capital ASCII is used to demonstrate 'A'~'F' and use

LRC check, cover the information from slave address to data.



| | |
|----------------------------|---|
| START | : (0x3A) |
| Address Hi | Communication address: 2 ASCII combine 8-bit address |
| Address Lo | |
| Function Hi | Function code: 2 ASCII combine 8-bit address |
| Function Lo | |
| DATA(0) ⋮ DATA (N-1) | Data content: nx8-bit 2n ASCII combine data content n<=16, maximum 32 ASCII |
| LRC CHK Hi | LRC check: 2 ASCII combine 8-bit check code |
| LRC CHK Lo | |
| END Hi | End: END Hi=CR(0x0D), END Lo=LF(0x0A) |
| END Lo | |

6. Command Codes and Communication Data

6.1 Command Code: 03H (0000 0011), read N words (can ready a maximum of consecutive five words)

For example: for an inverter with the slave address of 01H, the start address of memory is 0004, ready consecutive two words, the structure of the frame is as follows:

RTU mode:

RTU Command Message of the Master

| | |
|------------------------------|--|
| START | T1-T2-T3-T4 (transmission time of 3.5 bytes) |
| ADDR | 01H |
| CMD | 03H |
| Higher bits of start address | 00H |
| Lower bits of start address | 04H |
| Higher bits of data number | 00H |
| Lower bits of data number | 02H |
| CRC CHK lower bit | 85H |
| CRC CHK higher bit | CAH |
| END | T1-T2-T3-T4 (transmission time of 3.5 bytes) |

RTU Response Message of the Slave

| | |
|-------|--|
| START | T1-T2-T3-T4 (transmission time of 3.5 bytes) |
|-------|--|

ASCII Response Message of the Slave

| | |
|-------|---|
| START | : |
|-------|---|

| | |
|-----------------------------------|--|
| START | T1-T2-T3-T4 (transmission time of 3.5 bytes) |
| ADDR | 01H |
| CMD | 03H |
| Higher bits of byte number | 00H |
| Lower bits of byte number | 04H |
| Higher bits of data address 0004H | 00H |
| Lower bits of data address 0004H | 00H |
| Higher bits of data address 0005H | 00H |
| Lower bits of data address 0005H | 00H |
| CRC CHK lower bit | 43H |
| CRC CHK higher bit | 07H |
| END | T1-T2-T3-T4 (transmission time of 3.5 bytes) |

ASCII Command Message of the Master

| | |
|------------------------------|-----|
| START | ‘:’ |
| ADDR | ‘0’ |
| | ‘1’ |
| CMD | ‘0’ |
| | ‘3’ |
| Higher bits of start address | ‘0’ |
| | ‘0’ |
| Lower bits of start address | ‘0’ |
| | ‘4’ |
| Higher bits of data number | ‘0’ |
| | ‘0’ |
| Lower bits of data number | ‘0’ |
| | ‘2’ |
| LRC CHK Hi | ‘F’ |
| LRC CHK Lo | ‘6’ |
| END Lo | CR |
| END Hi | LF |

| | |
|--------------------|-----|
| CRC CHK lower bit | 05H |
| CRC CHK higher bit | 6DH |

| | |
|-----------------------------------|-----|
| START | : |
| ADDR | ‘0’ |
| | ‘1’ |
| CMD | ‘0’ |
| | ‘3’ |
| Higher bits of byte number | ‘0’ |
| | ‘0’ |
| Lower bits of byte number | ‘0’ |
| | ‘4’ |
| Higher bits of data address 0004H | ‘0’ |
| | ‘0’ |
| Lower bits of data address 0004H | ‘0’ |
| | ‘2’ |
| Higher bits of data address 0005H | ‘0’ |
| | ‘0’ |
| Higher bits of data address 0005H | ‘0’ |
| | ‘0’ |
| LRC CHK Hi | ‘F’ |
| LRC CHK Lo | ‘6’ |
| END Lo | CR |
| END Hi | LF |

6.2 Command code: 06H (0000 0110), read one word

For example, read 5000 (1388H) into the address 0008H of the inverter with the slave address of 02H, the structure of the frame is as follows:

RTU Command Message of the Master

| | |
|---------------------------------------|--|
| START | T1-T2-T3-T4 (transmission time of 3.5 bytes) |
| ADDR | 02H |
| CMD | 06H |
| Write higher bits of the data address | 00H |
| Write lower bits of the data address | 07H |
| Higher bits of data content | 13H |
| Lower bits of data content | 88H |

ASCII Response Message of the Slave

| | |
|--|--|
| | |
|--|--|

| | |
|-----|--|
| END | T1-T2-T3-T4 (transmission time of 3.5 bytes) |
|-----|--|

RTU Response Message of the Slave

| | |
|---------------------------------------|--|
| START | T1-T2-T3-T4 (transmission time of 3.5 bytes) |
| ADDR | 02H |
| CMD | 06H |
| Write higher bits of the data address | 00H |
| Write lower bits of the data address | 08H |
| Higher bits of data content | 13H |
| Lower bits of data content | 88H |
| CRC CHK lower bit | 05H |
| CRC CHK higher bit | 6DH |
| END | T1-T2-T3-T4 (transmission time of 3.5 bytes) |

ASCII Command Message of the Master

| | |
|---------------------------------------|-----|
| START | ‘:’ |
| ADDR | ‘0’ |
| | ‘2’ |
| CMD | ‘0’ |
| | ‘6’ |
| Write higher bits of the data address | ‘0’ |
| | ‘0’ |
| Write lower bits of the data address | ‘0’ |
| | ‘8’ |
| Higher bits of data content | ‘1’ |
| | ‘3’ |
| Lower bits of data content | ‘8’ |
| | ‘8’ |
| LRC CHK Hi | ‘5’ |
| LRC CHK Lo | ‘5’ |
| END Lo | CR |
| END Hi | LF |

| | |
|---------------------------------------|-----|
| START | ‘:’ |
| ADDR | ‘0’ |
| | ‘2’ |
| CMD | ‘0’ |
| | ‘6’ |
| Write higher bits of the data address | ‘0’ |
| | ‘0’ |
| Write lower bits of the data address | ‘0’ |
| | ‘8’ |
| Higher bits of data content | ‘1’ |
| | ‘3’ |
| Lower bits of data content | ‘8’ |
| | ‘8’ |
| LRC CHK Hi | ‘5’ |
| LRC CHK Lo | ‘5’ |
| END Lo | CR |
| END Hi | LF |

6.3 Communication frame error check

Frame error check includes two parts: byte bit check (odd/even parity check) and entire frame data check (CRC check).

6.3.1 Byte bit check: The user can select different bit check modes according to the actual needs. Alternatively, the user can select "no parity". This will affect the check bit setting of each byte.

Even check: Insert a even check bit before data transmission to demonstrate the number of "1" in data content is odd or even. If the number is even, check bit is set "0", otherwise the check bit is set "1", so the parity remain unchanged.

Odd check: Insert a odd check bit before data transmission to demonstrate the number of "1" in data content is odd or even. If the number is odd, check bit is set "0", otherwise the check bit is set "1", so the parity remain unchanged.

For example, If we want to transmit "11001110", the number of "1" is 5, check bit is "1" when use even check; check bit is "0" when use odd check. The receiver need to do the parity checking. If the parity of received data is not the same as the preset value, the communication has some errors.

6.3.2 Cyclical Redundancy Check (CRC):

The RTU frame format is used. The frame includes frame error detection field calculated on the basis of CRC. The CRC field detects the content of the entire frame. The CRC field has two bytes, including 16 bits

6.4 Definition of Communication Data Address

This part is the definition of the communication data address, used to control inverter operation, and obtain inverter status information and settings of related functional parameters of the inverter.

CRC: The CRC field detects the content of the entire frame. The CRC field has two bytes, including 16 bits of binary values. It is added to the frame after calculation of the transmission device. The receiving device recalculates

the CRC of the frame, and compares it with the value in the received CRC field. If the two CRC values are not the same, it indicates a transmission error. CRC is first stored in 0xFFFF, and then a process is called to process over six consecutive bytes in the frame and the value in the current register. Only the 8-bit data in each character is valid for CRC. The start bit, stop bit and parity check bit are invalid.

During CRC generation, each 8-bit character independently conducts (XOR) with the content of the register, the result moves to the least significant bit (LSB) direction, and the most significant bit (MSB) is filled in with 0. LSB is extracted for detection. If LSB is 1, the register independently conducts (XOR) with the preset value; if LSB is 0, the operation will not be conducted. The entire process will be repeated eight times. After the completion of the last bit (the eight bit), the next 8-bit byte will independently conduct (XOR) with the current value of the register. The final value in the register is the CRC value after the execution of all bytes in the frame.

The calculation method of CRC is the CRC principle in international standard. When editing CRC algorithm, the user can refer to the CRC algorithm in related standard, to write a CRC calculation program that really meets requirement.

A simple function for CRC calculation is provided for reference (programmed in C language):

```
unsigned int crc_cal_value(unsigned char *data_value, unsigned char data_length)
{
    int i;
    unsigned int crc_value=0xffff;
    while(data_length-->0)
    {
        crc_value^=*data_value++;
        for(i=0;i<8;i++)
        {
            if(crc_value&0x0001)crc_value=(crc_value>>1)^0xa001;
            else crc_value=crc_value>>1;
        }
    }
    return(crc_value);
}
```

In ladder logic, CKSM calculates the CRC value according to the frame content in tale loop-up method. This method features simple program, fast operation speed, but wider ROM space of program. Please use this method prudently in occasions with certain program space requirement.

6.3.3 ASCII Mode Check(LRC Check)

LRC Check Code is grouped of the value from Address to Data Content, lookup 6.2 check code of communication message above:

0x02+0x06+0x00+0x08+0x13+0x88=0xAB, 然后取2的补码=0x55.

| Function Description | Address Definition | Data Meaning | R/W Feature |
|----------------------|--------------------|---|-------------|
| | | Communication setting range (10000, 10000) | |

about inverter status information and setting of related functional parameters of the inverter.

6.4.1 Functional code parameter expression rule

To use a functional code serial number as a parameter to correspond to the register address, conversion in hexadecimal notation is needed. For example, the serial number of P5.05 is 82, the address of the functional address in hexadecimal notation is 0052H.

Ranges of higher/lower bytes are respectively: higher-bit bytes: 00~11; lower-bit bytes: 00~FF.

Note: F8 group: default settings, do not read or change the parameters in the group. Some parameters should not be changed during operation of the inverter. Some parameters should not be changed no matter in which state the inverter is. To change functional code parameters, pay attention to the setting range, unit and related description of the parameters.

In addition, frequency storage of EEPROM may reduce the service life of the EEPROM. For users, some functional codes do not need storage in communication mode. Change the value in RAM to meet the user requirement. To implement this function, change the most significant bit of the corresponding functional code address from 0 to 1. For example, functional code P0.12 is not stored in EEPROM. Modify the value in RAM only, and set the address to 800CH. This address can only be used in writing RAM, cannot be used for reading. It will be an invalid address if it is used for reading.

6.4.2 Address of other functions:

| Function Description | Address Definition | Data Meaning | R/W Feature |
|-------------------------------|--------------------|-----------------------------------|-------------|
| Communication control command | 1000H | 0001H: Forward running | W/R |
| | | 0002H: Reverse running | |
| | | 0003H: Forward jogging | |
| | | 0004H: Forward jogging | |
| | | 0005H: Stop | |
| | | 0006H: Free stop (emergency stop) | |
| | | 0007H: Fault reset | |
| | | 0008H: Jogging stop | |
| Inverter state | 1001H | 0001H: Forward running | R |
| | | 0002H: Reverse running | |
| | | 0003H: Inverter standby | |
| | | 0004H: Fault | |

| Function Description | Address Definition | Data Meaning | R/W Feature |
|----------------------|--------------------|------------------|-------------|
| | | 0000H: Not fault | |

| | | | |
|-------------------------------|----------|--|-----|
| Communication setting address | 2000H | Communication setting range (-10000~10000) Note: the communication setting is the percentage of the relative value (-100.00%~100.00%), which can conduct communication wiring operation. If it is set as frequency source, it corresponds to the percentage of the maximum frequency (P0.04); If it is set or fed back as PID, it corresponds to the percentage of PID. Where, PID setting value and PID feedback value go through PID calculation in form of percentage. | W/R |
| Run/stop parameter address | 3000H | Setting frequency | R |
| | 3001H | Running frequency | R |
| | 3002H | Output current | R |
| | 3003H | Output voltage | R |
| | 3004H | Running speed | R |
| | 3005H | Output power | R |
| | 3006H | Output torque | R |
| | 3007H | DC bus voltage | R |
| | 3008H | PID setpoint | R |
| | 3009H | PID feedback | R |
| | 300AH | Input terminal status | R |
| | 300BH | Output terminal status | R |
| | 300CH | V1 value | R |
| | 300DH | Cl value | R |
| | 300EH | Current segment of multi-speed control | R |
| 300FH | Reserved | R | |
| 3010H | Reserved | R | |
| 3011H | Reserved | R | |
| 3012H | Reserved | R | |
| Inverter fault address | 5000H | Fault message codes should be consistent with fault types in the functional code menu. The difference is that here hexadecimal data is returned to the upper computer, instead of fault characters. | R |

| | | | |
|------------------------------------|-------|---|---|
| ModBus communication fault address | 5001H | 0000H: No fault | R |
| | | 0001H: Password error | |
| | | 0002H: Command code error | |
| | | 0003H: CRC error | |
| | | 0004H: Illegal address | |
| | | 0005H: Illegal data | |
| | | 0006H: Parameter change invalid | |
| | | 0007H: System locked | |
| | | 0008H: Inverter busy (EEPROM is storing) | |

6.5 Exception response:

The AC motor drive is expected to return a normal response after receiving command messages from the master device.

In the exception response, the most significant bit of the original command code is set to "06", the data address is 0x5001, and an exception code which explains the condition that caused the exception is returned.

For example:

RTU Fault Response Message of the Slave

| | |
|-----------------------------------|--|
| START | T1-T2-T3-T4 (transmission time of 3.5 bytes) |
| ADDR | 01H |
| CMD | 06H |
| higher bits of the fault response | 50H |
| lower bits of the fault response | 01H |
| higher bits of the fault code | 00H |
| lower bits of the fault code | 05H |
| CRC CHK lower bits | 09H |
| CRC CHK higher bits | 09H |
| END | T1-T2-T3-T4 (transmission time of 3.5 bytes) |


| | |
|-------|---|
| START | ' |
|-------|---|

| | |
|-----------------------------------|-----|
| ADDR | '0' |
| | '1' |
| CMD | '0' |
| | '6' |
| higher bits of the fault response | '5' |
| | '0' |
| lower bits of the fault response | '0' |
| | '1' |
| higher bits of the fault code | '0' |
| | '0' |
| lower bits of the fault code | '0' |
| | '5' |
| LRC CHK Hi | 'A' |
| LRC CHK Lo | '3' |
| END Lo | CR |
| END Hi | LF |


Fault code meaning :

| Fault code | Data Meaning |
|------------|-----------------------------------|
| 1 | Password error |
| 2 | Command code error |
| 3 | CRC error |
| 4 | Illegal address |
| 5 | Illegal data |
| 6 | Parameter change invalid |
| 7 | System locked |
| 8 | Inverter busy (EEPROM is storing) |


Type 1: Plastic Frame



Type 3: Steel Frame (Standing)



Type 2: Steel Frame (Hanging)



Dimension form:

| Model | AC Drives Model | Applicable Motor (KW) | Dimensions (mm) | Type |
|-------|-----------------|-----------------------|-----------------|------|
|-------|-----------------|-----------------------|-----------------|------|

Appendix D: Accessories List

1. All Braking Resistors & Braking Units Use in AC Drives

| Model | Motor(KW) | A | B | H | W | D | d | | | |
|-------|----------------|------|-----|-----|------|------------|-----|-----|-----------------------|------------------------|
| | | | | | | | | | | |
| FL28 | DZB300B0007L2A | 0.75 | 125 | 159 | 170 | 113 | 142 | 5 | Plastic Frame | |
| | DZB300B0015L2A | 1.5 | | | | | | | | |
| | DZB300B0007L4A | 0.75 | | | | | | | | |
| | DZB300B0015L4A | 1.5 | | | | | | | | |
| FL37 | DZB300B0022L2A | 2.2 | 154 | 238 | 250 | 142 | 155 | 5 | | |
| | DZB300B0037L2A | 3.7 | | | | | | | | |
| | DZB300B0022L4A | 2.2 | | | | | | | | |
| | DZB300B0037L4A | 3.7 | | | | | | | | |
| | DZB300B0055L4A | 5.5 | | | | | | | | |
| | DZB300B0075L4A | 7.5 | | | | | | | | |
| FL75 | DZB300B0110L4A | 11 | 205 | 300 | 322 | 190 | 193 | 6.5 | | |
| | DZB300B0150L4A | 15 | | | | | | | | |
| FL030 | DZB300B0185L4B | 18.5 | 285 | 457 | 475 | 195 | 240 | 9 | Steel Frame (Hanging) | |
| | DZB300B0220L4B | 22 | | | | | | | | |
| | DZB300B0300L4B | 30 | | | | | | | | |
| FL045 | DZB300B0370L4B | 37 | 315 | 620 | 645 | 230 | 310 | 11 | | |
| | DZB300B0450L4B | 45 | | | | | | | | |
| FL075 | DZB300B0550L4B | 55 | 375 | 725 | 750 | 290 | 335 | 13 | | |
| | DZB300B0750L4B | 75 | | | | | | | | |
| | DZB300B0930L4B | 93 | | | | | | | | |
| FL132 | DZB300B1100L4B | 110 | 480 | 860 | 880 | 370 | 335 | 13 | | |
| | DZB300B1320L4B | 132 | | | | | | | | |
| FL187 | DZB300B1600L4B | 160 | 610 | 850 | 880 | 250 250 | 345 | 13 | | |
| | DZB300B1870L4B | 187 | | | | | | | | |
| | DZB300B2000L4B | 200 | | | | | | | | |
| FL200 | DZB300B1600L4B | 160 | 680 | | 1280 | | 440 | | | Steel Frame (Standing) |
| | DZB300B1870L4B | 187 | | | | | | | | |
| | DZB300B2000L4B | 200 | | | | | | | | |
| FL280 | DZB300B2200L4B | 220 | 800 | | 1600 | | 550 | | | |
| | DZB300B2800L4B | 280 | | | | | | | | |
| | DZB300B3150L4B | 315 | | | | | | | | |
| | DZB300B4000L4B | 400 | | | | | | | | |

| Voltage | K W (HP) | Braking Unit | | Braking Resistors Model No. of Units Used | | | Braking Torque 10%ED |
|-------------|-----------|--------------|-------------|---|-----------------|--------|----------------------|
| | | Model 70BR | Number | Resistors Values Recommended | Resistors Model | Number | |
| 220V Series | 0.5(0.7) | | | 80W 200Ω | 80W 120Ω | 1 | 100% |
| | 0.75(1.0) | | | 80W 200Ω | 80W 120Ω | 1 | |
| | 1.5(2.0) | | | 150W 100Ω | 150W 100Ω | 1 | |
| | 2.2(3.0) | | | 200W 80Ω | 200W 68Ω | 1 | |
| | 3.7(5.0) | | | 300W 50Ω | 300W 50Ω | 1 | |
| 400V Series | 0.75(1.0) | | | 80W 400Ω | 80W 400Ω | 1 | 100% |
| | 1.5(2.0) | | | 120W 330Ω | 180W 300Ω | 1 | |
| | 2.2(3.0) | | | 160W 250Ω | 250W 250Ω | 1 | |
| | 3.7(5.0) | | | 300W 150Ω | 400W 150Ω | 1 | |
| | 5.5(7.5) | | | 400W 100Ω | 600W 100Ω | 1 | |
| | 7.5(10) | | | 550W 75Ω | 800W 75Ω | 1 | |
| | 11(15) | | | 1000W 50Ω | 1000W 50Ω | 1 | |
| | 15(20) | | | 1500W 40Ω | 1500W 40Ω | 1 | |
| | 18.5(25) | 4030 | 1 | 2500W 35Ω | 2500W 35Ω | 1 | |
| | 22(30) | 4030 | 1 | 3000W 27.2Ω | 1200W 6.8Ω | 4 | |
| | 30(40) | 4045 | 1 | 5000W 17.5Ω | 2500W 35Ω | 2 | |
| | 37(50) | 4045 | 1 | 9600W 16Ω | 1200W 8Ω | 8 | |
| | 45(60) | 4045 | 1 | 9600W 13.6Ω | 1200W 6.8Ω | 8 | |
| | | | | | | | |
| | | | | | | | |
| | 55(75) | 4030 | 2 | 8800W 20Ω | 1500W 5Ω | 4 | |
| | 75(100) | 4045 | 2 | 9600W 15Ω | 1200W 7.5Ω | 8 | |
| | 93(125) | 4045 | 2 | 9600W 13.6Ω | 1200W 6.8Ω | 8 | |
| | 110(150) | 4045 | 3 | 9600W 16Ω | 1200W 8Ω | 8 | |
| | 132(175) | 4045 | 3 | 9600W 13.6Ω | 1200W 6.8Ω | 8 | |
| 160(220) | 4045 | 4 | 9600W 13.6Ω | 1200W 6.8Ω | 8 | | |
| 220(300) | 4045 | 5 | 9600W 13.6Ω | 1200W 6.8Ω | 8 | | |
| 250(330) | 4045 | 6 | 9600W 13.6Ω | 1200W 6.8Ω | 8 | | |

Note:

- Please only use the resistors and recommended values.
For instance, in 400 V series, 100 HP, AC drive has 2 braking units with each of 8 braking resistors, so two braking units use 16 braking resistors. (Refer to the "Braking Unit Module User Manual" for further detail.)
- Take into consideration the safety of the environment when installing the braking resistors.
- If the minimum resistance value is to be utilized, consult local dealers for the calculation of the Watt figures.

2. Standard Extension Cable:

FL — WX 0100


| Model | Length |
|-------|--------|
|-------|--------|

| | |
|------|------|
| 0100 | 1.0M |
| 0150 | 1.5M |
| 0200 | 2.0M |
| 0250 | 2.5M |
| 0300 | 3.0M |


network cable

company name


3.The Apparatus Size of the Digital Hand-Held Programming Panel



Digital Hand-Held Programming Panel 1



Digital Hand-Held Programming Panel 2



Digital Hand-Held Programming Panel 3