

PREFACE

Thank you very much for choosing VS500 series of general purpose inverter.

This manual provides guidance of using the inverter safely and carefully, containing introduction of installation, wiring, parameters list, routine maintenance, operating rules and cautions, etc.

In order to make good use of the inverter properly and safely, please read this manual thoroughly before using. It may lead to abnormal operation and failure, reduce using life, even damage the equipment and cause personal injury if you use it wrongly.

This manual is attachment together with the inverter. Please keep it well and it would be available to engineering and installation personnel, repairing and maintaining during the product functioning period. SUNFAR has the right to modify and ameliorate products, data and dimensions without notice, so this manual is updated and all the contents in this manual are subject to change without any notice.

VS500 Series of General Purpose Inverter Operation manual

Version: V1.0

Revision Date: JUNE. 2015

Table of Contents

1 INTRODUCTION	3
1.1 Model explanation	3
1.2 Appearance description	3
1.3 Model of inverter.....	5
1.4 Specifications.....	6
2 INSTALLATION GUIDELINES.....	8
2.1 Environmental requirements	8
2.2 Disassembly and assembly of the panel.....	8
2.3 Disassembly and assembly of the cover board.....	9
2.4 Dimension of inverter.....	10
3 WIRING PROCEDURE.....	13
3.1 Precautions	13
3.2 Wiring of external components	13
3.3 Basic wiring	15
3.4 Terminal of main circuit	16
3.5 Terminal of Control circuit	18
4 OPERATIONS OF INVERTER AND SIMPLE RUNNING.....	19
4.1 Operation panel.....	19
4.2 Basic function of panel and methods of operation.....	20
4.3 List of state monitor parameter	23
4.4 Simple operation.....	24
5 PARAMETERS LIST	25
6 DESCRIPTION OF SPECIFIC FUNCTIONS	37
6.1 Basic operation parameter unit	37
6.2 Primary application of parameter unit.....	42
6.3 Analog I/O parameter unit	46
6.4 Digital O/I parameter unit	49
6.5 Auxiliary running parameter unit	53
6.6 Multi-speed running parameter unit	58
6.7 Advanced running parameter unit	61
6.8 Wobble freq. running parameter unit	63
6.9 PID control parameter unit	65
6.10 Communication function parameter units	67
6.11 Special function parameter unit	69
7 SPECIAL FUNCTIONS FOR DRAWING MACHINE.....	71
7.1 Overview.....	71
7.2 Selection of dedicated functions of drawing machine	71
7.3 Parameter table of drawing machine dedicated function ([F0.0]=0001).....	72

8 Troubleshooting and Measures	81
8.1 Protective functions and Countermeasures	81
8.2 Fault record inquiry.....	82
8.3 Reset.....	83
9 MAINTENANCE AND CARE	84
9.1 Daily Maintenance.....	84
9.2 Damageable parts maintenance.....	85
9.3 Storage.....	85
9.4 After sale services.....	85
10 USAGE EXAMPLE.....	86
10.1 Panel on-off control, Panel potentiometer setting frequency.....	86
10.2 External on-off control mode, external voltage setting frequency.....	86
10.3 Multi-speed running, external on-off control mode.....	87
10.4 Panel on-off control, Panel potentiometer setting frequency and linkage control with inverters....	87
10.5 Energy-saving reconstruction of escalator (for reference only).....	89
10.6 PLC control of start/Stop and 3-stage speed running of inverter.....	89
Appendix I RS485 COMMUNICATION PROTOCOL.....	92
Appendix II MODBUS protocol.....	100
Appendix III OPTIONS	104

✧ PRECAUTIONS

In order to use the inverter properly and safely, please read this manual carefully before using. And you should follow the requirements of this manual to move, install, run, operate and repair the inverter.

1. Opening

- Please check any damage that may have occurred during transportation.
- Please check whether the nameplate data of inverter is in accordance with your order, if anything wrong, please contact supplier immediately.

Our product is manufactured, packed and transported in the strict quality system. But in case there is any error, please contact with our company or local agent, we will solve the problem as quickly as possible.

- Inverter's nameplate data




Fig-1 Nameplate

2. Safety regulations

There are four kinds of symbols being related with cautions as follows:



Danger: If user does not operate according to requirements, it will lead to death, grievous bodily harm or severe property loss.



Warning: If user does not operate according to requirements, it will lead to injury or damage of inverter.



This symbol will hint some useful information.



This symbol will hint some items that need to be noticed in operation.

2.1 Installing

- 2.1.1. Do not put the inverter on the combustible material.
- 2.1.2. E380 series inverter can't install in the explosive ambient.
- 2.1.3. Do not drop other material into the inverter.



It is forbidden to disassemble and refit the inverter.

2.2 Wiring

- 2.2.1. It must be operated by professional worker when wiring.
- 2.2.2. Please be sure to turn off the power supply at least 10 min before wiring.
- 2.2.3. Inverter and motor must be grounded correctly.
- 2.2.4. Be sure to wire or inspect the inverter after power-off at least 10 minutes.
- 2.2.5. Electron components are sensitive about static electricity, so do not drop other material in inverter or touch the main circuit.



It is forbidden to connect an AC power supply with the U, V and W output terminals directly

2.3 Maintenance



- 1. Do not touch the radiator after power-off at least 10 minutes.
- 2. The earth terminal of inverter must be connected to ground reliably.

3. Attention Notes:

- 3.1. Be sure to install the inverter in a well-ventilated ambient.
- 3.2. The temperature at variable-frequency will be higher than at line-frequency, which is normal phenomenon.
- 3.3. The ordinary motor cannot run in the low speed for a long time, so user should select the special motor for inverter or reduce the motor load under the low speed.
- 3.4. When the altitude is over 1000m, the inverter will be valid to decrease the rated current, and the rated current will decrease 10% when the attitude is increased 1500m.



Be sure not to connect the output terminals of inverter with the filter capacitors and other surge absorbers.

4 Dispose

When you dispose inverter and its parts, please pay attention to:


Capacitor: The capacitors in inverter may explode when they are burned.

Plastic: Poisonous gas may be generated when the front panel is burned, please pay attention to the waste gas when the plastic parts are burned.

Method: Please dispose inverter as industry rubbish


1. INTRODUCTION

1.1 Model explanation




1.2 Appearance description

1.2.1 Appearance of model I



It is fit for: VS500-4T0015~VS500-4T0075, VS500-2T0015~VS500-2T0037


1.2.2 Appearance of model II




It is fit for: VS500-4T0110~VS500-4T0750
VS500-2T0055~VS500-2T0370

It is fit for: VS500-4T0900~VS500-4T1320
VS500-2T0450~VS500-2T0750

1.2.3 Appearance of model III



It is fit for: VS500-4T1600~VS500-4T2200 VS500-2T0900~VS500-2T1100



It is fit for: VS500-4T2500~VS500-4T3150 VS500-2T1320

1.3 Model of Inverter

Model	General lode (G-load) ([F0.15]=0)			Pump and fan lode (P-load) ([F0.15]=1)		
	Rated Power (KVA)	Rated output current (A)	Applied Motor Power (KW)	Rated Power (KVA)	Rated output current (A)	Applied Motor Power (KW)
VS500-2T0015	2.9	7.5	1.5	--	--	--
VS500-2T0022	3.8	10	2.2	--	--	--
VS500-2T0037	5.7	15	3.7	--	--	--
VS500-2T0055	9.5	25	5.5	--	--	--
VS500-2T0075	12.6	33	7.5	--	--	--
VS500-2T0110	17.5	46	11	--	--	--
VS500-2T0150	22.9	60	15	--	--	--
VS500-2T0185	28.6	75	18.5	--	--	--
VS500-2T0220	32.4	85	22	--	--	--
VS500-2T0300	41.9	110	30	--	--	--
VS500-2T0370	51.5	135	37	--	--	--
VS500-2T0450	64.8	170	45	--	--	--
VS500-2T0550	78.1	205	55	--	--	--
VS500-2T0750	101	265	75	--	--	--
VS500-2T0900	122	320	90	--	--	--
VS500-2T1100	145	380	110	--	--	--
VS500-2T1320	172	450	132	--	--	--
VS500-4T0015	2.4	3.7	1.5	3.6	5.5	2.2
VS500-4T0022	3.6	5.5	2.2	5.6	8.5	3.7
VS500-4T0037	5.6	8.5	3.7	8.6	13	5.5
VS500-4T0055	8.6	13	5.5	11	17	7.5
VS500-4T0075	11	17	7.5	16.5	25	11
VS500-4T0110	16.5	25	11	21.7	33	15
VS500-4T0150	21.7	33	15	25.7	39	18.5
VS500-4T0185	25.7	39	18.5	29.6	45	22
VS500-4T0220	29.6	45	22	39.5	60	30
VS500-4T0300	39.5	60	30	49.4	75	37
VS500-4T0370	49.4	75	37	60	91	45
VS500-4T0450	60	91	45	73.7	112	55
VS500-4T0550	73.7	112	55	98.7	150	75
VS500-4T0750	98.7	150	75	116	176	90
VS500-4T0900	116	176	90	138	210	110
VS500-4T1100	138	210	110	171	260	132
VS500-4T1320	171	260	132	204	310	160
VS500-4T1600	204	310	160	237	360	185
VS500-4T1850	237	360	185	253	385	200
VS500-4T2000	253	385	200	276	420	220
VS500-4T2200	276	420	220	313	475	250
VS500-4T2500	313	475	250	352	535	280
VS500-4T2800	352	535	280	395	600	315
VS500-4T3150	395	600	315	424	645	350

1.4 Specifications

Input	Rated voltage and freq.		Three-voltage (4T****) 380V 50/60Hz	Three-voltage (2T****) 220V 50/60Hz	Single-voltage (2S****) 220V 50/60Hz
	Permissible voltage fluctuation		Three-voltage (4T****) 300V~460V	Three-voltage (4T****) 170V~270V	Three-voltage (4T****) 170V~270V
Output	Voltage		Three-voltage: 0~380 V		Single-voltage: 0~220 V
	Frequency		0 Hz ~400Hz		
	Over-loading Endurance		110% rated current for long-term; 150% rated current for 1min; 180% rated current for 2s		
Control System			VVVF control		
Control Characteristics	Freq. Control Resolution	Analog Input	0.1% of maximum output freq		
		Digital Input	0.01Hz		
		External pulse	0.1% of maximum freq.		
	Freq. Precision	Analog Input	Within 0.2% of maximum output freq.		
		Digital Input	Within 0.01% of setting freq.		
		External pulse	0.1% of maximum freq.		
	V/F Curve (Voltage-Frequency characteristics)		Reference freq. can be discretionary set between 5 and 400Hz. And V/F curve with multimode can be discretionary set. There are also three curves provided, constant torque curve, Dec torque curve 1 and Dec torque curve 2.		
Control Characteristics	Torque boost		Manual torque boost can be set between 0 and 20 percent; Automatic torque boost can be set according to output current.		
	Automatic current/voltage Limiting		It will determine automatically the current and voltage of stator of motor, which will be controlled within the allowable range.		
	Under voltage inhibit feature In running		It is especial for the users with lower-power supply and voltage fluctuate frequently, even the voltage is lower than Permissible voltage, and the system will maintain the longest running time.		
Typical Functions	Multi-speed selection And Wobble freq. running		Up to 8 stages of programmable multi-speed control, 6 kinds of running mode and 15 stages of multi-speed. Wobble freq. function is composed of preset freq., center freq. adjusted and save state and restart when inverter just had power off		
	Embedded PID control		Optional inner bipolar PID controller, 5-pump voltage regulation control system (supply water or gas), with sleep/ wake up, a typical energy-saving function.		
	RS485 communication and synchronization control		Through RS485 communication, master inverter is the role of synchronous controller linkage controlling proportion presupposition and trimming, slave inverter running frequency superposition and trimming internal. In system of multi-gearing series use, have load self-equalized function, all gearing load proportion according to pre-set to keep consistent strictly.		
	Dedicated functions of drawing machine		Possessing coil diameter calculation, fast high-precision PID control with feed forward compensation, disconnection protection and stop at fixed length, etc., being able to realize stable winding operation under various states.		
	Droop control		Realizing power equalization of multiple inverters with the same drive chain, and being able to realize control characteristics of the torque motor through appropriately setting parameters.		
	Freq Setting	Analog input	DC voltage 0 ~ 5V、0 ~ 10V , DC current 0 ~ 20mA		
		Pulse input	Its amplitude value is between 5 and 30V、 and its freq. is within 50KHz		
		Digital input	It can set by operation panel , RS485 , UP/DW terminal , also can set multiple combinations with analogue input		
	Output Signal	OC output	Two OC output, As many as 16 species of choice, fault relay output similarly optional.		
Analog output		Two 0~10V voltage or 0~20 mA current signal, Upper and lower limits can be set separately			

Typical Functions	Automatic energy saving running		The output current timely adjust output voltage and slip compensation, the motor has been working at the highest efficiency. According to the status of the scene automatic energy saving operation can set the depth. In particular, it suitable for ball-mill and other energy-saving field of micro-adjustment frequency.
	Voltage stabilizing running Automatically		Three ways for selection: Dynamic voltage regulation、Static Voltage regulation、No Voltage regulation, to get the most stable operating result
	Acceleration/deceleration Time setting		0.1Sec ~ 6000min Continuous set, S type 、linear mode for selection
	Determine speed and restart		To achieve Smoothing restart and instantaneous-stop restart function of running motor.
	Counter、Timer		Embedded one timer and one counter, which will help the system's integration.
	Operation functions		Upper and Lower frequency setting , frequency skip operation , Reversal operating restriction , Slip frequency compensation , automatic stable voltage operation , RS485 communication , frequency increasing/decreasing control, fault recovery operation.
Display	Operation panel display	Running status	Output Freq. , Output current , Output voltage , Motor rotate speed , Setting Freq. , Model temperature , PID setting , PID feedback , Analog I/O
		Alarm content	Last running parameters record: Last six fault record , Output frequency of last fault trip、 Setting frequency、 Output current、 Output voltage、 DC voltage、 Model Temperature
Protection / Warning functions			Over current , over voltage, under current, under voltage , electronic thermal , overheating, extreme high temperature , short circuit , Phase-lacking of output , internal memory fault
Environmental Conditions	Ambient temperature		-10°C 至+50°C
	Ambient humidity		Under 90% (non-condensing)
	Ambient environment		Indoors (no inflammable gasses or dust)
	Altitude		Lower than 1000m
Configuration	Enclosure rating		IP20
	Cooling method		Fans cooling
Installation			Hanging

2. INSTALLATION GUIDELINES

2.1 Environmental requirements:



1. Be sure to install the inverter in a well-ventilated room.
2. Ambient temperature is from -10°C to 40°C . If the temperature is 40°C to 50°C , please take out the lower cover to cool.
3. Please avoid putting the inverter in a high temperature and moist location. The humidity is less than 90% and non-condensing.
4. Keep away from combustible, explosive material and caustic gas or liquid.
5. No dust, floating fiber and metal particles.
6. The inverter must be installed in a firm and no vibration location.
7. The installation plane should be solid and not vibrant.

If users demand any special installation, please contact us firstly

VS500 series inverter is hanging model, so it should be in vertical way. In order to ensure the air circulation around the inverter to aid in cooling, there should be enough space around the inverter shown as Fig. 2-1-A. Add the air deflector when apply the up-down installation shown as Fig. 2-1-B.




Fig2-1-A Interval distance




Fig2-1-B Multi-inverter Installation

2.2 Disassembly and assembly of the panel

Disassembly

Put your middle finger into “open hole”. Then gently press the fixed spring on the top of panel. Then pull outward to remove the panel.

Assembly

Aim the fixed hook to spring clip at bottom of operation panel, then press the fixed spring backward. Then push inward to the certain place. Shown as Fig. 2-2




Fig.2-2 Disassembly and assembly of the panel

2.3 Disassembly and assembly of the cover board

2.3.1 Disassembly and assembly of plastic cover board

It is fit for: VS500-4T0015~VS500-4T0075, VS500-2T0015~VS500-2T0037

Disassembly

Put the finger into the “portable hole”, pull upward to move the cover form the shell, then pull downward, which will remove the cover board.

Assembly

Lift the bottom of cover up to about 15°C, inserting the “Fixed hook” into the hold down groove, then press the cover down to hear a sound of “Click”, which means the cover board has already been mounted and shown as Fig. 2-3-A.




Fig2-3-A Disassembly and assembly of plastic cover board

2.3.2 Disassembly and assembly of lower cover board

It is fit for: VS500-4T0110~VS500-4T1100, VS500-2T0055~VS500-2T0550

Disassembly

1. Take two screws at bottom of lower cover board.
2. Move the lower cover board downward.

Assembly

1. Put the lower cover board parallel with the interval.
2. Move the lower cover board upward.
3. Screw the bottom of lower cover board.




Fig.2-3--B Disassembly and assembly of lower cover

2.4 Dimension of inverter

2.4.1 Model I

It is fit for: VS500-4T0015~VS500-4T0075, VS500-2T0015~VS500-2T0037




Fig2-4-A Dimension of model I

2.4.2 Model II

It is fit for: VS500-4T0110~VS500-4T0750, VS500-2T0055~VS500-2T0370




Fig2-4-B Dimension of model II

2.4.3 Model □

It is fit for: VS500-4T0900~VS500-4T2200, VS500-2T0450~VS500-2T1100




Fig 2-4-C Dimension of model III

2.4.4 Model IV

It is fit for: VS500-4T2500~VS500-4T3150, VS500-2T1320




Fig 2-4-D Dimension of model IV

Installation dimension of inverter, E380 is shown as following table:

Inverter model (3-phase 380V)	Inverter model (3-phase 220V)	W1 (mm)	W (mm)	H1 (mm)	H (mm)	D (mm)	Screw
VS500-4T0015	VS500-2T0015	123	134	223	234	165	M4
VS500-4T0022	VS500-2T0022						
VS500-4T0037	--						
VS500-4T0055	VS500-2T0037	157	169	282	294	178	M5
VS500-4T0075	--						
VS500-4T0110	VS500-2T0055	184	204	328	344	199	M6
--	VS500-2T0075						
VS500-4T0150	VS500-2T0110	200	230	400	420	211	M6
VS500-4T0185	--						
VS500-4T0220	--	232	260	450	470	233	M8
VS500-4T0300	VS500-2T0150						
VS500-4T0370	VS500-2T0185	271	300	545	567	250	M8
VS500-4T0450	VS500-2T0220						
VS500-4T0550	VS500-2T0300						
VS500-4T0750	VS500-2T0370	344	381	588	614	298	M8
VS500-4T0900	VS500-2T0450	380	510	710	740	270	M8
VS500-4T1100	VS500-2T0550						
VS500-4T1320	VS500-2T0750						
VS500-4T1600	VS500-2T0900	400	580	760	793	300	M10
VS500-4T1850	--						
VS500-4T2000	VS500-2T1100	550	700	960	1000	340	M10
VS500-4T2200	--						
VS500-4T2500	VS500-2T1320	580	730	1103	1130	355	M10
VS500-4T2800	--						
VS500-4T3150	--						

3. WIRING PROCEDURE

3.1 Precautions

- 3.1.1. Installing a middle breaker between inverter and power supply in order to avoid enlarging the accident.
- 3.1.2. Reducing the electromagnetic interference (EMI), please connect surge absorber to the coils of electromagnetic contactors, relays, etc.
- 3.1.3. Frequency setting terminals (VC1, VC2, CC and PLS), Instrument circuit (AO1 and AO2), etc., these analog signal wires should be over 0.3mm^2 shield wire. Shield layer is connected with earth terminal GND and the length of wire should be than 30m.
- 3.1.4. Wire of relay input and output circuit(X1 ~ X6, OC1, OC2, FWD, REV, RST) must be selected over 0.75mm^2 shield wire. Shield layer should be connected to earth terminal CM and the length of wire should be shorter than 50m.
- 3.1.5. Separating the main circuit wire from the signal/process circuit wiring, paralleled wiring should be at a distance of over 10cm and crossed wiring should be vertical with each other.
- 3.1.6. The wire must be less than 30m between motor and inverter. When the length of wire is over 30m, the carrier frequency of inverter should be reduced properly.
- 3.1.7. All of leading wires should be tightened with the terminal adequately to ensure well-contact. The leading wire of main circuit had better use the cable or cuprum tier, and wiring had better be operated after the lug plate of corresponding section's cold pressing or welding.
- 3.1.8. Compressive resistance of all the wire should match with the voltage grade of inverter.



It is not allowed that U, V, W of inverter connect with the surge absorber capacitor or other surge absorber equipment and shown as following Fig.




Fig 3-1 Output end prohibited from connecting with resistance-capacitance absorbing device

3.2 Wiring of External Components




Fig 3-2 Wiring of inverter

- Power Supply
It is according to the rated input power specifications in manual.
- Air-break switch
 1. When the inverter is in maintenance or leave-unused, the air-break switch should isolate the inverter from power supply.
 2. Input side of inverter takes place the fault of short-circuits or low-voltage, the air-break would take the protection.
- Contactor
Control the power-on or power-off of inverter expediently.
- AC electric reactor
 1. Improve the power factor.
 2. Reduce the harmonic wave input for the electric network.
 3. Weaken the imbalance effect on 3-phase power voltage.
- Brake resistor
In the situation of regenerative braking, avoiding bringing voltage too highly.


Recommending specification of commanded equipment is shown as following table:

Model	Applied Motor (KW)		Wire spec (Main circuit) (mm ²)	Air-break (A)	Magnetic contactor (A)
	G-load	P-load			
VS500-2T0015	1.5	--	4	20	18
VS500-2T0022	2.2	--	4	20	18
VS500-2T0037	3.7	--	6	40	25
VS500-2T0055	5.5	--	10	63	32
VS500-2T0075	7.5	--	10	63	38
VS500-2T0110	11	--	16	100	50
VS500-2T0150	15	--	25	160	80
VS500-2T0185	18.5	--	25	160	80
VS500-2T0220	22	--	25	160	95
VS500-2T0300	30	--	50	200	150
VS500-2T0370	37	--	50	250	170
VS500-2T0450	45	--	70	250	170
VS500-2T0550	55	--	95	400	225
VS500-2T0750	75	--	95	400	330
VS500-2T0900	90	--	150	630	330
VS500-2T1100	110	--	185	630	400
VS500-2T1320	132	--	185	800	500
VS500-4T0015	1.5	2.2	2.5	16	12
VS500-4T0022	2.2	3.7	4	16	12
VS500-4T0037	3.7	5.5	4	20	18
VS500-4T0055	5.5	7.5	6	32	18
VS500-4T0075	7.5	11	6	40	25
VS500-4T0110	11	15	10	63	32
VS500-4T0150	15	18.5	10	63	38
VS500-4T0185	18.5	22	16	100	50
VS500-4T0220	22	30	16	125	50
VS500-4T0370	37	45	25	160	95

Model	Applied Motor (KW)		Wire spec (Main circuit) (mm ²)	Air-break (A)	Magnetic contactor (A)
	G-load	P-load			
VS500-4T0450	45	55	50	200	115
VS500-4T0550	55	75	50	200	150
VS500-4T0750	75	90	70	250	170
VS500-4T0900	90	110	70	315	225
VS500-4T1100	110	132	95	400	225
VS500-4T1320	132	160	95	400	330
VS500-4T1600	160	185	150	630	330
VS500-4T1850	185	200	150	630	400
VS500-4T2000	200	220	185	630	400
VS500-4T2200	220	250	185	800	500
VS500-4T2500	250	280	240	800	500
VS500-4T2800	280	315	240	1000	630
VS500-4T3150	315	350	300	1250	630


Note: When inverters of same model of VS500 series are connected with loads from fan or water pump, the adaptive motor power can be increased one power level as compared to connection with the generic loads.

3.3 Basic wiring




3.4 Terminal of main circuit


3.4.1 **I model** (It is fit for VS500-4T0015~VS500-4T0075, VS500-2T0015~VS500-2T0037)




3.4.2 **II model** (It is fit for VS500-4T0110~VS500-4T0150, VS500-2T0055~VS500-2T0075)




3.4.3 **III model** (It is fit for: VS500-4T0185~VS500-4T0300 / VS500-4T1600~VS500-4T2200, VS500-2T0110~VS500-2T0150/ VS500-2T0900~VS500-2T1100)




3.4.4 **IV model** (It is fit for: VS500-4T0370~VS500-4T1320, VS500-2T0185~VS500-2T0750)



3.4.5 V model (It is fit for: VS500-4T2500~VS500-4T3150, VS500-2T1320)




3.4.6 VI model (It is fit for: VS500-4T2500~VS500-4T3150, VS500-2T1320)



Description of terminal:

Terminal	Function	Terminal	Function
P+	DC electric Reactor can be connected between P- and P+.	P	Positive Terminal of DC Negative
P-	Negative Terminal of DC / DC brake unite can be connected between P and P-.	PB	DC brake resistance can be connected between P+ and PB.
R、S、T	Connecting three-phase AC power supply	U、V、W	Connecting three-phase AC motor
E	Earth Terminal	--	--

3.5 Terminal of Control circuit



Type	Terminal	Function	Notes
Analog Input	VS	It provides +10V/10mA or +5V/50mA power to JP1	Switch JP1
	VC1	Frequency setting voltage signal input terminal 1	0~5V
	VC2	Frequency setting voltage signal input terminal 2	0~10V
	CC	Frequency setting current signal input terminal	0~20mA
	PLS	Pulse input signal terminal	0~50KHz/5~30V
	GND	Common terminal of Frequency setting voltage signal	
Control Terminal	X1	Multi-function input terminal 1	The detailed function of multi-function Input terminal is by set parameter F3.0~F3.5, The terminal is valid while being closed with CM terminal.
	X2	Multi-function input terminal 2	
	X3	Multi-function input terminal 3	
	X4	Multi-function input terminal 4	
	X5	Multi-function input terminal 5	
	X6	Multi-function input terminal 6	
Control Terminal	FWD	FWD control command terminal	Those terminals are valid when it connects with CM. And running direction of panel control is controlled by FWD-CM state
	REV	REV control command terminal	
	RST	Fault reset input terminal	
	CM	Common terminal of control	
	24V	It provides +24V/50mA power and is grounded by CM.	
Analog Output	AO1	PLC voltage signal input terminal1. It is set by F2.13 and allowed to connect with external voltmeter.	voltage signal output : 0~20mA/0~15V.
	AO2	PLC voltage signal input terminal 2. It is set by F2.14 and allowed to connect with external voltmeter.	Voltage signal output : 0~10V/1mA
	GND	Common terminal of AM1 and AM2	Switch JP2、JP3 select voltage or current
OC Output	OC1	PLC open-circuit collector output is set by F3.6 and F3.7	The maximum load-current is 50mA, while the maximum withstand voltage is 24V.
	OC2		
PLC output	TA	General , TA-TB is connected, TA-Tc is unconnected when TA-TB is unconnected and TA-TC is connected, F3.8 is valid.	Capacity: AC 250V 1A Resistive load
	TB		
	TC		
RS485 Interface	+	RS485 interface	
	-		
ERH		Grounding terminal	

Explanation about JP:

JP1:


- 1-2shorted: Input +5V/50mA signal
- 2-3shorted: Input +10V/10mA signal

JP2:

- 1-2 shorted: AO1 input voltage signal
- 2-3 shorted: AO1 input current signal

JP3:

- 1-2 shorted: AO2 input voltage signal
- 2-3 shorted: AO2 input current signal



4. OPERATIONS OF INVERTER AND SIMPLE RUNNING

Operation panel has two functions: One is to modify the running state parameters. The other is to check and modify the internal parameters. So operation panel has two modes: modify mode, check and modify parameters mode.

Usually, operation panel mode is in normal modify mode when inverter is just power-on. At this time, current running parameter, which is shown on operation panel, is controlled by F6.12、F6.13. The operation panel mode will return the normal modify mode, if there isn't any operation on panel in 1 min.

4.1 Operation panel

4.1.1 Panel layout




Fig.4-1-A Panel layout
















Fig.4-1-B Small Panel layout

4.1.2 Function of Key

Item	Function
Display	Main LED It displays current state and setting parameter.
	Auxiliary LED It displays current state and setting parameter. At the beginning of power supply, it displays inverter's program version, and it will return normality in 2 second. Small panel layout doesn't have this auxiliary LED
	A、Hz、V The corresponding unit of current display.
	RUN Operation indicator light. The inverter is running and U, V and W output voltage.
Keypad	FWD key: When F0.1 is 0 and press this key, the inverter will running forward to setting frequency according to appointed ACC or DEC curve.
	REV key: When F0.1 is 1 and press this key, the inverter will be running backward to setting frequency according to appointed ACC or DEC curve.
	Stop and Reset key: When F0.4 is 000#, STOP is valid for panel control. If F0.4 is 001#, STOP is valid for all kinds of control methods. If inverter occur fault, press this key to reset it and return stop mode. If stop key is used together with SET copy and read-in of internal parameters will be done

Keypad		<p>Return key Press this key in normal modify state to enter query mode of not normal modify state /modify parameters to check running state. In any state, press this key to return the upper state. This key is used together with  to perform Parameter read / backup</p>
		<p>Set key: This key is used together with  to perform Parameter copy / write.</p>
	 	<p>Data modify key: It is used to modify the function code and parameter. In state modify mode, if F0.1 is 0, press this key will modify the frequency instruction.</p>
		<p>Jog key: It is valid when the state is only in operation panel control pattern</p>
		<p>Shift key: In any state, press   key to modify data's state. Press the key to modify the digital bit, the modification bit will be displayed blink. This key is used together with  to perform Parameter read / backup.</p>
		<p>Panel potentiometer: This button is used for setting Inverter's running freq. Turning left the button is to decrease running freq. ,turning right the button is to increase running freq.</p>



4.2 Basic function of panel and methods of operation




4.2.1 Basic functions of panel

Operation panel have functions of FWD running, REV running, JOG running, Stop, Fault reset, Modify and check of parameter and Monitor running parameter, besides other function as follows:

(1) Parameter read / backup

This function provides to copy the internal parameter of inverter and saves it permanently. (Only limit to open internal parameter). So user can copy typical settings parameters to operate panel. These parameters don't affect inverter running, and are checked out and modified separately



Press  and  key simultaneously to enter parameter read / backup. Even if the inverter is running, reading parameters is also carried though. When parameters are read, "0" is displayed blink from right to left. After parameters backup is finished, the display is normal.




In process of parameters backup, it can be cancelled by pressing  or . And press  key to return the normal monitor state.

(2) Parameter copy / write

This function provides to copy the backup parameter of inverter and saves to inner storage of inverter. (Only limit to open internal parameter) So user can copy typical settings parameters to operate panel. Those parameters don't affect inverter running, and are checked and modified separately.

Please set F6.16 as 1 and stop the inverter before write parameter. After writing, set F6.16 as 0 to prevent invalid parameters saving in inverter. And it had better copy the valid inner parameter to operation panel.

Please stop the inverter and then press  and  key simultaneously to enter parameter copy / write under normal monitor mode. When parameters are writing, "0" is displayed blink from right to left. After parameters copy is finished, the display is normal.

In process of parameters copy, it can be cancelled by pressing  or . And press  key to return the normal monitor state.

(3) Modify and check the internal parameter


Press **SET** key to enter Modify and check internal parameter mode under normal mode with general ways to check and modify data.

4) Modify and check the backup parameter


Under normal monitor mode, press **<<** and **SET** key simultaneously to enter modify and check the backup parameter mode. When panel displays function code, “F” in the fourth place of main LED will be displayed blink, which means current modify and check parameters is backup parameter.

4.2.2 Methods of panel operation

(1) State parameter inquiry (eg.)



(2) Parameter inquiry and modify (eg.)



4.3 List of State monitor parameter

Monitor Code	Content	Unit	Remarks
d.0	Current output frequency	Hz	
d.1	Current output current (Effective value)	A	
d.2	Current output voltage (Effective value)	V	
d.3	Rotate speed of motorDC bus voltage	rpm	
d.4	DC bus voltage	V	
d.5	Input voltage of inverter	V	
d.6	Setting freq	Hz	
d.7	Count value of Internal counter		
d.8	PID setting value		
d.9	PID feedback value		
d.10	Running linear speed		
d.11	Setting linear speed		
d.12	Analog input voltage VC1	V	
d.13	Analog input voltage VC2	V	
d.14	Analog input voltage CC	mA	
d.15	External pulse input PLS	KHz	
d.16	State of input terminal		
d.17	Temperature of module	°C	
d.18	Analog output AO1		
d.19	Analog output AO2		
d.20	Reserved		
d.21	Reserved		
d.22	Reserved		
d.23	Reserved		
d.24	Reserved		
d.25	Reserved		
d.26	First fault record		
d.27	Second fault record		
d.28	Third fault record		
d.29	Fourth fault record		
d.30	Fifth fault record		
d.31	Sixth fault record		
d.32	Output frequency of last fault	Hz	
d.33	Setting frequency of last fault	Hz	
d.34	Output current of last fault	A	
d.35	Output voltage of last fault	V	
d.36	DC voltage of last fault	V	
d.37	Temperature of module of last fault	°C	

4.4 Simple Operation

4.4.1. Initialization

(1) Frequency input channel / mode selection ([F0.1])

Initialization of inverter is different according to different model. If [F0.0] is 0, the frequency of inverter is set by keypad.

(2) Operation channel selection ([F0.4])

Initialization of inverter is different according to different model. If F0.4 is 00#0, Start and stop of inverter is controlled by **FWD** and **STOP** key.

4.4.2. Simply operation



➤ It is forbidden to connect Three-phase power to output terminal U, V and W directly.




Fig.4-1 simply running

① Please wire as the Fig 4-1.

② Be sure that the wiring is correct and turn the power on, the inverter will display “P.oFF” and “0”.

Auxiliary LED displays the program version transitorily.

③ Be sure that F0.1 is 0.

④ Please set parameters [F1.3] and [F1.4], according to the nameplate parameters of applied motor.

⑤ Please press **FWD** key to start inverter, then the inverter will display 0.0Hz.

⑥ Please press **▲** key to increase input frequency and motor will run.

⑦ Observe the motor whether it runs normally or not. If abnormal, please stop running at once and turn off the power, and find out the reason, then restart.

⑧ Press the key **▼** to decrease the setting frequency.

⑨ Press the key **STOP** to stop running. Then turn power supply off.



➤ Carrier wave frequency is fixed value between 1.5 and 10 KHz. If motor does not take any load, it will a slight oscillate. So please decrease setting value of F0.16, Or setting Oscillatory inhibiting factor value of FC.11

5. PARAMETERS LIST



Description of symbol on the function parameter list: “★” means that this parameter cannot be change during operation; “▲” means that this parameter is related to the inverter’s model; “◆”Indicate that parameter is a random value

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
Basic operation parameter unit	F0.0	Running mode selection	LED bits : Running mode 0: General mode 1: Special for drawing machine LED tens: Reserved LED hundreds: Reserved LED thousands: Reserved	1	0000	★
	F0.1	Frequency input channel / mode selection	0 : Frequency setting by operation panel 1 : UP/DW Acc and Dec control 2 : RS485 interface 3 : Panel potentiometer 4 : External voltage signal VC1 (0V~5V) 5 : External voltage signal VC2 (0V~10V) 6 : External current signal CC (0~20mA) 7 : External pulse signal (0.0~50.0KHz) 8 : Combination setting 9 : External terminals	1	0	
	F0.2	Frequency digital setting	0.00~ the upper limit frequency	0.01	0	
	F0.3	Auxiliary control of freq. Digital setting	The first part of LED(form right to left): 0: Setting freq. will save after power down 1: Setting freq. will not save after power down The second part of LED : 0 : Setting freq. is to keep when stopping 1 : Setting freq. will save in F0.2 when stopping 2 : Setting freq. is clear when stopping The third and fourth part of LED(form right to left) : Reserved	1	0000	
	F0.4	Operation channel selection	The first part of LED (form right to left): 0 : Panel control 1 : External terminals control 2 : RS485 interface The second part of LED : Function of key STOP 0 : It is valid for panel control. 1 : It is valid for all kinds of control method. The third and fourth part of LED(form right to left) : Reserved	1	0000	
	F0.5	Combination methods of instruction terminals	0 : Two-line mode 1 : Two-line mode 2 : Three-line mode	1	0	★

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
Basic operation parameter unit	F0.6	Running direction control and setting of operation instruction auxiliary	The first part of LED (form right to left): 0 : Running direction is consistent with setting direction 1 : Running direction is in contradiction to setting direction The second part of LED : 0 : Prevention REV is valid 1 : Prevention REV is invalid The third and fourth part of LED(form right to left) : External operation channel auxiliary function 0 : self-starting is forbidden when inverter is just power-on 1 : self-starting is allowed when inverter is just power-on The fourth part of LED(form right to left) : Reserved	1	0100	
	F0.7	The lower limit frequency	0.0~[F0.8]	0.01	0.0	
	F0.8	The upper limit frequency	[F0.7]~400.00 Hz	0.01	50.00Hz	
	F0.9	Reserved				
	F0.10	Acc time 1	0.1~6000 Sec	0.1	▲	
	F0.11	Dec time 1	0.1~6000 Sec	0.1	▲	
	F0.12	Characteristics parameter of Acc and Dec	The first part of LED (form right to left): 0 : Beeline 1 : S curve The second part of LED : 0 : Output freq. will be modified according to Acc/Dec time. 1 : Output freq. will be automatically modified according to lode. The third part of LED : Unit of Acc/Dec time 0 : Sec 1 : Min The fourth part of LED : Reserved	1	0000	
	F0.13	Acc/Dec initial section proportion Of S curve	10.0~50.0 (%)	0.1	20.0%	★
	F0.14	Acc/Dec ascending/decline section proportion of S curve	10.0~80.0 (%)	0.1	60.0%	★
	F0.15	Lode pattern selection	0 : General-purpose lode. 1 : Fan and pump lode.	1	0	★
F0.16	Carrier wave frequency	1.5~12.0 KHz	0.1	▲		

	F0.17	Carrier wave characteristics	<p>The first part of LED (form right to left): Reserved</p> <p>The second part of LED : 0 : Load carrier wave adjustment is invalid 1 : Load carrier wave adjustment is valid</p> <p>The third part of LED : 0 : Heat carrier wave adjustment is invalid 1 : Heat carrier wave adjustment is valid</p> <p>The fourth part of LED : 0 : Freq. relating carrier wave adjustment is Invalid 1 : Freq. relating carrier wave adjustment is valid</p>	1	1110	
Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
Basic operation parameter unit	F0.18	Parameter write-protection	<p>1 : Forbid to modify all parameter, except F0.2 and F0.18</p> <p>2 : Forbid to modify all parameter, except F0.18</p> <p>Other values: all parameters are allowed to modify</p>	1	0	
Primary applied parameter unit	F1.0	Type of V/F Curve	<p>0 : Constant torque curve</p> <p>1 : Low-freq. torque curve 1</p> <p>2 : Low-freq. torque curve 2</p> <p>3 : V/F user-defined curve</p>	1	0	★
	F1.1	Torque Boost	0.0~20.0 (%)	0.1	▲	
	F1.2	Torque boost pattern	0 : Manual 1 : Automatic	1	0	★
	F1.3	Basic running frequency	5.00~the upper limit frequency	0.01	50.00	
	F1.4	Max output voltage	200~500V /100~250V	1	400 220	
	F1.5	V/F freq. 3	[F1.7]~[F1.3]	0.01	0.0	★
	F1.6	V/F voltage 3	[F1.8]~100.0(%)	0.1	0.0	★
	F1.7	V/F freq. 3	[F1.9]~[F1.5]	0.01	0.0	★
	F1.8	V/F voltage 2	[F1.10]~[F1.6]	0.1	0.0	★
	F1.9	V/F freq. 1	0.0~[F1.7]	0.01	0.0	★
	F1.10	V/F voltage 1	[F1.1]~[F1.8]	0.1	0.0	★
	F1.11	DC braking current when starting	0.0~100.0 (%)	0.1	50.0	
	F1.12	DC braking time when starting	0.0~20.0Sec	0.1	0	★
	F1.13	Compensation for slipping freq.	0~150 (%)	1	0	
	F1.14	Droop control	0~100 (%)	1	0	
	F1.15	Initial level of droop control	0~150 (%)	1	25	
	F1.16	Ending level of droop control	10~200 (%)	1	100	
	F1.17	Droop control mode	0 : Absolute droop 1 : Relative droop	1	1	
F1.18	Reserved					
	F2.0	VC1 input lower limit voltage	0.0 V~[F2.1]	0.1	0.0	
	F2.1	VC1 input upper limit voltage	[F2.0]~5.0 V	0.1	5.0 V	

F2.2	VC2 input lower limit voltage	0.0 V~[F2.3]	0.1	0.0	
F2.3	VC2 input upper limit voltage	[F2.2]~10.0 V	0.1	10.0 V	
F2.4	CC input lower limit voltage	0.0 mA~[F2.5]	0.1	4.0 mA	
F2.5	CC input upper limit voltage	[F2.4]~20.0 mA	0.1	20.0 mA	
F2.6	The min pulse input	0.0 KHz~[F2.7]	0.01	0.0	
F2.7	The max pulse input	[F2.6]~50.00 KHz	0.01	10.0KHz	
F2.8	Frequency with the min setting	0.0~[F2.9]	0.01	0.00Hz	
F2.9	Frequency with the max setting	[F2.8]~600.0 Hz	0.01	50.00Hz	

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
Analog I/O parameter unit	F2.10	Characteristics selection of input channel	The first part of LED (form right to left) : (VC1channel) 0 : positive characteristics 1 : Negative characteristics The second part of LED : (VC2 channel) 0 : positive characteristics 1 : Negative characteristics The third part of LED : (CC channel) 0 : positive characteristics 1 : Negative characteristics The fourth part of LED : (pulse channel) 0 : positive characteristics 1 : Negative characteristics	1	0000	★
	F2.11	External freq. set time constant of filtering	0.01~1.00 Sec	0.01	0.10	
	F2.12	Combination setting mode	Refer to the explanations about F2.12	1	0	
	F2.13	Analog output selection (AO1、 AO2)	The first part of LED (form right to left) : AO1 output 0 : Output freq. 1 : Output current 2: Output voltage 3 : Rotate speed of applied motor 4 : PID setting 5 : PID feedback The second part of LED : AO2 output 0 : Output freq. 1 : Output current 2 : Output voltage 3 : Rotate speed of applied motor 4 : PID setting 5 : PID feedback The third and fourth part of LED : Reserved	1	0010	
	F2.14	The lower limit of analog output AO1	0.0~[F2.15]	0.1	0.0 V	
	F2.15	The upper limit of analog output AO1	[F2.14]~12.0	0.1	10.0 V	
	F2.16	The lower limit of analog output AO2	0.0~[F2.17]	0.1	2.0 V	
	F2.17	The upper limit of analog output AO2	[F2.16]~12.0	0.1	12.0 V	
	F2.18	Reserved				

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
Digital O/I parameter unit	F3. 0	Function selection of input terminal 1 (0~26)	0 : Control terminal is idle 1 : Multi-speed control terminal 1 2 : Multi-speed control terminal 2 3 : Multi-speed control terminal 3	1	1	★
	F3. 1	Function selection of input terminal 2 (0~26)	4 : Wobble freq. is valid 5 : State of wobble freq. reset 6 : FWD jog control 7 : REV jog control	1	2	★
	F3. 2	Function selection of input terminal 3 (0~26)	8 : Acc& Dec time selection terminal 1 9 : Acc& Dec time selection terminal 2 10 : Freq. setting channel selection 1 11 : Freq. setting channel selection 2	1	3	★
	F3. 3	Function selection of input terminal 4 (0~26)	12 : Freq. setting channel selection 3 13 : Freq. is controlled gradually increase (UP) 14 : Freq. is controlled gradually decrease (DW)	1	6	★
	F3. 4	Function selection of input terminal 5 (0~26)	15 : UP-DW freq. clear 16 : Uncontrolled stop control 17 : Fault signal of peripheral equipment input 18 : Three-line mode running control	1	13	★
	F3. 5	Function selection of input terminal 6 (0~26)	19 : DC braking control 20 : Inner counter clear 21 : Inner counter timer 22 : PLC running valid 23 : PID running valid 24 : Internal timer trigger terminal 25 : PLC state reset after stopping 26 : Multi-speed control terminal 4	1	14	★
	F3. 6	Output terminal OC1	0 : In the running 1 : Frequency reaching 2 : Freq. level detection signal (FDT) 3 : Over-loading alarm 4 : External fault halt	1	2	
	F3. 7	Output terminal OC2	5 : Output frequency reaches the upper-limit 6 : Output frequency reaches the lower-limit 7 : Running in zero speed 8 : Internal timer reaches the setting time	1	1	

	F3. 8	TA, TB and TC of relay contacts	9 : PLC stage is end of run 10 : PLC periodic is end of run 11 : Internal timer arrive regular time 12 : Setting value of counter arrives 13 : Designated value of counter arrives 14 : Deceleration running 15 : Reserved 16 : Inverter fault 17 : Restrictions on wobble freq. of the upper and lower limit freq. 18 : Reserved	1	16	
	F3. 9	Frequency reach the checkout amplitude	0.0~20.00 Hz	0. 01	5.00	
	F3. 10	FDT setting 1	0.0~the upper limit freq.	0.01	10.00	
	F3. 11	FDT output delay time 1	0.0~200.0 Sec	0.1	2.0	★
	F3. 12	FDT setting 2	0.0~the upper limit freq.	0.01	10.00	
	F3. 13	FDT output delay time 2	0.0~200.0Sec	0.1	2.0	★

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
	F3.14	Over-loading alarm level	50~200 (%)	1	110	
	F3.15	Over-loading alarm delay time	0.0~20.0 Sec	0.1	2.0	★
	F3.16	Reserved				
Auxiliary running parameter unit	F4.0	Start mode	0 : Routine mode 1 : Detect speed and restart	1	0	★
	F4.1	Start frequency	0.0~10.00 Hz	0.01	0.5	
	F4.2	Start frequency duration	0.0~20.0 Sec	0.1	0.0	★
	F4.3	Stop mode	0 : Decelerate mode 1 : Uncontrolled stop	1	0	
	F4.4	Initial freq. of DC braking when stopping	0.0~50.00 Hz	0.01	3.00	
	F4.5	Waiting time of DC braking when stopping	0.0~5.0 Sec	0.1	0.0	
	F4.6	Action time of DC braking when stopping	0.0~20.0 Sec	0.1	0	★
	F4.7	DC braking current when stopping	0.0~100 (%)	0.1	50.0	
	F4.8	Running threshold of zero freq.	0.0~100.00 Hz	0.01	0.0	
	F4.9	Return different of zero freq	0.0~50.00 Hz	0.01	0.50	
	F4.10	FWD jog frequency	0.0~the upper limit freq.	0.01	10.00	
	F4.11	Acc torque level	110~200 (%)	1	165	
	F4.12	Motor over-lode protection coefficient	50~110 (%)	1	110	
	F4.13	Automatic voltage regulation (AVR)	0 : Invalid 1 : Dynamic valid 2 : Static valid 3 : Deceleration invalid	1	0	
	F4.14	Energy-saving running	0 : Invalid 1 : Valid	1	0	★
	F4.15	Intensify of energy-saving running	30~90	1	60	
	F4.16	Dead time of FWD&REV	0.0~5.0 Sec	0.1	0.0	★
	F4.17	Acceleration time 2	0.1~6000 Sec	0.1	▲	
	F4.18	Deceleration time 2	0.1~6000 Sec	0.1	▲	
	F4.19	Acceleration time 3	0.1~6000 Sec	0.1	▲	
	F4.20	Deceleration time 3	0.1~6000 Sec	0.1	▲	
	F4.21	Acc time 4/Jog Acc time	0.1~6000 Sec	0.1	▲	
	F4.22	Dec time 5/Jog Dec time	0.1~6000 Sec	0.1	▲	
	F4.23	Modified rated of UP/DW terminals	0.01~100.0 Hz/Sec	0.01	10.00Hz	
	F4.24	Start voltage of dynamic braking	600~750 V	1	700V	
F4.25	Action ratio of dynamic braking	10~100 (%)	1	60%		

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
Auxiliary running parameter unit	F4.26	Restart after power down setting	The first part of LED : 0 : Invalid 1 : Valid The second part of LED : 0 : Routine mode 1 : Detect speed and restart mode The third and fourth part of LED : Reserved	1	0010	★
	F4.27	Waiting time of restart after power	0.0~10.0 Sec	0.1	0.5	★
	F4.28	REV jog frequency	0.0~the upper limit freq.	0.01	10.00	
Multi-speed running parameter unit	F5.0	Multi-speed running mode	The first part of LED(form right to left) : Simple PLC selection 0 :Simple PLC is invalid. 1 :Simple PLC is valid 2 : Simple PLC is conditional valid The second part of LED : Simple PLC running mode selection 0 : Single loop mode 1 : Single loop and stop mode 2 : Continuous loop mode 3 : Continuous loop and stop mode 4 : Keep the end value 5 : Keep the end value and stop mode The third part of LED 0 : Restart from the first stage freq. 1 : Restart from running freq., which is saved before running is break 2 : Restart from setting freq. when running is break. The fourth part of LED : PLC save state 0 : Non-save after power off 1 : Save after power off	1	0000	★
	F5.1	Multi-speed frequency 1	0.0~the upper limit freq	0.01	35.00	
	F5.2	Multi-speed frequency 2	0.0~the upper limit freq	0.01	15.00	
	F5.3	Multi-speed frequency 3	0.0~the upper limit freq	0.01	3.00	
	F5.4	Multi-speed frequency 4	0.0~the upper limit freq	0.01	20.00	
	F5.5	Multi-speed frequency 5	0.0~the upper limit freq	0.01	25.00	
	F5.6	Multi-speed frequency 6	0.0~the upper limit freq	0.01	30.00	
	F5.7	Multi-speed frequency 7	0.0~the upper limit freq	0.01	35.00	
	F5.8	Multi-speed frequency 8	0.0~the upper limit freq	0.01	40.00	
	F5.9	Multi-speed frequency 9	0.0~the upper limit freq	0.01	35.00	
	F5.10	Multi-speed frequency 10	0.0~the upper limit freq	0.01	15.00	
	F5.11	Multi-speed frequency 11	0.0~the upper limit freq	0.01	3.00	
	F5.12	Multi-speed frequency 12	0.0~the upper limit freq	0.01	20.00	
	F5.13	Multi-speed frequency 13	0.0~the upper limit freq	0.01	25.00	

	F5.14	Multi-speed frequency 14	0.0~the upper limit freq	0.01	30.00	
	F5.15	Multi-speed frequency 15	0.0~the upper limit freq	0.01	35.00	

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
Multi-speed running parameter unit	F5.16	Running time of Multi-speed 1	0.0~6000 Sec	0.1	10.0	
	F5.17	Running time of Multi-speed 2	0.0~6000 Sec	0.1	10.0	
	F5.18	Running time of Multi-speed 3	0.0~6000 Sec	0.1	10.0	
	F5.19	Running time of Multi-speed 4	0.0~6000 Sec	0.1	10.0	
	F5.20	Running time of Multi-speed 5	0.0~6000 Sec	0.1	10.0	
	F5.21	Running time of Multi-speed 6	0.0~6000 Sec	0.1	10.0	
	F5.22	Running time of Multi-speed 7	0.0~6000 Sec	0.1	10.0	
	F5.23	Running time of Multi-speed 8	0.0~6000 Sec	0.1	10.0	
	F5.24	Running direction of PLC multi-speed	The first part of LED(form right to left) : 0 : Stage 1 FWD 1 : Stage 1 REV The second part of LED : 0 : Stage 2 FWD 1 : Stage 2 REV The third part of LED : 0 : Stage 3 FWD 1 : Stage 3 REV The fourth part of LED : 0 : Stage 4 FWD 1 : Stage 4 REV	1	0000	
	F5.25	Running direction of PLC multi-speed	The first part of LED(form right to left) : 0 : Stage 5 FWD 1 : Stage 5 REV The second part of LED : 0 : Stage 6 FWD 1 : Stage 6 REV The third part of LED : 0 : Stage 7 FWD 1 : Stage 7 REV The fourth part of LED : 0 : Stage 8 FWD 1 : Stage 8 REV	1	0000	
F5.26	PLC timing running shutdown	0 : Invalid 1 ~ 9999(min) : timing running time	1	0		
Advanced running parameter unit	F6.0	Internal timer	0.1~6000.0 Sec	0.1	10.0	
	F6.1	Fault self-recovery time	0, 1, 2	1	0	★
	F6.2	Interval time of fault self-recovery	0.2~20 Sec	0.1	2.0	★
	F6.3	Final value setup of internal counter	1~60000	1	1	★
	F6.4	Internal timer setup	1~60000	1	1	★
	F6.5	Skip freq. 1	0.0~the upper limit freq.	0.01	0	
	F6.6	Amplitude accumulation of Skip freq. 1	0.0~5.00 Hz	0.01	0	
	F6.7	Skip freq. 2	0.0~the upper limit freq.	0.01	0	
	F6.8	Amplitude accumulation of Skip freq. 2	0.0~5.00 Hz	0.01	0	
	F6.9	Linear speed coefficient setting	0.01~100.0	0.01	1.00	

	F6.10	Close-loop analog coefficient setting	0.01~100.0	0.01	1.00	
	F6.11	Rotator speed coefficient setting	0.01~10.00	0.01	1.00	
	F6.12	Monitor item selection 1 / Main display	0~11	1	0	

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
Advanced running parameter unit	F6.13	Monitor item selection 2 / Auxiliary display	0~19	1	1	
	F6.14	Query or modify parameters	0~9999	1	1700	
	F6.15	Parameter initialization	0 : Parameter initialization is off. 1 : Parameter initialization is on. 2 : Clean fault records 3 : complete initialization	1	0	★
	F6.16	Copy parameter function	0 : Copy forbidden 1 : Copy allowed	1	0	
	F6.17	Manufactory password	0~9999	1	1500	
	F6.18	User password	0~9999	1	0	
	F6.19	Reference password	0~9999	1	◆	
Wobble freq. running parameter unit	F7.0	Wobble freq. running mode	The first part of LED (form right to left) : 0 : Function of wobble freq. is invalid. 1 : Function of wobble freq. is valid. 2 : Function of wobble freq. is conditional valid. The second part of LED: restart mode 0 : Restart according to parameters saved before stop 1 : Restart The third part of LED: wobble freq. characteristics 0 : The wobble freq. is fixed 1 : The wobble freq. is changeable. The fourth part of LED: Storage characteristics of wobble freq. 0 : It will not save the running state of wobble freq. after power off 1 : It will save the running state of wobble freq. after power off	1	0000	★
	F7.1	Preset freq. of wobble freq.	0.0~the upper limit freq	0.01	10.00	
	F7.2	Waiting time of preset freq.	0.0~6000.0 Sec	0.1	0.0	★
	F7.3	Amplitude of wobble freq.	0.0~50.0 (%)	0.1	10.0	
	F7.4	Jumping freq	0.0~80.0 (%)	0.1	10.0	
	F7.5	Triangular rise time	0.1~1000.0 Sec	0.1	10.0	
	F7.6	Triangular fall time	0.1~1000.0 Sec	0.1	10.0	
	F7.7	Preset center freq. of wobble freq.	0.0~the upper limit freq	0.01	10.0	
	F7.8	Reserved				

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
PID control parameter unit	F8.0	Inner P ID control	<p>The first part of LED(form right to left) :</p> <p>Inner PID control</p> <p>0 : Inner PID control is invalid</p> <p>1 : Inner PID control is valid</p> <p>2 : Inner PID control is conditional valid.</p> <p>The second part of LED :</p> <p>PID controller selection</p> <p>0 : proportion 1 : Integral</p> <p>2 : Proportion and integral</p> <p>The third part of LED :</p> <p>Regulating property of PID controller</p> <p>0 : positive interaction 1 : Reactor</p> <p>The fourth part of LED:</p> <p>0: Single polar PID control</p> <p>1: Bi-polar PID control</p>	1	0020	★
	F8.1	Inner PID setting and channel selection	<p>The first part of LED(form right to left) :</p> <p>0 : Digital setting. It is set by parameter F8.2.</p> <p>1 : Serials interface setting</p> <p>2 : Panel potentiometer setting, it is on the operation panel.</p> <p>3 : External voltage signal VC1 (0V~5V) 。</p> <p>4 : External voltage signal VC2 (0V~10V) 。</p> <p>5 : External current signal CC (0~20mA) 。</p> <p>The second part of LED : Reserved.</p> <p>The third part of LED : It is used to set PID feedback channel.</p> <p>0 : External voltage input VC1</p> <p>1 : External voltage input VC2</p> <p>2 : External current input CC</p> <p>3 : Pulse input PLS 4 : VC1+CC</p>	1	0000	★
	F8.2	Inner PID close-loop digital setting	0.00~10.00 V	0.01	0.00	
	F8.3	Minimum fixed value	0.0~[F8.4]	0.01	0.0	
	F8.4	Maximum fixed value	[F8.3]~10.00	0.01	10.00	
	F8.5	Feedback of minimum fixed value	0.0~10.00	0.01	0.0	
	F8.6	Feedback of maximum fixed value	0.0~10.00	0.01	10.00	
	F8.7	Proportion gain	0.0~5.00	0.01	1.00	
	F8.8	Integration time constant	0.1~100.0 Sec	0.1	50.0	
	F8.9	Allowable deviation limit	0.0~20.0 (%)	0.1	5.0	
	F8.10	Preset freq. for close-loop	0.0~the upper limit freq.	0.01	0.0	
	F8.11	Holding time of preset freq. for close-loop	0.0~6000.0 Sec	0.1	0.0	★
	F8.12	Long-distance manometer range	0.001~20.000 Mpa	0.001	1.000	
	F8.13	Sleeping threshold	[F8.14]~10.00V	0.01	10.00	

40 VISION VS500

	F8.14	Awakening threshold	0.01~[F8.13]	0.01	0.0	
--	-------	---------------------	--------------	------	-----	--

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
PID control parameter unit	F8.15	Switching time of Sleeping/Awakening mode	5.0~500.0 Sec	0.1	300.0	
	F8.16	Upper limit pressure value	[F8.17]~[F8.12]	0.001	1.000	
	F8.17	Lower limit pressure value	0.001~[F8.16]	0.001	0.0	
	F8.18 ... F8.24	Reserved				
Serials communication parameters	F9.0	Communication setting	The first part of LED(form right to left) : It is used to set baud rate of serials communication. 0 : Reserved 1 : 1200bps 2: 2400bps 3: 4800bps 4: 9600bps 5: 19200bps The second part of LED : To set data format of serials communication. 0 : Close 1 : Even 2 : Odd The third and fourth part of LED: Reserved.	1	0114	★
	F9.1	Local address	0~30	1	1	
	F9.2	Response delay of local	0~1000 ms	1	5ms	
	F9.3	Function setting of communication Auxiliary function	The first part of LED(form right to left) : 0 : The inverter is guest 1: The inverter is host The second part of LED : Act selection after communication is lost 0 : Stop 1 : Keep The third part of LED : linkage jog 0 : jog synchronized 1 : jog asynchronous The fourth part of LED : linkage control synchronized frequency source	1	0010	
	F9.4	Checkout time of communication overtime	0.0~100.0 Sec	0.1	10.0	
	F9.5	Linkage setting proportion	0.010~10.000	0.01	1.000	
	F9.6	Rectify channel of linkage setting proportion	0 : close 1 : Panel potentiometer Rectify channel 2 : External voltage signal VC1 (0 ~ 5V) Rectify channel 3 : External voltage signal VC2 (0 ~ 10V) Rectify channel 4 : External current signal CC (0 ~ 20mA)	1	0	
	F9.7	Setting channel of slave machine auxiliary freq.	0 : No auxiliary freq. 1 : Panel potentiometer 2 : External voltage signal VC1 (0 ~ 5V) 3 : External voltage signal VC2 (0 ~ 10V) 4 : External current signal CC	1	0	
	F9.8	Amplitude of auxiliary freq.	0.0~25.00 Hz	0.01	5.00	

42 VICSION VS500

	F9.9	Load self-equilibrium function	0 : Invalid 1 : Valid	1	0	
	F9.10	Load self- equilibrium proportion	0.50~2.00	0.01	1.00	

Function	Code	Name	Setting range	Minimum Setting	Manufacture Setting	Modify Limit
	F9.11	Trimming range of load self equilibrium freq.	0.0~5.00	0.01	2.00	
Special function parameter unit	FC.0	Under voltage protection level	360~460 V	1	380	
	FC.1	Over voltage limit level	660~760 V	1	720	
	FC.2	Current amplitude limiting level	150~200 (%)	1	190	
	FC.3	Reserved				
	FC.4	Reserved				
	FC.5	Action function selection	The first part of LED(form right to left) : Cooling fan control 0 : Cooling fan run after inverter run. 1 : Cooling fan will automatic run when inverter is power on. The second part of LED : Variable speed control of cooling fan 0:Low level (terminals is connected) 1:High level (terminals is disconnected)	1	1100	
	FC.6	Auxiliary function	The first part of LED(form right to left) : Forbid modify parameters function 0 : Invalid 1 : Valid The second part of LED : Input terminal effective level 0:Low level (terminals is connected) 1:High level (terminals is disconnected) The third part of LED: Reserved The fourth part of LED : selection of rotate speed display proportion 0: the coefficient of rotate speed display is valid 1: the deceleration proportion is valid	1	0000	
	FC.7	Reserved				
	FC.8	Agency password	0~9999	1	100	
	FC.9	Reserved				
	FC.10	Reserved				
	FC.11	Oscillatory inhibiting factor	0.00~2.00	0.01	0.00	
	FC.12	Reserved				
FC.13	Program version	1600~1699	1	▲		

6. DESCRIPTION OF SPECIFIC FUNCTIONS

(General parameter: [F0.0]=0000)

6.1 Basic operation parameter unit

F0.0 Choosing the running mode

Setting range: 0000 ~ 0001

It is used for selecting the running mode of inverter. Inverter is able to switch between the mode of general running and mode of dedicated drawing machine through changing the setting of first part of LED. And the parameters list and soft function mode have been operated.

The first part of LED(form right to left):

0: General mode (General parameter is valid.)

1: Dedicated drawing machine mode (Drawing machine parameter is valid.)

If the setting of parameter has changed, there would be a process of initialization; meantime, it would be shifted to the corresponding parameter environment. Meanwhile, this parameter cannot be initialized.

Please refer to the Seventh Chapter to use parameters. The first part of LED(form right to left): Reserved

It is used for selecting the running mode of inverter. Inverter is able to switch between the mode of general running and mode of dedicated drawing machine through changing the setting of first part of LED. And the parameters list and soft function mode have been operated.

The first part of LED(form right to left):

0: General mode (General parameter is valid.)

1: Dedicated drawing machine mode (Drawing machine parameter is valid.)

If the setting of parameter has changed, there would be a process of initialization; meantime, it would be shifted to the corresponding parameter environment. Meanwhile, this parameter cannot be initialized.



Please refer to the Seventh Chapter to use parameters. The first part of LED(form right to left): Reserved

F0.1 Frequency input channel / mode selection

Setting range: 0 ~ 9

It is used for selecting input channel of frequency instruction.

0: Frequency setting by operation panel

Frequency of inverter is set by parameter F0.2 as well as by the key  and  on the operation panel in normal monitor mode.

1: UP/DW Acc and Dec control

Running frequency is set by terminals UP and DW. And controlled terminals UP and DW can be selected by parameters [F3.0] ~ [F3.5]. When UP is on, the running frequency will increase. When UP is on, the running frequency will decrease. When UP and DW is on or off together with CM, running frequency will fix. The rate of modified frequency of terminals UP and DW is set by parameter F4.23.

2: RS485 interface

Through serial communication, it receives instruction of setting frequency from PC or the master.

3: Panel potentiometer

Running frequency can be set by potentiometer on the operation panel.

4: External voltage signal VC1

Running frequency is set by external voltage signal VC1. (VC1 is form 0.0 to 5.0V) Please set the VC1 referring to

the parameters F2.0 and F2.1.

5: External voltage signal VC2

Running frequency is set by external voltage signal VC2. (VC2 is form 0.0 to 10.0V) Please set the VC2 referring to the parameters F2.2 and F2.3.

6: External current signal CC

Running frequency is set by external current signal CC. (CC is form 0.0 to 20.0mA) Please set the CC referring to the parameters F2.4 and F2.5.

7: External pulse signal

Running frequency is set by external pulse signal. (It is form 0.0 to 350.0 KHz, and the amplitude accumulation is form 5 to 30V) Please set the pulse signal referring to the parameters F2.6 and F2.7.

8: Combination setting

Running frequency is set by linear combination of each channel, and combination mode is decided by parameter F02.12.



9: External terminals

External terminals set input channel of frequency. And it can be set by parameters F3.0~F3.5.

Freq. Setting terminal 3	Freq. Setting terminal 2	Freq. Setting terminal 1	Freq. Setting channel
0	0	0	Frequency setting by operation panel
0	0	1	UP/DW Acc and Dec control
0	1	0	RS485 interface
0	1	1	Panel potentiometer
1	0	0	External voltage signal VC1
1	0	1	External voltage signal VC2
1	1	0	External current signal CC
1	1	1	External pulse signal

F0.2 Frequency digital setting

Setting range: 0.0 ~ the upper limit frequency

When F0.1 is 0, Frequency digital setting controls output frequency of inverter. In normal monitor state, user can use the key  and  to modify this parameter.

As for F0.1 is 1 or F0.1 is 2, the frequency will save in parameter F0.3 after power off, if F0.3 is 00#0

F0.3 Auxiliary control of freq. digital setting

Setting range: 0000 ~ 0021

It is used for making sure that the frequency is set under the stopping or power off situation. When F0.1 is 0, 1 or 2, set parameter F0.3 to ensure that setting freq. is or not be saved in F0.2. The first part of LED(form right to left):

0: Inverter will run in setting freq. that is storage in F0.2 after stopping

1: Setting freq. will lost after stopping. And inverter will run in 0.0Hz when restarting

The second part of LED(form right to left):

0: Setting freq. is kept when stopping

1: Setting freq. will save in F0.2 when stopping

2: Setting freq. is cleared when stopping

The third and fourth part of LED(form right to left): Reserved.

F0.4 Operation channel selection Setting range: 0000 ~ 0012

It is used for selecting operation channel of inverter and function of key **STOP** .
 The first part of LED (form right to left): to select operation channel of inverter.

0: Keypad control

The inverter is controlled by key **FWD**, **REV**, **STOP** and **JOG** on the keypad. And FWD state will affect output phase sequence of inverter. When FWD is on with CM, output phase sequence will reverse with setting sequence, contrariwise, output phase sequence will go the same way with setting sequence.

1: External terminals control

The inverter receives running instruction from external terminals FWD, REV and CM. The manufacture setting is shown as follows.

Instruction	STOP Instruction		FWD	REV
Terminals State				

2: RS485 interface

Through serial communication, it receives instruction of setting frequency from PC or the master

The second part of LED (form right to left): to select function of the key. **STOP**

0: It is valid for panel control.

When F0.4 is 0, Stop key on the operation panel is available.

1: It is valid for all kinds of control method.

When F0.4 is not 0 and press **STOP** stop key, inverter will emergency stop and twinkling display Fu.16.

The third and fourth part of LED(form right to left): Reserved.

F0.5 Combination methods of instruction terminals Setting range: 0 ~ 2

It is used for setting control mode of external terminals.



This parameter will be valid only when F0.4 is set as ###1

0: Two-line mode 1 (default setting)

Instruction	STOP Instruction		FWD	REV
Terminals State				

0: Two-line mode 2

Instruction	STOP Instruction	run	FWD	REV
Terminals State				

2: Three- line mode

Please select a three-line mode terminal to set three-line mode. (Refer to description of parameters F3.0 ~ F3.5) X? is three-line mode terminals, and it is any one among terminals X1 ~ X6

Switch function is shown as follow:

- 1. SW1 —— Stop trigger switch of inverter
- 2. SW2 —— FWD trigger switch
- 3. SW3 —— REV trigger switch




Fig.6-1 three-line mode wiring




Fig.6-2 output freq when three-line

F0. 6 Running direction control and instruction auxiliary setting

Setting range: 0000 ~ 0111

It is used for changing the output phase-sequence of inverter, which changes the operating direction of motor (set by binary system)

The third part of LED: External operation channel auxiliary function

- 0: Self-starting is forbidden when inverter is just power-on
- 1: Self-starting is allowed when inverter is just power-on

When [F0.6]=#0##, when inverter is just power-on, even though the control terminal is in running, the inverter will not self-starting. In order to operate inverter, you should first give a stop signal, then a start-up instruction.

This parameter is used for modifying the present output phase sequence of inverter, which modifies the running motor direction. Control effect of panel control method is shown as following table.



Parameter F0.4 is valid together with direction control of external terminals.

FWD-CM	[F0.6]	Direction
OFF	## 1 #	FWD
ON	## 1 #	FWD
OFF	## 0 0	FWD
OFF	## 0 1	REV
ON	## 0 0	REV
ON	## 0 1	FWD

F0.7 The lower limit frequency

Setting range: 0.0 ~ [F0.8] Hz

F0.8 The upper limit frequency

Setting range: [F0.7] ~600.00Hz

When setting freq. is lower than lower limit freq., the inverter will run in lower limit freq. But the parameters F4.8 and F4.9 are priority over F0.7 and F0.8.

F0.9 Reserved

F0.10	Acc time 1	Setting range : 0.1 ~ 6000 Sec/Min
F0.11	Dec time 1	Setting range : 0.1 ~ 6000 Sec/Min

Acc time 1 is the time of output frequency accelerating from 0.0 Hz to 50.00Hz.
 Dec time 1 is the time of output frequency decelerating from 50.00 Hz to 0.00Hz.
 Units of Acc and Dec are set by parameter F0.12

F0.12	character parameter of Acc and Dec	Setting range: 0000 ~ 0111
-------	------------------------------------	----------------------------

The first part of LED(form right to left): It is used for setting curve type when inverter is accelerating or decelerating, shown as fig6-3.

0: Beeline

Output freq. of inverter will increase or decrease according to fixed rated.

1: S curve

Output freq. of inverter will increase or decrease according to graded rated. Characteristic of S curve is set by parameter F0.13 and F0.14.

The second part of LED: To set Acc/Dec method

0: Output freq. will be modified according to Acc/Dec time.

1: Output freq. will be automatically modified according to load.

The third part of LED:

It is used for setting unit of Acc/Dec time, namely unit of parameters F0.10, F0.11, F4.17, F4.18, F4.19, F4.20, F4.21 and F4.22.

0: Sec.

1: Minute

The fourth part of LED: Reserved




Fig.6-3 Acc/Dec curve

F0.13	Acc/Dec initial section proportion of S curve	Setting range: 10.0 ~ 50.0(%)
F0.14	Acc/Dec ascending/decline section proportion of S curve	Setting range: 10.0 ~ 80.0(%)

Parameters F0.13 and F0.14 define characteristic of S curve. It is totally divide into three sections, shown as fig6-3. Acc/Dec initial section is process that slope of output freq. is gradual increase from 0. The slope will fix in Acc/Dec ascending/decline section. And the slope will gradual decrease to 0 in end section.

F0.15	Load pattern selection	Setting range: 0, 1
-------	------------------------	---------------------

0: General purpose load.

1: Fan and pump load.

F0.16 Carrier wave frequency

Setting range: 1.5 ~ 10.0 KHz

Carrier wave frequency influences audio-frequency noise and calorific effect in running. When environmental temperature is too high and motor's load is too heavy, carrier frequency should be decreased properly to improve the heat thermal performance.

F0.17 Carrier wave characteristics

Setting range: 0000 ~ 1110

It is used for setting correlated characteristics about carrier wave.

The first part of LED (from right to left): Reserved

The second part of LED: Load relating carrier wave adjustment.

If this function is valid, when load current is too high, it will automatically reduce the carrier frequency to ensure operation safety of inverter.

0: Invalid 1: Valid

The third part of LED: Heat relating carrier wave adjustment

If this function is valid, when environmental temperature is too high, the inverter will automatically reduce the carrier wave frequency.

0: Invalid 1: Valid

The fourth part of LED: Freq. relating carrier wave adjustment

If this function is valid, the inverter will automatically reduce the carrier frequency in low-frequency running.

0: Invalid 1: Valid

Attention: When the inverter automatically adjusts carrier freq., the running noise will increase

F0.18 Parameter write-protect

Setting range: 1, 2

It is used for preventing error modify about data.

1: Forbid to modify all parameter, except F0.2 and F0.18

2: Forbid to modify all parameter, except F0.18



Parameter F0.4 is valid together with direction control of external terminals.

6.2 Primary application of parameter unit

The parameter sets [F1.0]-[F1.10] are used for setting V/F curve during V/F control mode. V/F curve type (parameter [F1.0]) can be freely selected and set according to the load type. To solve the defect that the low-frequency torque of V/F control method is insufficient, setting of the torque compensation can boost the output torque, and substantially increase the output voltage value of the inverter to enhance the output current of the inverter; the torque boosting function can be specifically set according to [F1.1]-[F1.2] parameters. Parameters [F1.5]-[F1.10] are used for determining the curve setting during customized output of V/F curve, and please refer to the parameter description for the details

F1.0 Type of V/F Curve

Setting range : 0 ~ 3

0: Constant torque curve

The output voltage of inverter is in direct ratio to the output frequency, and most load take this mode.

1: low-freq. torque curve 1

The output voltage of inverter is conic with the output frequency, which is suited to the fan and pump load.

2: low-freq. torque curve

The output voltage of inverter is conic with the output frequency, which is suited to the constant power load, such as

fan, pump, etc. If there is some unstable phenomenon in light-load running, please switch to run in the decreasing torque curve 1.

3: V/F user-defined curve

It is used for setting user-defined curve which user need




Fig. 6-4 V/F curve

F1.1 Torque Boost(output voltage at 0 Hz) Setting range: 0.0 ~ 20.0 (%)

It is used for improving the low-frequency torque character. In low-frequency running, it will make boost compensation for the output voltage of inverter, as shown in Fig.6-5.

$$\text{Boost voltage} = \frac{[F1.1]}{100} \times [F1.4]$$




Fig.6-5 Torque boost

F1.2 Torque boost pattern Setting range: 0 , 1

0: Manual

Torque boost voltage is completely controlled by F1.1. There are two features: voltage will steady boost. And motor will easily magnetic saturation when light-load.

1: Automatic

Torque boost voltage is changed with the stator current of motor. The boost voltage is higher with the stator current higher.

$$\text{Boost voltage} = \frac{[F1.1]}{200} \times [F1.4] \times \frac{\text{Inverter's output Current}}{2 \times \text{inverter's rated current}}$$

Auto torque boost can prevent the magnetic saturation, as the boost voltage is too high with light load, which can avoid the over-heat phenomenon of motor in low frequency running.

F1.3 Base running frequency	Setting range : 5.00 ~ the upper frequency
F1.4 Max output voltage	Setting range : 200 ~ 500V/100~250V

Basic running frequency is corresponding to minimum frequency when output voltage of inverter is the highest. Usually, it is rated frequency of motor.

Max output voltage is corresponding to output voltage when inverter outputs the basic running frequency. Usually, it is rated voltage of motor.

F1.5 V/F freq. 3	Setting range : F1.7] ~ [F1.3]
F1.6 V/F voltage 3	Setting range: [F1.8] ~ 100%
F1.7 V/F freq. 2	Setting range: [F1.9] ~ [F1.5]
F1.8 V/F voltage 2	Setting range: [F1.10] ~ [F1.6]
F1.9 V/F freq. 1	Setting range: 0.0 ~ [F1.7]
F1.10 V/F voltage 1	Setting range: [F1.1] ~ [F1.8]

Those parameters are used for setting user-defined curve which user need. Shown as Fig.6-6 below:




Fig.6-6 V/Fuser-defined curve

F1.11 DC braking current when starting	Setting range: 0.0 ~ 100.0 (%)
F1.12 DC braking time when starting	Setting range: 0.0 ~ 20.0 S

This functional parameter is used for occasion that the inverter needs braking before starting, and please refer to Fig. 6-7. [F1.11] defines the percentage of DC braking against the rated current of inverter during start of inverter



When rated current of motor is lower than rated current of inverter, please pay attention to set, F1.11. Make sure that DC braking current is lower than rated current of motor

Parameter F1.12 defines duration that inverter output DC braking current. When F1.12 is 0, DC braking is invalid when starting.




Fig.6-7 Process of start and stop

F1.13 Compensate for slip freq.	Setting range: 0.0 ~ 150 (%)
--	-------------------------------------

The actual slip of motor will change with the load change. The inverter, through setting of this functional parameter, will automatically regulate its output frequency according to the load condition to compensate the influence of the load on motor speed. This parameter is only valid for V/F control mode.




Fig.6-8 Compensate for slip freq

F1.14 Droop control	Setting range: 0.0 ~ 100.0 (%)
F1.15 Initial level of droop control	Setting range: 0 ~ 150%
F1.16 Ending level of droop control	Setting range: 10 ~ 200%

Droop control is a special control mode to poise output power when multi-inverters inverter the same load or rotator speed of motor will change with the load. It will poise power and torque by setting those parameters, when multi-inverters inverter the same load. If those parameters are appropriate set, applied asynchronous motor will have the same characteristic with torque motor. Shown as fig6-9.




Fig6-9 Motor characteristic when droop control

They are nameplate parameters of applied motor. The running performance will improve if those parameters are input correctly

F1.17 Droop control mode	Setting range: 0, 1
---------------------------------	----------------------------

Droop control is a special control mode that is used for poising output power when multi-inverters inverter the same load. Output power will decrease automatically when output torque or current of a certain inverter is heavier than usual. Some load will off, so the power will be poised.

The adjustment range of frequency changed with the load will decide by parameters FC.14, FC.15 and FC.16.

0: Absolute droop

$$\text{Actual output freq. of inverter} = \frac{\text{Actual output torque level} - \text{initial level of droop}}{\text{Ending level of droop} - \text{Initial level of droop}} \times \text{Base running frequency [F1.3]}$$

The max of actual freq. of inverter is setting freq..

When setting freq. of inverter is lower than base-running freq., ending level of inverter will reduce to 0 before inverter run to ending level of droop

1: Relative droop

$$\text{Actual output freq. of inverte} = \frac{\text{Actual output torque level} - \text{initial level of droop}}{\text{Ending level of droop} - \text{Initial level of droop}} \times \text{Setting frequency}$$

The max of actual freq. of inverter is setting freq..

If output torque is beyond initial level of droop, output freq. will decrease. When output torque arrives ending level of droop, actual output freq. will reduce to 0

F1.18 Reserved

6.3 Analog I/O parameter unit

F2.0 VC1 input lower limit voltage	Setting range: 0 .0 V ~ [F2.1]
F2.1 VC1 input upper limit voltage	Setting range: [F2.0] ~ 5.0 V

F2.2 VC2 input lower limit voltage	Setting range: 0V ~ [F2.3]
F2.3 VC2 input upper limit voltage	Setting range: [F2.2] ~ 10.0V

F2.2 VC2 input lower limit voltage	Setting range: 0V ~ [F2.3]
F2.3 VC2 input upper limit voltage	Setting range: [F2.2] ~ 10.0V

F2.4 CC input lower limit voltage	Setting range: 0.0 mA ~ [F2.5]
F2.5 CC input upper limit voltage	Setting range: [F2.4] ~ 20.0 mA

F2.6 the min pulse input	Setting range: 0.0 KHz ~ [F2.7]
F2.7 the max pulse input	Setting range: [F2.6] ~ 50.0 KHz

[F2.0] and [F2.1] define the range of analog input voltage channel VC1, and it should be set according to the actual input signal.

[F2.2] and [F2.3] define the range of analog input voltage channel VC2, and it should be set according to the actual input signal.

[F2.4] and [F2.5] define the range of analog input current channel CC, and it should be set according to the actual input signal.

[F2.6] and [F2.7] define the freq. range of external pulse signal

F2.8 frequency with the min setting	Setting range: 0.0Hz ~ [F2.9]
F2.9 frequency with the max setting	Setting range: [F2.8] ~ 600.0Hz

They define the Corresponding relation between analog input (pulse input) and setting frequency. Shown as fig.6-10

F2.10 Character selection of input channel	Setting channel: 0000 ~ 1111
--	------------------------------

It is used for selecting input character of external analog value or pulse value.

The first part of LED (form right to left): It defines character of voltage signal analog input VC1.

0: positive character 1: Negative character

The second part of LED (form right to left): It defines character of voltage signal analog input VC2.

0: positive character 1: Negative character

The third part of LED (form right to left): It defines character of current signal analog input CC.

0: positive character 1: Negative character

The fourth part of LED (form right to left): It defines character of pulse signal analog input PLS.

0: positive character 1: Negative character

The corresponding relation is shown as fig.6-10 between input signal and setting freq




Fig.6-10 Corresponding relation between analog input and setting freq

F2.11 External freq. set time constant of filtering	Setting range: 0.01 ~ 1.00s
---	-----------------------------

Setting freq. set by external analog input will be filtered to eliminate fluctuation. Time constant of filtering have to appropriate set according to fluctuate of external input signal.

F2.12 Combination setting mode	Setting range : 0 ~ 29
--------------------------------	------------------------

The parameter is valid only when the frequency input channel F0.1 is set as 8

The setting frequency of the inverter is determined by the linear combination of multiple frequency input channels, and please see the following table for the combination modes of setting. Frequency output of inverter jointly controlled by multiple channels can be realized through the combination setting.

Setting Value	Combination setting mode	Setting Value	Combination setting mode
0	External voltageVC1 + External current CC	1	External voltageVC1 - External current CC
2	External voltageVC2 + External current CC	3	External voltageVC2 - External current CC
4	External voltageVC1 + External voltageVC2	5	External voltageVC1 - External voltage VC2
6	External voltageVC1 + pulse setting	7	External voltageVC1 - pulse setting

Setting Value	Combination setting mode	Setting Value	Combination setting mode
8	External voltageVC2+ External current CC+ pulse setting	9	External voltageVC2+ External current CC- pulse setting
10	External voltageVC1 + panel setting + pulse setting	11	External voltageVC1+ panel setting - pulse setting
12	External voltage1 + panel setting + digital setting	13	External voltage1 - panel setting + digital setting
14	External voltage2 + panel setting + digital setting	15	External voltage2 - panel setting + digital setting
16	External current + panel setting + digital setting	17	External current - panel setting + digital setting
18	Serials interface setting + External voltage1	19	Serials interface setting - External voltage1
20	Serials interface setting + External current + pulse setting	21	Serials interface setting - External current + pulse setting
22	Serials interface setting + External voltage1 + panel setting	23	Serials interface setting + External voltage2 - panel setting
24	External voltage2 + External current + pane setting	25	External voltage2+ External current - panel setting + digital setting
26	The max of external voltage1 and external voltage2	27	The max among External voltage1, External voltage2 and
28	Nonzero valid of External voltage1and External voltage2	29	Nonzero valid External voltage1, External voltage2 and External current CC
30		External voltage 1+external terminal vp/dw	

F2.13 Analog output selection

Setting range: 0000 ~ 0055

It defines meaning of AO1、AO2.

The first part of LED: it defines the meaning of analog output terminal AO1.

The second part of LED: it defines the meaning of analog output terminal AO2.

0: Output freq

Amplitude accumulation of AO1 and AO2 are in direct ratio to the output frequency. F2.15 and F2.17 are corresponding to the upper limit freq.

1: Output current

Amplitude accumulation of AO1 and AO2 are in direct ratio to the output current. F2.15 and F2.17 are twice rated current of inverter.

2: Output voltage

Amplitude accumulation of AO1 and AO2 are in direct ratio to the output voltage. F2.15 and F2.17 are corresponding to [F1.4] and [F1.14].

3: Rotate speed of applied motor

Amplitude accumulation of AO1 and AO2 are in direct ratio to the motor rotate speed of inverter. F2.15 and F2.17 is corresponding rotate speed that is corresponded the upper limit freq.

4: PID setting

Amplitude accumulation of AO1 and AO2 are in direct ratio to the setting value of PID. F2.15 and F2.17 are corresponding to feedback of 10.00.

5: PID feedback

Amplitude accumulation of AO1 and AO2 are in direct ratio to the PID feedback. F2.15 and F2.17 are corresponding to feedback of 10.00.

The third and fourth part of LED: Reserved.

F2.14	the lower limit of analog output AO1	Setting range: 0.0 V/0.0mA ~ [F2.15]
F2.15	the upper limit of analog output AO1	Setting range: [F2.14] ~ 12.0 V/24.0mA

F2.16	the lower limit of analog output AO2	Setting range: 0.0Hz ~ [F2.9]
F2.17	the upper limit of analog output AO2	Setting range: [F2.16] ~ 12.0 V/24.0mA

Those parameters define the max and min value of analog output AO1 and AO2, shown as fig 6-11





Fig.6-11 output of analog terminals

AO1 and AO2 provide voltage signal from 0 to 12V or current signal from 0 to 24 mA. Two kinds of output signal can be selected by JP (JP1 and JP2) switch. JP1 and JP2 are shown as fig.6-12



- JP2:
- 1-2 shorted: AO1 output voltage signal;
 - 2-3 shorted: AO1 output current signal;
- JP3:
- 1-2 shorted: AO2 output voltage signal
 - 2-3 shorted: AO2 output voltage signal

Fig.6-12 JP2/JP3 terminal

F2.18	Reserved
-------	----------

6.4 Digital O/I parameter unit

F3.0	Function selection of input terminal 1	Setting range: 0 ~ 26
F3.1	Function selection of input terminal 2	Setting range: 0 ~ 26
F3.2	Function selection of input terminal 3	Setting range: 0 ~ 26
F3.3	Function selection of input terminal 4	Setting range: 0 ~ 26
F3.4	Function selection of input terminal 5	Setting range: 0 ~ 26
F3.5	Function selection of input terminal 6	Setting range: 0 ~ 26

- 0: Control terminal is idle
- 1: Multi-speed control terminal 1
- 2: Multi-speed control terminal 2
- 3: Multi-speed control terminal 3
- 26: Multi-speed control terminal 4

Combination of multi-speed control terminals is used for selecting output freq. of multi-speed.

- 4: Wobble freq. is valid

When F7.0 is ###2 and any of those parameters is set 4, wobble freq. is valid.

- 5: State of wobble freq. reset

When inverter is stop and F7.0 is ##0#, forcible reset will work by setting those parameters.

- 6: FWD jog control

- 7: REV jog control

When F0.4 is ###1 and any of those parameters is set 6 or 7, external jog signal is valid.

- 8: Acc& Dec time selection terminal 1

- 9: Acc& Dec time selection terminal 2

They are used for selecting external terminals Acc/Dec time 1~4.

- 10: Freq. setting channel selection 1

- 11: Freq. setting channel selection 2

- 12: Freq. setting channel selection 3

When F0.1 is 9, Frequency input channel is set by terminals state of 10, 11 and 12. See the explanation about parameter F0.1.

- 13: Freq. is controlled gradually increase (UP)

- 14: Freq. is controlled gradually decrease (DW)

- 15: UP-DW freq. clear

When F0.3 is ##0#, one of terminal X1~X6 defined by this parameter has function of forcible clear.

- 16: Uncontrolled stop control

If one of terminal X1~X6 defined by this parameter is connected with CM, the inverter will lock output signal and applied motor will uncontrolled stop. Then inverter will detect speed and restart after terminal is disconnected with CM.

- 17: Fault signal of peripheral equipment input

When one of terminal X1~X6 is defined by this parameter is connected with CM, peripheral equipment is fault. The inverter will lock output signal and display FU.16.

- 18: Three-line mode running control

When F0.5 is 2, one of external terminal X1~X6 defined by this parameter is stop trigger switch of inverter. See explanation about F0.5.

- 19: DC braking control

When inverter stops and one of external terminals X1~X6 defined by this parameter is connected with CM and output freq. is lower than Initial freq. of DC braking, function of DC braking is valid until terminal is disconnected with CM. Refer to explanation about F4.4~F4.7.

- 20: Inner counter clear

- 21: Inner counter timer

Only terminal X6 is used for Inner timer, namely parameter F3.5 is 21.

- 22: PLC running valid

When F5.0 is ###2 and any of those parameters is set 22, PLC running is valid.

- 23: PID running valid

When F8.0 is ###2 and any of those parameters is set 23, PID running is valid.

- 24: Internal timer trigger terminal

The terminals is defined to be the internal timer trigger terminal


- 25: PLC state reset after stopping

If F5.0 is set as #1##, the PLC state will keep fix. But external terminals will force reset, which is set by this function.

F3.6	Output terminal OC1	Setting range: 0 ~ 18
F3.7	Output terminal OC2	Setting range: 0 ~ 18
F3.8	TA, TB and TC of relay contacts	Setting range: 0 ~ 18

It defines expression content of relay contact and terminals OC1 and OC 2 when collector is open-circuit. Shown as fig.6-13.

When TA is on with TC, setting functions will available



While connecting the externa inductance cell (For example, Relaycoil), it must connect the parallel fly-wheel diode D

Fig.6-13 Inner wiring diagram of output terminals

0: In the running

When the inverter is in the running state, it will output the valid signal. While the inverter is in stop mode, it will output the invalid signal.

1: Frequency reaching

When the output frequency of inverter approaches the certain range of the setting frequency. (The range is decided by parameter F3.9), it outputs valid signal, otherwise, outputs the invalid signal (High-resistance).




Fig.6-14 Freq. reaching signal

2: Freq. level detection signal (FDT)

When the output frequency of inverter is over FDT Frequency level, the inverter will output the valid signal (Low electrical level) after the setting delay time. When the output frequency of inverter is lower than FDT frequency level, after the same delay time, it will output the invalid signal (High resistance).




Fig. 6-15 Freq. level detection signal (FDT)

3: Over-loading alarm

When the output current of inverter is over the over-loading alarm level, it will output the valid signal (Low level) after the setting alarm delay time. When the output current is lower than the over-loading alarm level, it will output the invalid signal (High resistance) after the same delay time.




Fig.6-16 Over-load alarm

4: External fault halt

When the external fault input signal is valid and it will lead to stop-machine, the terminal will output the valid signal (Low level); otherwise it will output the invalid signal (High resistance).

5: Output frequency reaches the upper-limit

When the output frequency reaches the upper-limit frequency, the terminal will output the valid signal (Low level). Otherwise, it will output the invalid signal (High resistance).

6: Output frequency reaches the lower-limit

When the output frequency reaches the lower-limit frequency, the terminal will output the valid signal (Low level). Otherwise, it will output the invalid signal (High resistance)

7: Running in zero speed

Running instruction is valid and output freq. is 0, if inverter is input freq., the terminal will output the valid signal (Low electrical level). If inverter is not input freq., the terminal will output the invalid signal (High resistance).

8: Internal timer reaches the setting time

When the internal timer reaches the setting time, the terminal will output the valid pulse signal of 0.5 Sec pulse widths. (Low electrical level)

9: PLC stage is end of run

When simple PLC is valid and current stage is end, this port will output pulse signal with 0.5s pulse width.

10: PLC periodic is end of run

When simple PLC is valid and current period is end, this port will output pulse signal with 0.5s pulse width.

11: Internal timer arrive regular time

If the internal timer arrive regular time, the corresponding port will output 0.5s width pulse signal.

12: Setting value of counter arrives

See the explanation about parameter F6.3

13: Designated value of counter arrives

See the explanation about parameter F6.4.

14: Deceleration running

15: Reserved

16: Inverter fault

When inverter is running with fault, it will output available signal (low level).

17: Restrictions on wobble freq. of the upper and lower limit freq.

When parameters setting about wobble freq. result in that running freq. is beyond the upper and lower limit freq., this port will output available signal (lower lever). Generally, this port output high resistance.

18: Reserved

F3. 9 Frequency reach the checkout amplitude

Setting range: 0.0 ~ 20.00Hz

If output freq. of inverter is within setting value that is set by F3.9, selected terminal will output valid signal. Shown as fig.6-15

F3.10	FDT setting 1	Setting range: 0.0 ~ upper limit freq.
F3.11	FDT output delay time 1	Setting range: 0.0 ~ 200.0 s
F3.12	FDT setting 2	Setting range: 0.0 ~ Setting range
F3.13	FDT output delay time 2	Setting range: 0.0 ~ 200.0 s

The parameter is used for setting the frequency detection level. When output frequency is higher than the setting value of FDT, after the setting delay time, terminals will output the valid signal, shown as fig.6-15. Parameters F3.10 and F3.11 are used for setting FDT of OC1, parameters F3.12 and F3.13 are used for setting FDT of OC2

F3.14	Overload alarm level	Setting range: 50 ~ 200 (%)
F3.15	Overload alarm delay time	Setting range: 0.0 ~ 20.0s

If output freq. beyond the setting value set by parameter F3.14, after the setting delay time set by parameter F3.15, terminals output valid signal, shown as fig.6-16

F3.16	Reserved
-------	----------

6.5 Auxiliary running parameter unit

F4.0	Start mode	Setting range: 0~1
F4.1	Start frequency	Setting range: 0.0~10.00Hz
F4.2	Start frequency duration	Setting range: 0.0~20.0s

Those parameters are used for defining characteristic with relation to start mode, shown as fig6-17. The explanation of F4.0 is shown as follows.

0: Routine mode

It is fit for mostly load, which have not special demand.

1: Detect speed and restart

It is fit for fault reset and restart occasion, or, power off and restart occasion. Inverter will judge automatically running speed and direction of motor. Motor, which have not stop, will start up directly according to detect result.

Start frequency: It is fit for system, which are big inertia, heavy load and high start torque




Fig6-17 Start and stop freq output curve

F4.3	Stop mode	Setting range: 0 ~ 1
------	-----------	----------------------

0: Decelerate mode

Inverter will gradually decrease output freq. to 0 according to Dec time when stopping.

1: Uncontrolled stop

Inverter will output zero freq. and lock output signal when stop, so motor will uncontrolled stop.

If user needs restart motor before motor complete stop, function of detect speed and restart must be valid when inverter is uncontrolled stop.

Start mode and stop mode is shown as fig6-16

F4.4	Initial freq. of DC braking when stopping	Setting range: 0.00 ~ 50.00 Hz
F4.5	Waiting time of DC braking when stopping	Setting range: 0.0 ~ 5.0 S
F4.6	Action time of DC braking when stopping	Setting range: 0.0 ~ 20.0 S
F4.7	DC braking current when stopping	Setting range: 0.0 ~ 100 (%)

It is used for setting DC braking parameters when stopping, shown as fig6-7.

When output freq. is lower than setting freq. of Parameter F4.4, inverter will lock output and start DC braking function after waiting setting time of parameter F4.5. DC braking when stopping is invalid while F4.6 is 0.

DC braking current when stopping is the percentage of rated current of inverter. When capability of applied motor is lower than inverter capability, please be sure to set F4.7

F4.8	Running threshold of zero freq	Setting range: 0.00 ~ 100.00 (Hz)
F4.9	Return different of zero freq	Setting range: 0.00 ~ 50.00 (Hz)

Those parameters define characteristic of freq. zero-crossing.

When inverter takes analog input freq. to set freq., analog signal will fluctuate around zero to cause astable input. Those parameters have lagging function to avoid fluctuating around zero. Appropriate set

Function of sleep and awakening will be work, if those parameters are appropriate set. For example analog input channel VC2 is shown as fig6-18




Fig6-18 freq. zero-crossing curve

F4.10 FWD jog frequency Setting range: 0.0 ~ Upper limit

Jog running is special running method of inverter.

Whatever the initial state of inverter is stop or run, jog signal will be received. The transition from initial running freq. to jog freq. is ac8 according to parameters F4.21 and F4.22




Fig6-19 Jog running

F4.10 FWD jog frequency Setting range: 0.0 ~ Upper limit

It is used for setting permissible output level of torque current under motor acceleration state.

The restriction on torque level is set by F4.11. It is percentage of rated current of inverter. For example, F4.11 set 150% that means the max output current is 150 percentage of rated current.

When output current of inverter is beyond setting value of F4.11, inverter will prolong Acc/Dec time to inhibit output current in setting value of F4.11. Shown as fig6-20.




Fig6-20 Acc torque level

F4.12 Motor over-load protection coefficient**Setting range: 50 ~ 110 (%)**

The parameter is used for setting the sensitivity of thermal relay protection for applied motor. When the rated current of applied motor doesn't match with the rated current of inverter, it can accomplish the correct heat protection for the motor to set this parameter.

The setting value of this parameter can be set by the following formula:

$$[F4.12] = \frac{\text{Rated current of motor}}{\text{Inverter's rated output current}} \times 100\%$$



While one inverter parallel running with multi-motors, the thermal relay protection of inverter will be invalid, in order to protect the motor, please install the thermal relay on inlet terminals the motor.

F4.13 Automatic voltage regulation (AVR)**Setting range: 0 ~ 3**

The function of Automatic voltage regulation is to ensure the output voltage of inverter not to fluctuate with the input voltage. When the range of fluctuation of power supply voltage is too heavy, and expect to motor have the stabilized stator voltage and current, this function should be open.

0: Invalid 1: Dynamic valid 2: Static valid 3: Deceleration invalid

When user selects dynamic voltage regulation, fast dynamic voltage regulation can inhibit form increasing current cause by DC voltage in motor deceleration. But it easy brings current resonance.

In acceleration and stabilization state, automatic voltage regulation is valid; but in deceleration state, it is invalid.

F4.14 Energy-saving running**Setting range: 0 ~ 1**

0: valid 1: Invalid

When F4.15 is 0, inverter will check motor load automatically and real-time rectify output voltage.

Energy-saving running works high efficiency under occasions that the range of freq. is small and the range of speed is wide.

Because fan or pump has a specific relationship with rotation speed, it cans compendiary judge load state according output freq. Low-freq. torque curve V/F is a typical example in energy-saving running. When user takes low-freq. torque curve (F0.1 is 1 or2), function of energy-saving running needn't valid.

F4.15 Intensity of energy-saving running**Setting range: 30 ~ 90**

It is used for setting the voltage regulating strength in energy-saving running. When inverter is in energy-saving running state, output voltage will be automatically adjusted with load, to enable the motor running in the most efficient state.

If the parameter is set larger, the energy-saving effect is better, and the running stability will be worse. The client can set the parameter according to currently state

F4.16 Dead time of FWD&REV**Setting time: 0.0 ~ 5.0 Sec**

The parameter means that the duration at zero frequency when the inverter changes its running direction, and it is shown as the following fig.6-20. FWD and REV dead time is set for the big inertia load which has the mechanical dead zone.




Fig.6-21 Dead zone between FWD and REV

F4.17	Acceleration time 2	Setting range: 0.1 ~ 6000 Sec
F4.18	Deceleration time 2	Setting range: 0.1 ~ 6000 Sec
F4.19	Acceleration time 3	Setting range: 0.1 ~ 6000 Sec
F4.20	Deceleration time 3	Setting range: 0.1 ~ 6000 Sec
F4.21	Acc time 4/Jog Acc time	Setting range: 0.1 ~ 6000Sec
F4.22	Dec time 5/Jog Dec time	Setting range: 0.1 ~ 6000Sec

Jog frequency has the highest priority. In any state, as long as Jog instruction is input, the inverter will transit to run at Jog frequency according to the setting Acc and Dec time.




Fig.6-22 Acc/Dec time selection

F4.23	Modified rated of UP/DW terminals	Setting range: 0.01 ~ 100.00 (Hz/Sec)
-------	-----------------------------------	---------------------------------------

It defines rate that terminals UP/DW modify setting freq. Speed of F4.23 isn't controlled by Acc/Dec time

F4.24	Start voltage of dynamic braking	Setting range: 600 ~ 750 V
F4.25	Action ratio of dynamic braking	Setting range: 10 ~ 100 (%)

Those parameters are valid for inverter with the inner brake unit. And they define the action parameter of inner brake unit. When inner DC voltage of inverter is higher than the start voltage of dynamic braking, the inner brake unit will act. If inverter connects external brake resistance, DC energy of inverter will be release by it to decline DC voltage. When DC voltage declines to the certain value ([F4.24]-50V), inner brake unit of inverter will be off, shown as Fig.6-23.

Brake unit action ratio is used for defining the voltage on brake resistor, and the voltage on brake unit is Voltage PWP. Duty cycle equals break action ratio. The ratio is larger, and the energy is consumed more quickly, at the same time, the power of brake resistor is bigger. User can set parameter according to the resistance and power of resistor and actual brake effect.




Fig.6-23 dynamic braking

F4.26 Restart after power down setting	Setting range: 0000 ~ 0011
F4.27 waiting time of restart after power down	Setting range: 0.0 ~ 10.0s

Parameter F4.26

The first part of LED

0: Invalid 1: Valid

When restart after power down setting is invalid, the inverter will clear automatically all running command and run according to new command after power on.

When restart after power down setting is valid, the inverter will save all running command and run according to the save command after power on.

Please make sure that other equipments in system are ready before using function of restart after power Down.

The second part of LED:

Applied motor is still running when user select restart. Here, users have to select function of checking speed and restarting.

The third and fourth part of LED: reserved.

F4.28 REV jog frequency	Setting range: 0.0 ~ Upper limit
-------------------------	----------------------------------

6.6 Multi-speed running parameter unit

F5.0 Multi-speed running mode	Setting range: 0000 ~ 1252
-------------------------------	----------------------------

F5.1 Multi-speed frequency 1	Setting range: 0.0 ~ the upper limit freq
F5.2 Multi-speed frequency 2	Setting range: 0.0 ~ the upper limit freq
F5.3 Multi-speed frequency 3	Setting range: 0.0 ~ the upper limit freq
F5.4 Multi-speed frequency4	Setting range: 0.0 ~ the upper limit freq
F5.5 Multi-speed frequency 5	Setting range: 0.0 ~ the upper limit freq
F5.6 Multi-speed frequency 6	Setting range: 0.0 ~ the upper limit freq
F5.7 Multi-speed frequency 7	Setting range: 0.0 ~ the upper limit freq
F5.8 Multi-speed frequency8	Setting range: 0.0 ~ the upper limit freq
F5.9 Multi-speed frequency 9	Setting range: 0.0 ~ the upper limit freq
F5.10 Multi-speed frequency 10	Setting range: 0.0 ~ the upper limit freq
F5.11 Multi-speed frequency 11	Setting range: 0.0 ~ the upper limit freq
F5.12 Multi-speed frequency12	Setting range: 0.0 ~ the upper limit freq
F5.13 Multi-speed frequency 13	Setting range: 0.0 ~ the upper limit freq
F5.14 Multi-speed frequency 14	Setting range: 0.0 ~ the upper limit freq
F5.15 Multi-speed frequency 15	Setting range: 0.0 ~ the upper limit freq

F5.16 Running time of Multi-speed1	Setting range: 0.0 ~ 6000s
F5.17 Running time of Multi-speed2	Setting range: 0.0 ~ 6000s
F5.18 Running time of Multi-speed3	Setting range: 0.0 ~ 6000s
F5.19 Running time of Multi-speed4	Setting range: 0.0 ~ 6000s
F5.20 Running time of Multi-speed5	Setting range: 0.0 ~ 6000s
F5.21 Running time of Multi-speed6	Setting range: 0.0 ~ 6000s
F5.22 Running time of Multi-speed7	Setting range: 0.0 ~ 6000s
F5.23 Running time of Multi-speed8	Setting range: 0.0 ~ 6000s

F5.24 Running direction of PLC multi-speed
 F5.25 Running direction of PLC multi-speed

Setting range: 0000 ~ 1111
 Setting range: 0000 ~ 1111

Parameter F5.0 is multi-speed running mode. It is used for setting basic characteristic of multi-speed running.


The first part of LED(form right to left): Simple PLC selection

0: Simple PLC is invalid.

1: Simple PLC is valid. If priority of freq. channel is permit after starting, inverter will run at simple PLC state

2: Simple PLC is conditional valid. If external X1~X6 terminals is valid (F3.0~F3.5 is set as 22), inverter will run at simple PLC state.

Priority of freq. channel is shown as following table:

Priority grade	Priority	Setting freq
High  Low	1	JOG freq.
	2	Wobble freq. running
	3	PID output
	4	PLC multi-speed freq
	5	External terminals select multi-speed freq
	6	Freq. setting channel selection (Parameter [F0.1])

The second part of LED: Simple PLC running mode selection

0: Single loop mode

The inverter will run in setting freq of the first stage and in turn output freq. of each stage according to setting running time. If setting running time of a certain stage is 0, the inverter will skip this stage. When a cycle operation is end of run, inverter will stop input until user input available running instrument to restart a next cycle.

1: Single loop and stop mode

Its function has an analogy with single loop mode. The difference is that output freq. is be reduced to 0 within the given decelerate time after a certain stage is end of run and inverter will run next stage.

2: Continuous loop mode

Inverter will run eight stages in turn. If the eighth stage is end of run, the inverter will run the next cycle form the first stage.

3: Continuous loop and stop mode

Its function has an analogy with Continuous loop mode. The difference is that output freq. is be reduced to 0 within the given decelerate time after a certain stage is end of run and inverter will run next stage.

4: Keep the end value

Its function has an analogy with single loop mode. The difference is that inverter will run in the last stage with non-zero speed.

5: Keep the end value and stop mode

Its function has an analogy with keep the end value. The difference is that inverter will reduce the output freq. to 0 after arriving setting value of Acc time after a certain stage is end of run and, then inverter will run the next stage

The third part of LED

0: Restart from the first stage freq.

When inverter stop, caused by fault or receiving stop instrument in PLC running, it will clear current running state and restart form the first stage freq.

1: Restart from running freq., which is saved before the running is breaking.

When inverter stop, caused by fault or receiving stop instrument in PLC running, inverter will restart from running time and freq. that is saved before the running is breaking.

2: Restart from setting freq. when the running is breaking.

When inverter stop, caused by fault or receiving stop instrument in PLC running, setting of running time and freq. of a certain stage will be saved. And inverter will restart form setting of running time and freq. the different between mode 1 and mode 2 is initial freq. Shown as fig6-24.

The fourth part of LED: PLC save state

0: Non-save after power off

It will not be saved PLC running state after power off. Inverter will run form the stage 1 when power is on.

1: Save after power off

It will save PLC running state after power off. Inverter will run form the stage 1 when power is on




Fig.6-24 a PLC recover running after restart




Fig.6-24 b PLC recover running after restart

[F5.1]~[F5.15] Multi-speed freq.1~15

Those parameters are used for setting output freq. of multi-speed.

[F5.16]~[F5.23] Running time of Multi-speed 1~8

Those parameters are used for confirming running time of each stage.

F5.24)、 [F5.25] Running direction of PLC multi-speed

Those parameters are used for defining running direction of PLC multi-speed
[F5. 24]

The first part of LED(form right to left):

- | | |
|----------------|----------------|
| 0: Stage 1 FWD | 1: Stage 1 REV |
| 0: Stage 2 FWD | 1: Stage 2 REV |
| 0: Stage 3 FWD | 1: Stage 3 REV |
| 0: Stage 4 FWD | 1: Stage 4 REV |

The first part of LED(form right to left):

- | | |
|----------------|----------------|
| 0: Stage 5 FWD | 1: Stage 5 REV |
| 0: Stage 6 FWD | 1: Stage 6 REV |
| 0: Stage 7 FWD | 1: Stage 7 REV |
| 0: Stage 8 FWD | 1: Stage 8 REV |

F5.26 PLC timing running shutdown

Setting range: 0000~9999min

When PLC multi-speed running function is valid, it is used for setting PLC multi-speed running, beyond the time, it will automatically shutdown. To recovery operations, first give a shutdown instruction, and then give a start-up instruction. When the parameter equals 0, timing running shutdown function is invalid.

6.7 Advanced running parameter unit

F6.0 interna timer	Setting range: 0.1 ~ 6000.0 Sec
--------------------	---------------------------------

It is used for setting the internal timer. The internal timer is triggering start-upped by external terminals X1~X6, external terminals X1~X6 should be set as 24(explained by parameters F3.0~F3.5). Internal timer arrives the regular time, OC1、OC2 or TA, TB, TC will output 0.5s width pulse (set by F3.6~F3.8)
The function can realize the timing operation shutdown.

F6.1 Fault self-recovery time	Setting range: 0 ~ 2
F6.2 Interval time of fault self-recovery	Setting range: 0.2 ~ 20.0s

F6.1 is used for resetting some faults and run again
F6.2 defines interval time between fault starting and fault recovery. If inverter can't recover in setting value of F6.1, it will output fault signal. Inverter will check speed and restart.



Inverter can't self-recovery about overheat or overload protect

F6.3 Final value setup of internal counter	Setting range: 1 ~ 60000
F6.4 Internal timer setup	Setting range: 1 ~ 60000

The parameter defines the counting action of internal counter, and the clock terminals of counter are selected by parameter F1.6.
The counting value of counter for the external clock reaches the value appointed by parameter F3.5, and the corresponding Terminal OC outputs a valid signal of same width with the external clock cycle.
When the counting value of counter for external clock reached the value appointed by Parameter F6.3, the corresponding Terminal OC will output the valid signal, Go on counting to the value provided by parameter F6.4, which will lead to reset and the output valid signal will be withdrawn.
The clock cycle of counter should be over 5ms and the min width should be 2ms




Fig.6-25 Internal counter function

F6.5 Skip freq. 1	Setting range: 0.0 ~ upper frequency
F6.6 Amplitude accumulation of Skip freq. 1	Setting range: 0.0 ~ 5.00Hz
F6.7 Skip freq.2	Setting range: 0.0 ~ upper frequency
F6.8 Amplitude accumulation of Skip freq.	Setting range: 0.0 ~ 5.00Hz

It is used for avoiding resonance point of mechanical load. Shown as fig. 6-26




Fig.6-26 Skip freq

F6.9 Linear speed coefficient setting

Setting range: 0.01 ~ 100.0

This parameter is used for confirming the display value of running linear speed and setting linear speed, and displaying other value being positive ratio with the output frequency.

$$\begin{aligned} \text{Running linear velocity (d.10)} &= [\text{F6.9}] \times \text{output frequency (d.0)} \\ \text{Setting linear velocity (d.11)} &= [\text{F6.9}] \times \text{Setting frequency (d.6)} \end{aligned}$$

F6.10 close-loop analog coefficient setting

Setting range: 0.01 ~ 100.0

$$\begin{aligned} \text{PID feedback value (d.9)} &= [\text{F6.10}] \times \text{actual feedback value} \\ \text{PID setting value (d.8)} &= [\text{F6.10}] \times \text{setting value} \end{aligned}$$

F6.11 rotator speed coefficient setting

Setting range: 0.01 ~ 10.00

It is used for rectifying the display value of rotator speed.

$$\text{rotator speed (d.3)} = [\text{F6.11}] \times \text{actual output rotator speed}$$

F6.12 Monitor item selection 1 / Main display

Setting range: 0 ~ 11

F6.13 Monitor item selection 2 / Auxiliary display

Setting range: 0 ~ 19

This parameter is used for confirming display content of operation panel in state monitor mode.

F6.14 Query or modify parameters

Setting range : 0 ~ 9999

It is used for getting check code to query or modify parameters.

F6.15 parameter initialization

Setting range: 0 ~ 3

It is used for modifying inverter's parameters to manufacture setting.

0: Parameter initialization is off.

1: Parameter initialization is on.

Parameter F0~F9 return to manufacture setting. The following parameters can't be initialized:

- [F0.0]: Reserved
- [F0.1]: Frequency input channel / mode selection
- [F0.4]: Operation channel selection
- [F6.17]: Manufactory password
- [F6.18]: User password
- [F6.19]: Reference password

2: Clean fault records

3: Complete initialization

Except the following parameters, Parameters F0 ~ FC return to manufacture setting and clean fault records.

- [F0.0]: Reserved
- [F6.17]: Manufactory password
- [F6.19]: Reference password
- [FC.3]: Reserved
- [FC.4]: Reserved
- [FC.8]: Agency password
- [FC.13]: Program version

F6.16 Copy parameter function

Setting range: 0 ~ 1

0: Forbid

It is forbidden to copy the backup data form operation panel to inverter, but this function doesn't affect the copy and read parameter function.

1: Allow

F6.17 manufactory password

Setting range: 0 ~ 9999

Don't modify this parameter without our permission.

F6.18 user password

Setting range: 0 ~ 9999

It is used for getting some special power for user.

F6.19 reference password

Setting range: 0 ~ 9999

It is always random number.

6.8 wobble freq. running parameter unit

F7.0 wobbles freq. running mode

Setting range: 0000~1112

It is always random number

It is used for setting basic characteristic of wobble freq. running

The first part of LED (form right to left) :

0: Function of wobble freq. is invalid.

1: Function of wobble freq. is valid.

When inverter receives running instruction, inverter will run in setting freq. of F7.1. Then inverter will in wobble freq. running mode after arriving setting time of F7.2.

2: Function of wobble freq. is conditional valid.

When external input terminals are valid (namely one of F3.0~F3.5 is 4), the inverter will run in wobble freq. running mode. When external input terminals are invalid, the inverter will run in preset freq. of wobble freq. (F7.1)

The second part of LED: restart mode

0: Restart according to parameters saved before stop

1: Restart

The third part of LED: wobble freq. characteristic (See explanation about parameter F7.3)

0: The wobble freq. is fixed

1: The wobble freq. is changeable.

The fourth part of LED: Storage characteristic of wobble freq.

0: It will not save the running state of wobble freq. after power off

1: It will save the running state of wobble freq. after power off

F7.1 Preset freq. of wobble freq.

Setting range: 0.0 ~ the upper limit freq.

F7.2 waiting time of preset freq.

Setting range: 0.0 ~ 6000.0s

Preset freq. of wobble freq. is running freq. before inverter is in or out wobble freq. mode.

When [F7.0]=###1, inverter will start and run in preset freq. of wobble freq., then run in wobble freq. mode after the setting time of F7.2.

When [F7.0]=###2 and the terminals of wobble freq. is valid (F3.0~F3.5 is 4), the inverter will run in wobble freq. mode. When [F7.0]=###2 and the terminals of wobble freq. is invalid, inverter will output preset freq. [F7.1].

F7.3 Amplitude of wobble freq.

Setting range: 0 ~ 50.0 %

F7.3 is rate of amplitude of wobble freq. When F7.0 is [F7.0]=#0##,

Amplitude of wobble freq. = [F7.3] × the upper limit freq. [F0.8] When F7.0 = #1##,

Amplitude of wobble freq. = [F7.3] × (Preset center freq. of wobble freq. [F7.7] + External setting freq.)

F7.4 Jumping freq.

Setting range: 0.0 ~ 80.0 %

When freq. arrives the upper limit freq., the freq. will fast decline. Or when freq. arrives the lower limit freq., the freq. will fast ascend. Jumping freq. is amplitude, which freq. is ascending or decline. Shown as fig6-27

Actual jumping freq. = [F7.4] × Amplitude of wobble freq. [F7.3]

F7.5 Triangular rise time

Setting range: 0.1 ~ 1000.0 s

F7.6 Triangular fall time

Setting range: 0.1 ~ 1000.0 s

F7.5 defines the running time form lower limit freq. to upper limit freq. of wobble freq., namely Acc time F7.5 defines the running time form upper limit freq. to lower limit freq. of wobble freq., namely Dec time The sum of F7.5 and F7.6 is running cycle of wobble freq.



F7.5 and F7.6 define slope of Acc and Dec in wobble freq.

F7.7 Preset center freq. of wobble freq.

Setting range: 0.0 ~ upper limit freq

Center freq. of wobble freq. is central value of output freq. when inverter is in wobble freq. mode. The sum of setting value of F7.7 and F0.1 is actual center freq.

Running process of wobble freq. is shown as fig6-28




Fig.6-27 Running process of wobble freq




Fig.6-28 Running process of wobble freq

F7.8 Reserved

6.9 PID control parameter unit

F8.0 Inner PID control

Setting range: 0000 ~ 1122

The first part of LED (from right to left): Inner PID control

0: Inner PID control is invalid 1: Inner PID control is valid

2: Inner PID control is conditional valid. Inner PID is set by external terminals X1~X6 (Parameters F3.0~F3.5)

The second part of LED: PID controller selection

0: proportion 1: Integral 2: Proportion and integral

The third part of LED: Regulating property of PID controller

0: positive interaction 1: Reactor

The fourth part of LED: reserved

F8.1 inner PID setting and channel selection

Setting range: 0000 ~ 5705

It is used for setting inner PID and feedback channel.

The first part of LED (from right to left): It is used for setting PID channel .

0: Digital setting. It is set by parameter F8.2.

1: Serials interface setting

2: Panel potentiometer setting, it is on the operation panel.

3: External voltage signal VC1 (0V~5V)

4: External voltage signal VC2 (0V~10V)

5: External current signal CC (0~20mA)

The second part of LED: Reserved.

The third part of LED: It is used for setting PID feedback channel.

0: External voltage input VC1 is as feedback channel, which is in the range of 0~5V.

1: External voltage input VC2 is as feedback channel, which is in the range of 0~10V.

2: External current input CC is as feedback channel, which is in the range of 0~20mA.

3: Pulse input PLS is as feedback channel, which is in the range of 0~50 KHz.

4: VC1+CC Feedback value is composed of VC1 and CC

5: VC1-CC Feedback value is that VC1 minus CC.

6: Min (VC1, CC) Feedback value is min value between VC1 and CC

7: Max (VC1, CC) Feedback value is max value between VC1 and CC

The fourth part of LED: Reserved

F8.2 Inner PID close-loop digital setting

Setting range: 0.0 ~ 10.00V

If F8.1 is 0#00, setting value will be set by F8.2.

F8.3 Minimum fixed value

Setting range: 0.0 ~ [F8.4]

F8.4 Maximum fixed value

Setting range: [F8.3] ~ 10.00

F8.5 Feedback of minimum fixed value

Setting range: 0.0 ~ 10.00

F8.6 Feedback of maximum fixed value

Setting range: 0.0 ~ 10.00

Parameters F8.3 and F8.4 define the upper and lower limit value of PID setting. Parameters F8.5 and F8.6 define corresponding relation with PID feedback value. Shown as fig.6-29




Fig.6-29 Relation between PID fixed value and expected feedback value

F8.7 Proportion gain

Setting range: 0.0 ~ 5.00

F8.8 Integral time constant

Setting range: 1.0 ~ 100 Sec

Those parameters are inner parameter of PID.

F8.9 Allowable deviation limit

Setting range: 0.0 ~ 20.0(%)

The parameter is the allowable deviation value relative to the setting max value. When the difference between feedback value and the setting value is lower than this setting value, PID controller will stop. Shown as fig.6-30.

This function is mainly suited for the system that has lower control precision and needs to avoid adjusting frequently, for example, water-supply with constant pressure system.




Fig.6-30 PID Control allowable deviation limit

F8.10 Preset freq. for close-loop

Setting range: 0.00 ~ the upper limit freq.

F8.11 Holding time of preset freq. for close-loop

Setting range: 0.0 ~ 6000.0s

Those parameters define freq. and running time of inverter before actual PID control is valid. In some control systems, inverters will forcible output a certain freq. (F8.10) and keep it in setting time (F8.11) for controlled object arrives fast targeted value. When controlled object almost arrives targeted value, PID controller will be valid to improve response speed.

F8.12 long-distance manometer range

Setting range: 0.00~20.000Mpa

It defines measuring range of long-distance manometer, user have to input it.

F8.13 Sleeping threshold	Setting range: [F8.14]~[F8.12]
--------------------------	--------------------------------

It defines feedback value while inverter goes sleep state. When actual feedback value is larger than setting value and inverter arrives lower limit value, the inverter will go sleep.

F8.14 Awaking threshold	Setting range: : 0.0~[F8.13]
-------------------------	------------------------------

It defines feedback value while inverter is in the state of sleeping. When actual feedback value is less than setting value, the inverter will be in the sleepy state. The inverter will wait [F8.15] to switch modes, if the inverter receives satisfied sleep or awaking condition. Shown as fig.6-31.




Fig.6-31 Sleep and awakening function of PID

F8.15 Switching time of Sleeping/Awakening mode	Setting range: : 0.0~[F8.13]
---	------------------------------

When PID controller operates, switching time of sleeping/awakening mode is shown as fig.6-31.

F8.16 upper limit pressure value	Setting range: [F8.13]~[F8.12] Mpa
F8.17 Lower limit pressure value	Setting range: 0.0 ~ 6000.0s

It is used for setting the upper and lower limit pressure value.

F8.18~F8.24 Reserved	
----------------------	--

6.10 Communication function parameter units

F9.0 Communication setting	Setting range: 0000 ~ 0025
----------------------------	----------------------------

The first part of LED(form right to left): It is used for setting baud rate of serials communication.

- 0: Reserved 1: 1200bps 2: 2400bps
- 3: 4800bps 4: 9600bps 5: 19200bps

To make sure both sides have the same baud rate, when client use serials communication. The second part of LED: To set data format of serials communication.

- 0: Close 1: Even 2: Odd

To make sure both sides have the same data format, when client use serials communication. The third and fourth part of LED: Reserved

F9.1 Local address	Setting range: 0 ~ 30
--------------------	-----------------------

F9.2 Response delay of local	Setting range: 0 ~ 1000 ms
------------------------------	----------------------------

It defines waiting time, which is the time form local receives correctly code to send response data frames

F9.3 Function setting of communication Auxiliary function

Setting range: 0000 ~ 1111

The first part of LED(form right to left):

0: The inverter is slave

1: The inverter is master

The second part of LED: Act selection after communication is lost

0: Stop 1: Keep

The third part of LED: Linkage jog

0: Jog synchronized

1: Jog asynchronous

The fourth part of LED: Linkage control synchronized frequency source

0: Setting frequency

1: Output frequency

F9.4 Checkout time of communication overtime

Setting range: 0.0 ~ 100.0 Sec

If the machine itself doesn't receive correct data signals in regulate time, the communication is fault. Inverter will keep on running or stop according to setting of parameter F9.3

F9.5 linkage setting proportion

Setting range: 0.010 ~ 10.000

F9.6 Rectify channel of linkage setting proportion

Setting range: 0 ~ 4

It is used for setting proportion of output freq. between master and slave, when takes linkage setting control. When F9.6 is 0, rectify channel of linkage setting proportion is invalid.

Slave freq. = Master freq. × [F9.5]

When F9.6 is 1, 2, 3 or 4, rectify channel of linkage setting proportion is valid. When the lower limit value of rectify channel is selected, The rectify coefficient is 0.5; when the upper limit value of rectify channel is selected, the rectify coefficient is 2.0,

Slave freq. = Master freq. × [F9.5] × rectify coefficient (0.50~2.00)

F9.6 is used for selecting rectify channel. Rectify channel 1: Panel potentiometer

Rectify channel 2: External voltage signal VC1 (0~5V) Rectify channel 3: External voltage signal VC2 (0~10V)

Rectify channel 4: External current signal CC (0~20mA)

F9.7 Setting channel of guest inverter auxiliary freq.

Setting range: 0.010 ~ 10.000

F9.8 Amplitude of auxiliary freq

Setting range: 0.0~25.00 Hz

It is used for selecting the setting channel of guest inverter auxiliary freq. and amplitude of auxiliary freq




Fig.6-32 Adjust amplitude of auxiliary freq

When the input value of auxiliary freq. setting channel is middle value, auxiliary freq. is 0, Slave output freq. = master instruction freq. × linkage proportion + auxiliary freq. (Linkage proportion is set by [F9.5]、[F9.6])

F9.9	Load self- equilibrium function	Setting range: 0~1
F9.10	Load self- equilibrium proportion	Setting range: 0.50~2.00
F9.11	Trimming range of load self- equilibrium freq	Setting range: 0.0~5.00

These parameters are used for setting load self-equilibrium function ,in linkage synchronous running mode, master inverter is equals an inverter plus a high-precision synchronizer, usually can get high-precision freq. Synchronous. In some application field, load of inverter group should keep balanced so that all the transmission chain tension or velocity strict agreement.

VS500 serial of inverter has loaded self- equilibrium function when inverters are in linkage running mode.

When the load self- equilibrium function is valid, master inverter will transfer the load information to every slave inverter, and every slave inverter will adjust the load instructions according the master.

When the certain slave inverter should to bear a heavier load, it could change through [F9.10]. The value is greater, the load capacity is heavier.

Load self- equilibrium below 5Hz, the effect limited. Only if each master and slave inverter has good linkage ratio coefficient, the self- equilibrium function is valid.

If the adjust is not obvious, please increase parameter [F9.11]

6.11 Special function parameter unit

FC.0	Under voltage protection level	Setting range: 360V ~ 460V
------	--------------------------------	----------------------------

It defines lower limit voltage which terminals P+ and P- are allow while inverter is working normally. For some low voltage conditions, user can decrease under voltage protection level to ensure that inverter is running normally

FC.1	over voltage limit level	Setting range: 660V ~ 760V
------	--------------------------	----------------------------

It defines threshold of voltage stall protection while motor is decelerating. If DC voltage caused by decelerating is beyond setting value of FC.1, deceleration time will automatic prolong. Shown as fig 6-33




Fig 6-33 Voltage stall protection in Dec

FC.2	current amplitude limiting level	Setting range: 150 ~ 200%
------	----------------------------------	---------------------------

It defines the max output current which is permitted by inverter. Whatever the operation mode is, inverter will adjust output freq. to inhibit current within the range of regulation, when output current of inverter is beyond setting value of FC.2.

FC.3 Reserved

FC.4 Reserved

It is used for setting some coefficients with special function in running process. Generally, user needn't set.

The first part of LED(form right to left): Under voltage compensation intensity

The second part of LED: Over voltage inhibit intensity

The third part of LED: Over current inhibit intensity

The fourth part of LED: Self-adapting braking torque adjust intensity

FC.5 Action function selection

Setting range: 0000 ~ 0111

The first part of LED(form right to left): Cooling fan control

0: Cooling fan run after inverter run.

Cooling fan will stop after inverter stop. When temperature is above 40°C, the cooling fan also will also run.

1: Cooling fan will automatic run when inverter is power on.

The second part of LED: Reserved.

The third part of LED: Voltage over modulation

0: Invalid 1: Valid

The fourth part of LED: Reserved

FC.6 Auxiliary functions

Setting range: 0000~0011

The first part of LED(form right to left): Forbid to modify parameter.

0: Invalid.

1: Valid.

When it forbids modifying parameter is valid, [F0.18] will be invalid, if you want to get new password, please ask for our service department. This function is used for preventing modify parameter wrongly.

The second part of LED: Input terminal effective level.

0: Low level (terminals is connected)

1: High level (terminals is disconnected)

The third part of LED: Reserved

The fourth part of LED: Selection of rotate speed display proportion

0: the coefficient of rotational speed display is valid

Rotational speed display=Rotational speed×Rotator speed coefficient setting (F6.11)

1: the deceleration proportion is valid

Rotational speed display=Rotate speed / Rotator speed coefficient setting(F6.11)

FC.7 Reserved

FC.8 Agency password

Setting range: 0 ~ 9999

FC.9~ FC.10 Reserved

FC.11 Oscillatory inhibiting factor

Setting range: 0.0~ 2.00

FC.12 Reserved

FC.13 Program version

Range: 1600 ~ 1699

7. SPECIAL FUNCTIONS FOR DRAWING MACHINE

7.1 Overview

On the mechanical equipment for metal products, paper making and wires and cables, etc., the tension stability must be ensured during continuous drawing out fabrics or wires from the machines and during winding, to ensure the product quality. For the special application requirements of the drawing machine, E380 series inverter (program version of above V1611) is built in with the dedicated control module, realizes highly stable winding control through the advanced PID control with feed forward compensation, and provides multiple dedicated functions such as disconnection protection and stop at fixed length.

Typical traction application of drawing machine specialized inverter, show as Fig. 7-1:




Fig. 7-1 Typical Traction Application

7.2 Selection of dedicated functions of drawing machine

Change the single-digit setting of parameter [F0.0] to switch between the general running mode and drawing machine dedicated mode and enable the corresponding parameter table and software functional module. The drawing machine dedicated function is a controlled function, and the dedicated authorization code is required for enabling this function.

LED single-digit definition of parameter [F0.0]:

0: General mode 1: Drawing machine dedicated mode

When setting of this parameter is changed, it will automatically start one parameter initialization process, and switch to the corresponding parameter environment



In the application of dual inverter wire drawer:

- Only the rolling inverter needs to work in the dedicated mode and the main drawing inverter works in the general mode.
- When the rolling inverter is used for the first time or changed the using equipment, the dancer arm raise delay may be too quick or too slow, which is caused by self-correcting of parameter

7.3 Parameter table of drawing machine dedicated function ([F0.0]=0001)



The drawing machine dedicated parameter table can be used in comparison with the general parameter table, wherein, the parameters in the shaded part are somewhat different from the parameters in the general parameter table (with different value or definition), other parameters are identical with that defined in the general parameter table, and please refer to the description of the general parameter table for the corresponding description and user guide.

Description of marks in the functional parameter table:

“★” means that the parameter cannot be changed during the running; “▲” means that the parameter is associated with the inverter model.

Parameter Type	Code	Name	Probable Causes	Min. Unit	Factory Value	Modification Limited
The basic operation parameters	F0.0	Running mode selection	LED bits : Running mode 0: General mode 1: Special for drawing machine LED tens: Reserved LED hundreds: Reserved LED thousands: Reserved	1	0001	★
	F0.1	Frequency input channel / mode selection	0 : Frequency setting by operation panel 1 : UP/DW Acc and Dec control 2 : RS485 interface 3 : Panel potentiometer 4 : External voltage signal VC1 (0V~5V) 5 : External voltage signal VC2 (0V~10V) 6 : External current signal CC (0~20mA) 7 : External pulse signal (0.0~50.0KHz) 8 : Combination setting 9 : External terminals	1	2	
	F0.2	Frequency digital setting	0.00~ the upper limit frequency	0.01	0	
	F0.3	Auxiliary control of freq. Digital setting	The first part of LED(form right to left): 0: Setting freq. will save after power down 1: Setting freq. will not save after power down The second part of LED : 0 : Setting freq. is to keep when stopping 1 : Setting freq. will save in F0.2 when stopping 2 : Setting freq. is clear when stopping The third and fourth part of LED(form right to left) : Reserved	1	0021	

	F0.4	Operation channel selection	<p>The first part of LED (form right to left):</p> <p>0 : Panel control 1 : External terminals control</p> <p>2 : RS485 interface</p> <p>The second part of LED : Function of key STOP</p> <p>0 : It is valid for panel control.</p> <p>1 :It is valid for all kinds of control method.</p> <p>The third and fourth part of LED(form right to left) : Reserved</p>	1	0002	
--	------	-----------------------------	--	---	------	--

Parameter Type	Code	Name	Probable Causes	Min. Unit	Factory Value	Modification Limited
The basic operation parameters	F0.5	Combination methods of instruction terminals	0 : Two-line mode 1 1 : Two-line mode 2 2 : Three-line mode	1	0	★
	F0.6	Running direction control and setting of operation instruction auxiliary	The first part of LED (form right to left): 0 : Running direction is consistent with setting direction 1 : Running direction is in contradiction to setting direction The second part of LED : 0 : Prevention REV is valid 1 : Prevention REV is invalid The third and fourth part of LED(form right to left) : External operation channel auxiliary function 0 :self-starting is forbidden when inverter is just power-on 1 : self-starting is allowed when inverter is just power-on The fourth part of LED(form right to left) : Reserved	1	0010	
	F0.7	The lower limit frequency	0.0~[F0.8]	0.01	0.0	
	F0.8	The upper limit frequency	[F0.7]~400.00 Hz	0.01	80.00Hz	
	F0.9	Reserved				
	F0.10	Acc time 1	0.1~6000 Sec	0.1	1.0	
	F0.11	Dec time 1	0.1~6000 Sec	0.1	1.0	
	F0.12	Characteristics parameter of Acc and Dec	The first part of LED (form right to left): 0 : Beeline 1 : S curve The second part of LED : 0 : Output freq. will be modified according to Acc/Dec time. 1 : Output freq. will be automatically modified according to lode. The third part of LED : Unit of Acc/Dec time 0 : Sec 1 : Min The fourth part of LED : Reserved	1	0000	
	F0.13	Acc/Dec initial section proportion Of S curve	10.0~50.0 (%)	0.1	20.0%	★
	F0.14	Acc/Dec ascending/decline section proportion of S curve	10.0~80.0 (%)	0.1	60.0%	★
	F0.15	Lode pattern selection	0 : General-purpose lode. 1 : Fan and pump lode.	1	0	★
	F0.16	Carrier wave frequency	1.5~12.0 KHz	0.1	▲	

Parameter Type	Code	Name	Probable Causes	Min. Unit	Factory Value	Modification Limited
The basic operation parameters	F0.17	Carrier wave characteristics	The first part of LED (form right to left): Reserved The second part of LED : 0 : Load carrier wave adjustment is invalid 1 : Load carrier wave adjustment is valid The third part of LED : 0 : Heat carrier wave adjustment is invalid 1 : Heat carrier wave adjustment is valid The fourth part of LED : 0 : Freq. relating carrier wave adjustment is Invalid 1 : Freq. relating carrier wave adjustment is valid	1	1110	
	F0.18	Parameter write-protection	1 : Forbid to modify all parameter, except F0.2 and F0.18 2 : Forbid to modify all parameter, except F0.18 Other values: all parameters are allowed to modify	1	0	
The primary application of parameter	F1.0	Type of V/F Curve	0 : Constant torque curve 1 : Low-freq. torque curve 1 2 : Low-freq. torque curve 2 3 : V/F user-defined curve	1	3	★
	F1.1	Torque Boost	0.0~20.0 (%)	0.1	▲	
	F1.2	Torque boost pattern	0 : Manual 1 : Automatic	1	0	★
	F1.3	Basic running frequency	5.00~the upper limit frequency	0.01	50.00	
	F1.4	Max output voltage	200~500V/100~250V	1	400 220	
	F1.5	V/F freq. 3	[F1.7]~[F1.3]	0.01	30.00	★
	F1.6	V/F voltage 3	[F1.8]~100.0(%)	0.1	65.0	★
	F1.7	V/F freq. 3	[F1.9]~[F1.5]	0.01	20.00	★
	F1.8	V/F voltage 2	[F1.10]~[F1.6]	0.1	50.00	★
	F1.9	V/F freq. 1	0.0~[F1.7]	0.01	10.00	★
	F1.10	V/F voltage 1	[F1.1]~[F1.8]	0.1	25.0	★
	F1.11	DC braking current when starting	0.0~100.0 (%)	0.1	50.0	
	F1.12	DC braking time when starting	0.0~20.0Sec	0.1	0	★
	F1.13 ~ F1.18	Reserved				
	F2.0 ~ F2.18	The same with the general definition of parameters, please refer to the general parameter table				

Parameter Type	Code	Name	Probable Causes	Min. Unit	Factory Value	Modification Limited
Digital O/I parameters	F3.0	Function selection of input terminal 1 (0~35)	0 : Control terminal is idle 1 : Multi-speed control terminal 1 2 : Multi-speed control terminal 2 3 : Multi-speed control terminal 3	1	1	★
	F3.1	Function selection of input terminal 2 (0~35)	4 : Wobble freq. is valid 5 : State of wobble freq. reset 6 : FWD jog control 7 : REV jog control	1	16	★
	F3.2	Function selection of input terminal 3 (0~35)	8 : Acc& Dec time selection terminal 1 9 : Acc& Dec time selection terminal 2 10 : Freq. setting channel selection 1 11 : Freq. setting channel selection 2	1	3	★
	F3.3	Function selection of input terminal 4 (0~35)	12 : Freq. setting channel selection 3 13 : Freq. is controlled gradually increase (UP) 14 : Freq. is controlled gradually decrease (DW)	1	6	★
	F3.4	Function selection of input terminal 5 (0~35)	15 : UP-DW freq. clear 16 : Uncontrolled stop control 17 : Fault signal of peripheral equipment input	1	34	★
	F3.5	Function selection of input terminal 6 (0~35)	18 : Three-line mode running control 19 : DC braking control 20 : Inner counter clear 21 : Inner counter timer 22 : PLC running valid 23 : PID running valid 24 : Internal timer trigger terminal 25 : PLC state reset after stopping 26 : Multi-speed control terminal 4 27~30: Reserved 31 : Coil diameter reset 32 : Initial coil diameter selection terminal 1 33 : Position switch 34 : Disconnection proximity switch 35 : Disconnection reset / Brake release	1	35	★
	F3.6	Output terminal OC1	0: Inverter in running 1: Frequency reaching 2: Freq. level detection signal (FDT) 3: Over-loading alarm 4: External fault halt 5: Output frequency reaches the upper-limit 6: Output frequency reaches the lower-limit 7: Running in zero speed	1	2	
	F3.7	Output terminal OC2	8: Under voltage shutdown 9: PLC stage is end of run 10: PLC periodic is end of run 11: Internal timer arrives regular time 12: Setting value of counter arrival 13: Designated value of counter arrival	1	22	

	F3.8	TA, TB and TC of relay contacts	14: Deceleration running 15: Reserved 16: Inverter fault 17: Restriction on wobble freq. of upper & lower-limit 18~20: Reserved 21: Disconnection inspection output 22: Brake signal output	1	16	
--	------	---------------------------------	---	---	----	--

Parameter Type	Code	Name	Probable Causes	Min. Unit	Factory Value	Modification Limited
Digital O/I parameters	F3.9	Frequency reach the checkout amplitude	0.0~20.00 Hz	0.01	5.00	
	F3.10	FDT setting 1	0.0~the upper limit freq.	0.01	2.00	
	F3.11	FDT output delay time 1	0.0~200.0 Sec	0.1	0.1	★
	F3.12	FDT setting 2	0.0~the upper limit freq.	0.01	10.00	
	F3.13	FDT output delay time 2	0.0~200.0Sec	0.1	2.0	★
	F3.14	Over-loading alarm level	50~200 (%)	1	110	
	F3.15	Over-loading alarm delay time	0.0~20.0 Sec	0.1	2.0	★
	F3.16	Reserved				
Auxiliary running parameter	F4.0	Reserved				
	F4.1	Start frequency	0.0~10.00 Hz	0.01	0.5	
	F4.2	Start frequency duration	0.0~20.0 Sec	0.1	0.0	★
	F4.3	Stop mode	0 : Decelerate mode 1 : Uncontrolled stop	1	0	
	F4.4	Initial freq. of DC braking when stopping	0.0~50.00 Hz	0.01	3.00	
	F4.5	Waiting time of DC braking when stopping	0.0~5.0 Sec	0.1	0.1	
	F4.6	Action time of DC braking when stopping	0.0~20.0 Sec	0.1	2.0	
	F4.7	DC braking current when stopping	0.0~100 (%)	0.1	30.0	
	F4.8	Running threshold of zero freq.	0.0~100.00 Hz	0.01	0.0	
	F4.9	Return different of zero freq.	0.0~50.00 Hz	0.01	1.00	
	F4.10	FWD jog frequency	0.0~the upper limit freq.	0.01	4.00	
	F4.11	Acc torque level	110~200 (%)	1	150	
	F4.12	Motor over-lode protection coefficient	50~110 (%)	1	110	
	F4.13	Automatic voltage regulation (AVR)	0 : Invalid 1 : Dynamic valid 2 : Static valid 3 : Deceleration invalid	1	0	
	F4.14	Energy-saving running	0 : Invalid 1 : Valid	1	0	★
	F4.15	Intensify of energy-saving running	30~90	1	60	
	F4.16	Dead time of FWD&REV	0.0~5.0 Sec	0.1	0.0	★
	F4.17	Acceleration time 2	0.1~6000 Sec	0.1	0.8	
	F4.18	Deceleration time 2	0.1~6000 Sec	0.1	0.8	
	F4.19	Acceleration time 3	0.1~6000 Sec	0.1	▲	
	F4.20	Deceleration time 3	0.1~6000 Sec	0.1	▲	
	F4.21	Acc time 4/Jog Acc time	0.1~6000 Sec	0.1	▲	
F4.22	Dec time 5/Jog Dec time	0.1~6000 Sec	0.1	▲		

Parameter Type	Code	Name	Probable Causes	Min. Unit	Factory Value	Modification Limited	
Auxiliary running parameter	F4.23	Modified rated of UP/DW terminals	0.01~100.0 Hz/Sec	0.01	10.00Hz		
	F4.24	Start voltage of dynamic braking	600~750 V	1	700V		
	F4.25	Action ratio of dynamic braking	10~100 (%)	1	60%		
	F4.26	Restart after power down setting	The first part of LED : 0 : Invalid 1 : Valid The second part of LED : 0 : Routine mode 1 : Detect speed and restart mode The third and fourth part of LED :Reserved	1	0010	★	
	F4.27	Waiting time of restart after power down	0.0~10.0 Sec	0.1	0.5	★	
	F4.28	REV jog frequency	0.0~the upper limit freq.	0.01	4.00		
		F5.0 ~ F5.26	Reserved				
Winding PID control	F6.0 ~ F6.19	The same with the general definition of parameters, please refer to the general parameter table					
	F7.0	PID feedback channel selection/Pendulum feedback input	0: VC1 input 1: VC2 input 2: CC input 3: PLS input	1	0	★	
	F7.1	PID function setting	LED bits: PID function selection 0: PID off 1: PID function valid LED tens: PID parameter adjustment 0: Use 1st group parameters only 1: Adjust by coil diameter 2: Adjust by running freq. LED hundreds: PID output polarity (only valid for straight wire drawing machine) 0: Positive 1: Negative LED thousands: special function to slow down pendulum arising speed 0: valid 1: invalid	1	0021		
	F7.2	The proportional gain 1	0.0~6000.0 Sec	0.01	1.00		
	F7.3	Integral time 1	0.0~50.0 (%)	0.1	10.0		
	F7.4	Derivative time 1	0.0~80.0 (%)	0.01	2.00		
	F7.5	Proportional gain 2	0.1~1000.0 Sec	0.01	1.00		
	F7.6	Integral time 2	0.1~1000.0 Sec	0.1	15.0		
	F7.7	Derivative time 2	0.0~the upper limit freq	0.01	5.00		
	F7.8	PID upper limit limiter	5~50 %	1%	20%		
Parameters special for drawing machine	F8.0	Start delay gain	1.0~100.0	0.1	10.0	★	
	F8.1	Initial operating freq.	0.0~50.00 Hz	0.01	6.00	★	
	F8.2	PID error limiter	5.0~100.0 %	0.1	20.0		
	F8.3	Mechanical transmission ratio	0.01~300.0	0.01	1.00		
	F8.4	Max. coil diameter	10mm~10000mm	1	400		
	F8.5	Reel diameter 1	10mm~10000mm	1	220		

Parameter Type	Code	Name	Probable Causes	Min. Unit	Factory Value	Modification Limited
Parameters special for drawing machine	F8.6	Reel diameter 2	10mm~10000mm	1	100	
	F8.7	Coil diameter filter time	0.50~100.00 Sec	0.01	10.00s	
	F8.8	Linear speed input source	0: No input 1: VC1 input 2: VC2 input 3: CC input 4: PLS input	1	0	
	F8.9	Max. linear speed	0.1m/Min~6500.0m/Min	0.1m/Min	2500.0	
	F8.10	Coil diameter calculation min. Linear speed	0.1m/Min~6500.0m/Min	0.1m/Min	500.0	
	F8.11	Pendulum stable point setting	20.0~80.0 (%)	0.1	50.0	
	F8.12	Disconnection detection method	0: Invalid 1: To detect by disconnection proximity switch signal 2: To detect by PID feedback (pendulum signal)	1	0	
	F8.13	Min. Freq. of disconnection detection	0.00~50.00Hz	0.01 Hz	10.00Hz	
	F8.14	Upper limit value of disconnection detection	0.1%~50.0%	0.10 %	10.0%	
	F8.15	Disconnection detection start delay time	0.1Sec~60.0 Sec	0.10 %	6.0s	
	F8.16	Disconnection detection judgment delay time	0.1Sec~60.0 Sec	0.10 %	2.0s	
	F8.17	Disconnection fault auto reset	0: Invalid 1: Valid	1	0	
	F8.18	Disconnection fault auto reset interval time	1.0~99.0 Sec	0.1	15.0 s	
	F8.19	Brake signal start freq.	0.0~50.00 Hz	0.01	1.50 Hz	
	F8.20	Braking time	0.1~100.0 Sec	0.1	3.0 s	
	F8.21	Setting length arrives action selection	LED bits: fixed length to stop 0: No action 1: Stop LED tens: fixed length stop method 0: setting length arrival 1: Max. Coil diameter arrival 2: Each of setting length and max. coil diameter arrival	1	0000	
	F8.22	Proportion of high & low grade	0.01~100.00	0.01	1.00	
	F8.23	Winding motor pole pairs	1~8	1	2	
F8.24	Preset length	1.00~650.0 KM	0.01	300.0		

Parameter Type	Code	Name	Probable Causes	Min. Unit	Factory Value	Modification Limited
Communication function parameters	F9.0	Communication setting	The first part of LED(form right to left) : It is used to set baud rate of serials Communication. 0 : Reserved 1 : 1200bps 2: 2400bps 3: 4800bps 4: 9600bps 5: 19200bps The second part of LED : To set data format of serials communication. 0 : Close 1 : Even 2 : Odd The third and fourth part of LED: Reserved.	1	0014	★
	F9.1	Local address	0~30	1	0	
	F9.2	Response delay of local	0~1000 ms	1	5ms	
	F9.3	Function setting of communication Auxiliary function	The first part of LED(form right to left) : 0 : The inverter is guest 1: The inverter is host The second part of LED : Act selection after communication is lost 0 : Stop 1 : Keep The third part of LED : linkage jog 0 : jog synchronized 1 : jog asynchronous The fourth part of LED : linkage control synchronized frequency source 0 : setting frequency 1 : output frequency	1	0010	
	F9.4	Checkout time of communication overtime	0.0~100.0 Sec	0.1	10.0	
	F9.5	Linkage setting proportion	0.010~10.000	0.01	1.000	
	F9.6	Rectify channel of linkage setting proportion	0 : close 1 : Panel potentiometer Rectify channel 2 : External voltage signal VC1 (0 ~ 5V) Rectify channel 3 : External voltage signal VC2 (0 ~ 10V) Rectify channel 4 : External current signal CC (0 ~ 20mA)	1	0	
F9.7 ~ F9.11	Reserved					
FC.0 ~ FC.5	The same with the general definition of parameters, please refer to the general parameter table					

Parameter Type	Code	Name	Probable Causes	Min. Unit	Factory Value	Modification Limited
	FC.6	Auxiliary function	<p>The first part of LED(form right to left) : Forbid modify parameters function 0 : Invalid 1 : Valid</p> <p>The second part of LED : Input terminal effective level 0:Low level (terminals is connected) 1:High level (terminals is disconnected)</p> <p>The third part of LED: Reserved</p> <p>The fourth part of LED : selection of rotate speed display proportion 0: the coefficient of rotate speed display is valid 1: the deceleration proportion is valid</p>	1	0000	
	FC.7 ~ FC.9	The same with the general definition of parameters, please refer to the general parameter table				
	FC.10	Starting preset frequency ratio	0~50	1	20	
	FC.11 ~ FC.13	The same with the general definition of parameters, please refer to the general parameter table				

8. TROUBLESHOOTING AND MEASURES

8.1 Protective functions and Countermeasures

Code	Faults	Probable Causes	Solutions
Fu.01	Over-current during Acc	<ol style="list-style-type: none"> 1、 Acceleration time is too short. 2、 V/F curve is not suitable 3、 You hasn't set the right motor parameters 4、 User start rotating motor, but doesn't set function of detect speed and restart. 5、 Value of torque boost set too high. 6、 Power grid voltage is too low 	<ol style="list-style-type: none"> 1. Prolong the acceleration time 2. Descend the torque boost or adjust the V/F curve 3. Input motor's parameter once again and do self-determination to parameter. 4. To set function of detecting speed and restart 5. To decrease voltage of torque boost 6. Check power grid voltage, and reduce power then use
Fu.02	over-current during Dec	Deceleration time is too short.	Prolong the deceleration time
Fu.03	Over-current during Running or stopping	<ol style="list-style-type: none"> 1. Load occurs mutation 2. Power grid voltage is too low 	<ol style="list-style-type: none"> 1. Decrease load fluctuation 2. Check power supply voltage.
Fu.04	over-voltage during Acc	<ol style="list-style-type: none"> 1. Input voltage is too high 2. Power supply is switched on or off frequently. 	<ol style="list-style-type: none"> 1. Check power supply voltage 2. Decrease setting value of F4.11 3. Control the on-off of inverter by the control terminal
Fu.05	over-voltage during Dec	<ol style="list-style-type: none"> 1. Deceleration time is too short. 2. Input-voltage is abnormal 	<ol style="list-style-type: none"> 1. Extend the deceleration time 2. Check power supply voltage 3. Install or select the brake resistance
Fu.06	over-voltage during running	<ol style="list-style-type: none"> 1. Power supply is abnormal 2. There are energy feedback load 	<ol style="list-style-type: none"> 1. Check power supply 2. Install or select brake resistor
Fu.07	over-voltage during stop	Power supply is abnormal	Check power supply voltage
Fu.08	Under-voltage during running	<ol style="list-style-type: none"> 1. Power supply is abnormal 2. There is great fluctuation of load into electric network. 	<ol style="list-style-type: none"> 1. Check power supply voltage 2. Provide the power supply separately
Fu.09	protective action of inverter	<ol style="list-style-type: none"> 1. Output is short-circuit or ground 2. Load is too heavy 	<ol style="list-style-type: none"> 1. Check wiring 2. Reduce the load 3. Check whether brake resistor is short-circuit
Fu.10	Output grounding	<ol style="list-style-type: none"> 1. The output terminal of inverter grounds 2. The wire is too long between inverter and motor and the carrier frequency is too high. 	<ol style="list-style-type: none"> 1. Check the connecting wire 2. Shorten the connection wire or reduce the carrier frequency.
Fu.11	Interfere of inverter	Fault action caused by disturbance of electromagnetism	Add absorb circuit around inverter
Fu.12	Inverter over-loading	<ol style="list-style-type: none"> 1. Load is too heavy. 2. Acceleration time is too short. 3. Torque boost is too high or V/F curve is not suitable. 4. Voltage of Power supply is too low 5. User start rotating motor, but doesn't set function of detecting speed and restart. 	<ol style="list-style-type: none"> 1. Reduce the load or replace with higher capacity inverter. 2. Prolong Acc time. 3. Decrease the torque boost or adjusting V/F curve. 4. Check Voltage of Power supply 5. To set function of detect speed and restart
Fu.13	Motor over-loading	<ol style="list-style-type: none"> 1. Load is too heavy. 2. Acceleration time is too short. 3. The setting of protection factor is too small 4. Torque boost is too high or V/F curve is not suitable. 	<ol style="list-style-type: none"> 1. Reduce the load 2. Prolong Acc time 3. Increase the over-loading protection factor of motor ([F4.12]) 4. Decrease torque boost voltage and adjust V/F curve

Fu.14	Inverter overheat	1. Wind hole is blocked 2. Environmental temperature is too high 3. Fan is damaged	1. Clear air duct or improve the air condition. 2. Improve ventilation condition or decrease carrier frequency. 3. Replace fan.
Fu.15	Reserved		
Fu.16	External equipment failure	There is signal input on the peripheral. Equipment fault input terminal of Inverter	Check the signal source and the pertinent equipments.
Fu.17	Reserved		
Fu.18	Reserved		
Fu.19	Reserved		
Fu.20	Current checking error	1.The current detecting equipment or circuit is damaged 2.Auxiliary power supply has problem	Contract Us
Fu.21	Temperature sense occur faults	1. Signal line of temperature is poor contact 2. Temperature sensor is damage.	1. Check jack 2. Contract Us
Fu.22- Fu.36	Reserved		
Fu.37	External equipment failure	U-phase current output phase lack or unbalance	Inspect U-phase and motor connecting wire
Fu.38	External equipment failure	V-phase current output phase lack or unbalance	Inspect V-phase and motor connecting wire
Fu.39	External equipment failure	W-phase current output phase lack or unbalance	Inspect W-phase and motor connecting wire
Fu.40	Inner data of storage is wrong.	Read and write errors of the control parameter	Contract Us

8.2 Fault record inquiry

This series inverter records the codes of faults occurring in the latest 6 times and the inverter output parameters of the last fault, through query of which can help find out the fault reasons.

The fault information and status monitoring parameters are stored uniformly, and please query the information by referring to the keyboard operation method.


Monitor Item	Contents	Monitor Item	Contents
d-26	First fault record	d-32	Output frequency of last fault
d-27	Second fault record	d-33	Setting frequency of last fault
d-28	Third fault record	d-34	Output current of last fault
d-29	Fourth fault record	d-35	Output voltage of last fault
d-30	Fifth fault record	d-36	DC voltage of last fault
d-31	Sixth fault record	d-37	Module temperature of last

8.3 Reset



- Be sure to check the fault cause and exclude it before reset, otherwise, which may lead to the inverter, permanent damaged.
- If the inverter can not be reset or occur the fault again after reset, please find out the reason. Continuous reset will damage the inverter
- Over-load or over-heat protective action should delay 5 minutes to reset.

When the inverter occurs the fault, you can reset the inverter to resume the normal running by any way as follows:

- I. External reset input-terminal RST and GND terminal are closed, and then off.
- II. While the fault code is displayed, press  key.
- III. It will send fault reset instrument by RS485 interface.
- IV. Turn the power source off.

9. MAINTENANCE AND CARE

As a result of ambient temperature, humidity, dust, vibration and aging of internal components of inverter, the inverter will probably appear the potential problem during running. In order to ensure the inverter to run steadily for a long time, the inverter should be checked up once at 3 to 6 months.



First of all, turn the inverter's power off. And professional worker performs nance.

9.1 Daily Maintenance

The daily inspection and care can contribute to promptly discover different abnormal situations, find out the reasons for abnormality, early eliminate hidden dangers of fault, ensure the equipment to normally run, and prolong the service life of the converter. Please refer to the following table for the daily inspection and care

Inspection items	Time		Inspection contents	Criterion
	Daily	Periodic		
Running Environment	√		1. Temperature, Humidity 2. Dust, gas	1. When temperature is over 40℃, the panel should be opened. Humidity is less than 90%, and no condensation 2. No peculiar smell, no flammable and explosive gases.
Cooling system		√	1. Installation Environment 2. Fan in inverter	1. Installation environment is well ventilated, and the duct is not blocked. 2. Fan is normal and no abnormal voice.
Inverter	√		1. Vibration, Temperature raise 2. Noises 3. Wire, Terminal	1. Vibration smooth, the temperature of air outlet is normal. 2. Not abnormal voice and no peculiar smell 3. Fastening screw is not loosed.
Motor	√		1. Vibration, Temperature raise 2. Noises	1. Running smooth, and temperature is normal
Input/output Parameters	√		1. Input voltage 2. Output current	1. Input-voltage is in the setup range 2. Output-current is under the rated value

Recommend the use of instrument:

input voltage	Moving-coil voltmeter
Output voltage	Rectifier-type voltmeter
O/I current	Tong-type ammeter



- (1) Inverter has done the electric insulating experiment before leave-factory, so user don't need to do the withstand voltage test.
- (2) Do the insulation test to the inverter if necessary, all of I/O terminals must be connected in short-circuit (R, S, T, L1, L2, U, V, W, P, P-, PB). Strictly prohibit from doing the insulation test for the single terminal. Please use 500V Meg-ohmmeter to perform this test.
- (3) Control circuit can not be used the Meg-ohmmeter to test.
- (4) For insulation test to motor, the connection wire between motor and inverter should be disassembled.

9.2 Damageable parts maintenance

Some cells in inverter are worn out or the performance descends in the process of usage process, in order to ensure the stable running of inverter, so the inverter needs to do the preventative maintenance or replace the part if necessary

9.2.1 Filter capacitor

Pulse current in main circuit will take effect on the performance of aluminum electrolytic filter capacitor, and the degree of effect has relation with the ambient temperature and usage condition. In normal condition, the electrolytic capacitor of inverter should be replaced at 4 to 5 years.

When the electrolytic capacitor leaks out, safety valve falls out or main block of capacitor expands, the corresponding parts should be replaced immediately.

9.2.2 Cooling fan

The lifetime of all the cooling fans in the inverter is about 15000 hours (that inverter is used continuously about two years). If the fan happens to abnormal noise or vibration, it should be replaced immediately.

9.3 Storage

If the inverter don't used for a long time, please notice the following items:

- (1) The environment for storage shall be consistent with the following table:

Environmental	Requirement	Remarks
Ambient temperature	-20°C-60°C	The long-term storage temperature shall not be over 30°C, so as to prevent deterioration of the capacitance characteristics, and the environment with condensation or freezing caused due to temperature shock shall be avoided
Relative	20~90%	Plastic membrane sealing and desiccant, etc. can be used
Storage environment	No direct sunlight, no dust, no corrosive or inflammable gas, no oil, steam, gas, drip or vibration, with less salt	

- (2) If the inverter is not to be used for a long time, it shall be electrified once every half year for recovering the characteristics of the filter capacitor, and checking its other functions. During electrification, one autotransformer shall be used to gradually increase the voltage, and the electrification time shall be over half an hour.



If inverter is not used for a long time, the performance of internal filter capacitor will descend.

9.4 After sale services

In guarantee time, if the faults are caused by the following cases, certain service cost would be charged.

- ① Malfunction caused by not following the operation manual or over the standard specification;
- ② Malfunction caused by repair or refitting by oneself without grant.
- ③ Malfunction caused by the bad-storage.
- ④ Malfunction due to application of inverter for abnormal functional needs.
- ⑤ Damage caused by the fire, salt-corrode, gas-corrode, earthquake, storm, flood, thunder, voltage abnormal or other force majored.

Even if over guarantee time, our company will provide the paid service forever.

10. USAGE EXAMPLE

10.1 Panel on-off control, Panel potentiometer setting frequency

10.1.1 Parameters setting

1. When F0.4 is 00#0, panel control is valid.
2. When F0.1 is 3, panel potentiometer is valid

10.1.2 Basic wiring




Fig10-1 Basic wiring

10.1.3 Operation Notes:

Press **FWD** key to start the inverter, and then rotate the button of panel potentiometer in clockwise to increase setting frequency step by step. Contrarily, rotate in anti-clockwise to decrease setting frequency step by step.

Press **STOP** key to stop the inverter.



➤ External control terminal FWD decides the running direction of motor.

10.2 External on-off control mode, external voltage setting frequency

10.2.1 Initial setting

1. When F0.4 is 00#1, external terminals control is valid.
2. When F0.1 is 5, external voltage VC2 (0~10V) is valid

10.2.2 Basic wiring




Fig10-2 Basic wiring

10.2.3 Operation

FWD-CM is off, the motor will run forward. REV-CM is off, the motor will run backward. FWD-CM and REV-CM are off or on at the same time, the inverter will stop.

Setting frequency is set by external voltage signal VC2



- Control method of terminals FWD and REV is set by parameter F0.5. (See the explanation about parameter F0.5.)

10.3 Multi-speed running, external on-off control mode

10.3.1 Initial setting

1. When F0.4 is 00#1, external terminals is valid.
2. To set external terminals X1, X2 and X3 as multi-speed terminals. (Namely, parameter [F3.0] ~[F3.2])
3. To set running freq. of each stage according to user needs. (namely, parameter[F5.1]~[F5.15])

10.3.2 Basic wiring




Fig10-3 Basic wiring

10.3.3 Operation Notes:

FWD-CM is off, the motor will run forward. REV-CM is off, the motor will run backward. FWD-CM and REV-CM is off or on at the same time, the inverter will stop.

If X1, X2 and X3 are all open with CM, the multi-speed running is invalid. The inverter will run as the setting instruction speed. (The setting frequency channel is selected by parameter F0.1)

If one terminal or all of X1, X2 and X3 are connected with CM terminal, the inverter will run as the multi-speed frequency selected by X1, X2 and X3



- The multistage speed control terminals are selected through parameters [F3.0]-[F3.5]. When three multistage speed control terminals are selected, the multistage speed control of 15-stage speed can be conducted

10.4 Panel on-off control, Panel potentiometer setting frequency and linkage control with inverters

10.4.1 Initial setting

Master setting:

1. Freq. setting channel is panel potentiometer mode. Namely F0.1 is 3.
2. Operation channel selection is panel control, namely F0.4 is 00#0.

3. Communication setting (Parameter F9.0) is default.
4. If F9.3 is 0001, the inverter is master. Slave setting:
 1. Freq. setting channel is RS485 interface. Namely F0.1 is 2.
 2. Operation channel selection is RS485 interface. Namely F0.4 is 00#2.
 3. Communication setting (Parameter F9.0) is default.
 4. If F9.3 is 0000, the inverter is slave.
 5. Linkage setting proportion (Parameter F9.5) will be set by user needs.
 6. Rectify channel of linkage setting proportion is external voltage signal VC1. Namely F9.6 is 2

10.4.2 Basic wiring




Fig10-4 Basic wiring

10.4.3 Operation Notes:

Running freq. of slave has a certain proportion with master. Linkage setting proportion is set by parameter F10.5.

In this example, freq. proportion of master and slaves can get across by VC1 channel

10.5 Energy-saving reconstruction of escalator (for reference only)

10.5.1 Initial setting

1. Command channel: External control ([F0.4] =###1).
2. Mode of running command: 3-wire mode ([F0.5] =2).
3. 3-wire running control: Select the terminal X3 ([F3.2] =18).
4. Relay output selection: Time of internal timer is up ([F3.8] =11).
5. Internal timer: be set according to the specific circumstance ([F6.0]).
6. Trigger terminal of internal timer: Terminal X4 ([F3.3] =24).

10.5.2 Basic Wiring Diagram:




Fig. 10-5 Basic Wiring Diagram

10.5.3 Operation instructions

Under the normal state, when TA and TB are connected, X3 and CM will be naturally connected to form the valid command status. At this time, when there is input signal by infrared induction, FWD terminal will receive the starting signal for running and the inverter will start to run. After running to the time set by parameter [F6.0], TA and TB will output 0.5s disconnection signal and the inverter will stop running.

This scheme is used in inductive self-running control of the escalator: the escalator automatically stops when there is no person and logistics (it is used only in the reconstruction of the escalator that can be stopped).

10.6 PLC control of start/Stop and 3-stage speed running of inverter

10.6.1 Introduction of exemplificative control function:

One typical control method is hereby provided through one simple routine of PLC control of inverter, to achieve the purpose of integrating the inverter and the system. The control approach is as follows: 1. Start inverter running through X0 terminal; 2. Stop inverter running through X5 terminal; 3. Connect X1, X2, and X3 to separately correspondingly output frequencies 10Hz, 20Hz and 50Hz; 4. When terminals are connected at the same time, the frequency output is invalid (outputting 0 frequency).

10.6.2 System configuration:

Master station: Mitsubishi PLC Model: FX2N-16MR-001

Slave station: E380-4T0220 series inverter

10.6.3 Hardware connection of the master and slave

SUNFAR inverter can realize RS485 communication with PLC by connecting with crystal head telephone line, show as follows:




Fig. 1 Wiring Method

10.6.4 Wiring Diagram of SUNFAR inverter and PLC Master:




Fig.2 Main Loop Wiring Diagram


10.6.5 Slave setting:

1. Frequency input channel: communication interface (F0.1=2)
2. Running command channel: communication interface (F0.4=00#2)
3. Communication setting F9.0: defaults
4. Communication auxiliary function configuration F9.3 = 0000: the inverter as slave

10.6.6 Operation description:

- X0 terminal on, PLC control inverter operation.
- X1 terminal on, inverter running speed 10Hz.
- X2 terminal on, inverter running speed 20Hz.
- X3 terminal on, inverter running speed 50Hz.
- X5 terminal on, inverter stops.

10.6.7 Ladder Diagram of PLC Master



Appendix I MODBUS protocol.

1. Communication Configuration

F9.0=X1XX, select MODBUS-RTU protocol.

F9.0=X0XX, select SUNFAR self-defined protocol.


Notes: X indicates that bit is an arbitrary number.

2. Communication Function

To complete the communication between the upper computer and inverter, including sending the operating command to the inverter, setting running frequency, rewriting the function code parameters as well as reading the running status, monitoring parameters, fault information and function code parameters of the inverter

3. Protocol Format

MODBUS-RTU Format



4. Protocol Format Explanation

4.1 Slave address

0 is broadcast address, slave address can be set from 1~247.

4.2 PDU part

(1) Function code 03: for reading the functional parameters, running status, monitoring parameters and fault information of multiple inverters, which can read maximum 6 address-contiguous inverter parameters.

Transmission by the master:

PDU part	03	Register start address, high-order	Register start address, low-order	Number of registers, high-order	Number of registers, low-order
Data length (Byte)	1	1	1	1	1

Response by the slave:

PDU part	03	Number of bytes read (2*number of registers)	Content read
Data length (Byte)	1	1	2*number of registers

(2) Function code 06: for rewriting the operating command, running frequency and functional parameters of single inverter.

Transmission by the master:

PDU part	06	Register start address, high-order	Register start address, low-order	Register data, high-order	Register data, low-order
Data length (Byte)	1	1	1	1	1

Response by the slave:

PDU part	06	Register start address, high-order	Register start address, low-order	Register data, high-order	Register data, low-order
Data length (Byte)	1	1	1	1	1

The slave will conduct objection response in case of occurrence of certain error.

Objection response:

PDU part	0x80+function code	Objection code
Data length (Byte)	1	1

Objection code indicates the error type:

Objection code	Error corresponded
01	Illegal function code
02	Illegal data address
03	Data exceeding limit
04	Invalid operation of slave
20	Excessive parameters read
21	Retention and implicit parameters read and written
22	Data modification prohibited during slave running
23	Data modification protected by password

4.3 CRC

CRC	CRC low-order	CRC high-order
Data length (Byte)	1	1

CRC function is as follows:

unsigned int crc_chk_value(unsigned char *data_value, unsigned char length)

```

{
    unsigned int crc_value=0xFFFF;
    int i;
    while(length--)
    {
        crc_value^=*data_value++;
        for(i=0;i<8;i++)
        {
            if(crc_value&0x0001)
                crc_value=( crc_value>>1)^0xA001;
            else
                crc_value= crc_value>>1;
        }
    }
    return(crc_value);
}
    
```

5. Address Definition of Communication Parameters

Address distribution of inverter parameters

Register meaning	Register address space
Function parameter ¹	The high-order is the group-index of the function code, and the low-order is the label of the function code, such as F1.11, and its register address is F10B
Monitoring parameter	The high-order is 0xD0, low-order is the label of monitoring, such as d.12, its register address is D00C
Given by PID	0x1000
Operating command ²	0x1001
Frequency setting	0x1002
Inverter status ³⁾	0x2000
Fault information ⁴⁾	0x2001

Note:

- 1) If EEPROM of the function code parameter is frequently written, its service life will be reduced. Some parameters do not need to be stored under the communication mode, and only the value in RAM needs to be modified. It only needs to change F in the register high address to 0 when writing RAM value of the functional parameter, for example, if needing to write RAM value of F1.11, its register address shall be 010B. However, this register address representation method cannot be used for reading the functional parameter of the inverter.
- 2) Operating command code corresponding to the operating instruction:

Operating command code	Operation command
0x0000	Invalid
0x0001	Forward run to start
0x0002	Reversion run to start
0x0003	Stop
0x0004	Slave forward jog
0x0005	Slave reversion jog
0x0006	Jog run to stop
0x0020	Slave fault reset

- 3) Inverter status code corresponding to the indication meaning:

Inverter status code	Implications
0x0000	Slave DC voltage is not prepared
0x0001	Slave forward running
0x0002	Slave reversion running
0x0003	Slave stop
0x0004	Slave forward jog running
0x0005	Slave reversion jog running
0x0011	Forward accelerating
0x0012	Reversion accelerating
0x0013	Instantaneous stop and restart
0x0014	Forward decelerating
0x0015	Reversion decelerating
0x0016	Slave is under DC braking status
0x0020	Slave is on fault status

- 4) The high-order of the fault information code is 0, and low-order corresponds to the label of inverter fault code behind Fu. for example, the fault information code 0x000C means the inverter fault code is Fu.12.

6 Examples

6.1 To start forward running of 1# inverter

Master request:

Slave address	Function code	Top-bit of register initial address	Low-bit of register initial address	Top-bit of register data	Low-bit of register data	Low-bit of CRC calibration	Top-bit of CRC calibration
01	06	10	01	00	01	1D	0A

Response by slave: inverter under forward running, return: request the same data with the master

6.2 To set the inverter running frequency to 50.00Hz

Master request:

Slave address	Top-bit of register initial address	Top-bit of register initial address	Low-bit of register initial address	Top-bit of register data	Low-bit of register data	Low-bit of CRC calibration	Top-bit of CRC calibration
01	06	10	02	13	88	21	9C

Response by slave: inverter under 50.00Hz running, return: request the same data with the master

6.3 To read the current running frequency and output current of the inverter: Inverter reply frequency of 50.00Hz and output current of 1.1A

Master request:

Slave address	Function code	Top-bit of register initial address	Low-bit of register initial address	Top-bit of register number	Low-bit of register number	Low-bit of CRC calibration	Top-bit of CRC calibration
01	03	D0	00	00	02	FC	CB

Response by slave:

Slave address	Function code	Read bytes	Top-bit of 1 st register data	Low-bit of 1 st register data	Top-bit of 2 nd register data	Low-bit of 2 nd register data	Low-bit of CRC calibration	Top-bit of CRC calibration
01	03	04	13	88	00	0B	3F	5A

Appendix II OPTIONS

1. Operation panel

Sometimes users need to take operation panel out of the inverter or control cabinet, if users purchase panel base and wire, it is convenient to install and debug. Wire between operation panel and inverter should be less than 15m. If the length is above 15m, long-distance control line is needed

1.1 Appearance of panel base




Fig C-1 Dimension of panel base




Fig C-2 Hole dimension of panel base

1.2 Appearance of small panel base




Fig C-3 Dimension of small panel base




Fig C-4 Hole dimension of small panel base



It is recommended that users take Fig C-4 and Fig-D Hole dimension of panel base

1.3 Installation of panel base

Open a hole on the control cabinet according to dimension of panel base. And put the panel horizontally into the hole. Then four locks in panel base will lock. There is an interface on the bottom of base, please insert the long-distance control wire into it,

3. Brake resistance

During the running of the inverter, if the speed of the controlled motor drops too fast or the motor load jitters too fast, the motor's electromotive force, through the inverter, will charge the internal capacitor of the inverter in reverse, thus pumping the voltages of both ends of the power module and easily resulting in damage to the inverter. The internal control of the inverter will suppress such situation according to the load condition; when the brake performance fails to reach requirements of customers, external braking resistor will be required to realize prompt release of energy. External braking resistor belongs to the energy-consumption braking mode, of which the energy will be all dissipated to power braking resistor. Therefore, the selection of power and resistance value of the braking resistor must be reasonable and effective. The following is the introduction of the recommended braking resistor powers and resistance values for partial models of Sunfar inverters. Users can appropriately change the values according to the load condition, but the values shall be within the scope required by Sunfar inverters.

Model	Applied motor (KW)	Power of brake resistance (KW)	Brake resistance (Ω)	Brake torque (%)
E380-2S0015	1.5	0.4	75	100
E380-2S0022	2.2	0.6	50	100
E380-2S0037	3.7	1	35	100
E380-4T0015G/0022P	1.5	0.5	300	100
E380-4T0022G/0037P	2.2	0.65	200	100
E380-4T0037G/0055P	3.7	1.0	125	100
E380-4T0055G/0075P	5.5	1.5	85	100
E380-4T0075G/0110P	7.5	2.0	65	100
E380-4T0110G/0150P	11	2.5	50	100
E380-4T0150G/0185P	15	3.6	35	100
E380-4T0185G/0220P	18.5	4.5	30	100
E380-4T0220G/0300P	22	5.5	25	100
E380-4T0300G/0370P	30	6.5	20	100
E380-4T0370G/0450P	37	8.5	15	100
E380-4T0450G/0550P	45	12	12	100
E380-4T0550G/0750P	55	15	10	100
E380-4T0750G/0900P	75	18	8	100
E380-4T0900G/1100P	90	18	8	100
E380-4T1100G/1320P	110	25	6	100
E380-4T1320G/1600P	132	30	5	100
E380-4T1600G/1850P	160	36	4	100
E380-4T1850G/2000P	185	42	3.5	100
E380-4T2000G/2200P	200	50	3	100
E380-4T2200G/2500P	220	50	3	100
E380-4T2500G/2800P	250	60	2.5	100
E380-4T2800G/3150P	280	60	2.5	100
E380-4T3150G/3500P	315	75	2	100
E380-4T3500G/4000P	350	75	2	100
E380-4T4000G/4500P	400	90	1.5	100

If the braking effect is not obvious, please decrease brake resistance and increase power of brake resistance according to proportion.



The braking resistor power is the estimated value under the intermittent working of the braking resistor. The power level of the braking resistor shall be appropriately increased when the braking resistor continuously works for relatively long (over 5s), on the premise of the same resistance value.

3. Remote Control Panel 1

3.1 Remote Control Panel Wiring Diagram




Fig. C-5 Remote Control Panel Wiring Diagram

3.2 Description of remote keyboard connection

1. Install the sending dock of the remote keyboard on the inverter, and install its receiving dock at the designation place for operation, which communicates with the sending dock through the 6-core communication cable (connected through RS485 interface).
2. The remote keyboard needs connecting with the external DC15-24V (18V recommended) for power supply.

4. Remote Control Panel 2 (RMKB001 Remote Control Panel)

4.1 Scope of application

RMKB001 type remote control panel applies to the remote control and operation of the E320, E380 and C300 series variable frequency speed controllers produced by Shenzhen Sunfar Electric Technologies Co., Ltd.

This remote control panel can be used at the same time with the operation panel of the inverter, and the viewing, modification and storage of parameters are valid at the same time.

RMKB001 remote control panel requires the independent 10-24 DC power supply. The 24V DC power supply of terminal of the inverter can be selected when the remote control wiring length is <100m and impedance is <50Ω (refer to the basic wiring diagrams C-6 and C-7).

4.2 Main Specifications

1. Wiring method: RS485 point to point communication
2. Remote control distance: 1~1000m
3. Power supply: DC10~24V / 250mA

RMKB001 remote control panel requires independent DC10~24V power supply, when remote control wire length is less than 100m, and wire resistance is less than 50Ω, please choose inverter terminal DC24V (Please refer to basic wiring diagram C-6 and C-7).

4.3 Inverter Basic Setting

Before using remote control panel, please carefully check parameters as follows:

1. Communication setting: (F9.0 = 0014), baud rate: 9600bps, parity calibration
2. Inverter address: 0
3. Inverter response delay time: less than 10ms.
4. Master - slave mode: slave (F9.3 = 0010)

4.4 Remote control

When the inverter requires to be conducted remote start/stop control, please set the “Running command channel” of the inverter to be “Serial port communication” mode ([F0.4] = ###2); when this mode is selected for the inverter, the external control terminal, and the operation panel of the inverter will lose the control function.

If the operation panel of the inverter requires emergency stop function when the inverter is controlled through the remote control panel, please set “STOP key valid for all control modes” (Running command channel [F0.4] = ##12). At this time, when the inverter is stopped through the “STOP” key on its panel, it is stopped according to the fault mode, displaying “Fu.16”.

Please set the “Select frequency input channel/mode” parameter of the inverter as “RS485 interface” ([F0.1]=2) if requiring to adjust or set frequency with the remote control panel, and then directly adjust the frequency with the UP or DOWN key of the remote control panel; or, set the frequency through digital setting ([F0.2]) on the remote control panel.

4.5 Basic Wiring

Remote control panel has two basic wiring methods, user can choose any one.




Fig. C-6 Wiring Method 1




Fig. C-7 Wiring Method 2



When the wiring length is over 100m, please separately supply power to the remote control panel, and the 24V power supply of the inverter cannot be accessed to.

4.6 Basic function

RMKB001 remote control panel features most functions of the standard operation panel of the inverter, mainly including:

- 1) Viewing, modification and storage of parameters

Through the remote control panel, all parameters from F0-FC sets can be viewed (except the retention parameters), and only parameters of F0-F9 sets can be modified.

When the parameter modification is locked by the parameter write protection function, only the legal parameters can be modified.

- 2) Start/stop control of the inverter
- 3) Fault display, viewing and resetting
- 4) Viewing of running parameters



Partial parameters cannot be conducted valid upper/lower limit suppression when internal parameters of the inverter are modified through the remote control panel, and when the data scope exceeds the limit, it will result in failure of the parameter setting.

4.7 Operating instructions

The operation method of RMKB001 remote control panel is identical with that of the standard keyboard of the inverter produced by Sunfar, and please refer to the relevant description of any of C320, E380 or C300 series inverter.

4.8 Product Appearance and Dimension Size




Fig. C-8 Product Appearance




Fig. C-9 Dimension Size: 150.5 * 77.5 mm
Sheet thickness ≤ 1.5mm