

# **NK105 G2F/G3F Integrated CNC System**

## **Manufacturers' Manual**

---

3rd Edition

Weihong Electronic Technology Co., Ltd.

The copyright of this manual belongs to Weihong Electronic Technology Co., Ltd. (hereinafter referred to as Weihong Company). This manual and any image, table, data or other information contained in this manual may not be reproduced, transferred, or translated without any prior written permission of Weihong Company.

The information contained in this manual is constantly being updated. You can login to the official website of Weihong Company <http://en.weihong.com.cn> to download the latest PDF edition for free.

# Preface

## About This Manual

This manual is intended for machine tool builders and users. If you use the CNC system for the first time, you need to read through the manual. If you are experienced with the system, you can search for the desired information via the contents.

With 8 chapters, this manual can be divided into 4 parts, as follows:

- 1) Part 1: preface, introducing the precautions about transportation and storage, installation, wiring, debugging, usage, and so on. You need to read them carefully beforehand to ensure safe operation.
- 2) Part 2: an overview of hardware, including chapter 1, chapter 2 and 7. Chapter 1 introduces system composition, installation dimensions as well as IO wiring of the control box. Chapter 7 introduces parameter setting of drivers of varied brands as well as wiring diagrams between the drivers and the controller.
- 3) Part 3: introduction to software operations, including chapter 3~5. In these chapters, each function and its user interface is illustrated in details. Besides, related parameter setting is listed. This part helps you get familiar with operation unit and command of the system.
- 4) Part 4: software license agreement. You can refer to chapter 8.

## Applicable Product Models

This manual is applicable to NK105G2F/G3F CNC system. Refer to the table below for details:

Product Model	Remarks
NK105G2F/G3F Integrated CNC System	Herein referred to NK105G2/G3F as abbreviation.

## Contact Us

You can contact us by the following information for technical support and pre-sales/after-sales service:

Company Name: Weihong Electronic Technology Co., Ltd.  
 Headquarters Address: No. 1590, Huhang Rd., Fengxian, Shanghai, PRC 201400  
 Tel: +86-21-33587550  
 Fax: +86-21-33587519  
 Website: <http://en.weihong.com.cn>

## Revision History

You can refer to the following table for the revision records of each edition.

Date	Edition	Revision Contents
2016.03	R3	Main revision contents are: 1) Document style updated. 2) Picture of NK105 four axes control box and dimensional diagram of the handheld box added in chapter 1.1. 3) Terminals of NK105G2F/G3F control box revised in chapter 1.3. 4) Contact information updated. 5) Other revisions.

## Precautions:

Precautions can be divided into caution and warning according to the degree of possible loss or injury in case of negligence or omission of precautions stipulated in this manual.



: General info, mainly for informing, such as supplementary instructions and conditions to enable a function. In case of negligence or omission of this kind of precautions, you may not activate a function. Note that in some circumstances, negligence or omission of even this kind of precautions could cause physical injury or machine damage.



: Warning info requiring special attention. In case of negligence or omission of this kind of precautions, you may suffer physical injury, or even death, machine damage or other losses.



### 1) Precautions Related to Storage and Transportation

- The products should be transported properly in terms of the weight;
- An excess of specified quantity of stacking products is prohibited;
- Climbing, standing or placing heavy loads on the products is prohibited;
- Dragging or carrying the products via cables or devices connected to them is prohibited;



## 2) Precautions Related to Installation

- Only when this equipment installed in the qualified electricity cabinet can it be used. The construction of the cabinet must reach IP54 grade of protection;
- Paste sealing strips on the joint of the cabinet to seal all the cracks;
- Cable entry should be sealed while easy-to-open on the spot;
- A fan or heat exchanger should be adopted for the heat dissipation and air convection of the cabinet;
- If a fan is adopted, air strainer is a must in air inlet or air outlet;
- Dust or cutting fluids may have access to the CNC device via the tiny cracks and tuyere. Therefore it is necessary to pay attention to the surroundings and air flow direction of the air vent to make sure that the outflow gas is towards pollution source;
- 100 mm space should be preserved between the back of the CNC device and the cabinet wall
- for plugging cable connected with the device and the ventilation & heat dissipation in the cabinet;
- Space between this device and other equipment should also be preserved according to the requirements;
- The product should be installed firmly and without vibration. During installing, casting, knocking, striking, or loading on the product is forbidden;
- To reduce electromagnetic interference, power-supply components used should be above AC or DC 50V and the space between cable and CNC device should be preserved above 100mm;
- It will be better if CNC device is installed at a position facilitating debugging and maintenance.

## 3) Precautions Related to Wiring

- Only qualified people are allowed to participate in the wiring and checking;
- The CNC device should be grounded reliably and grounding resistance should be less than 4 ohm. Neutral line is absolutely not allowed to replace earth wire. Otherwise, it may result in malfunction of the device due to the interference;
- Wiring should be firm and steady, or misoperation may occur;
- Voltage values and positive & negative polarity of any connection plug should be in accordance with specifications set forth in the manual, or it may result in breakdowns such as short circuit and permanent damage to the device;
- To guard against electric shock or CNC device damage, fingers should keep dry before



plugging or touching switch;

- The connecting wire should not be damaged and squeezed, or the leakage or short circuit may occur;
- It is prohibited to plug or open the chassis of CNC device when power on.

#### **4) Precautions Related to Running & Debugging**

- Parameters setting should be checked before running, since wrong setting may lead to accidental movements;
- Modification to parameters should be within the allowable range, or such breakdowns as unsteady running and machine damage will occur.

#### **5) Precautions in Use**

- Before power-on, please make sure that the switch is on blackout to avoid occasional start-up;
- Please check the electromagnetic compatibility during electrical design in order to avoid or reduce electromagnetic interference to the CNC device. A low pass filter should be employed to reduce electromagnetic interference if there are other electrical devices nearby;
- It is not allowed to frequently power on and power off. It is recommended to power up the machine again at least one (1) minute later after power failure or blackout.



#### **1) Precautions Related to Product and Manual**

- Matters related to restrictions and functions available stipulated in the manuals issued by the machine manufacturer are prior to those in this manual;
- This manual assumes all the optional functions are available, which you must confirm through manuals issued by the machine manufacturer;
- Please refer to manuals issued by the machine manufacturer for the instructions of machine tools;
- Functions, and software interfaces vary with the system and the version of software. Before using the system, you must confirm the specifications.



**2) Precautions When Opening the Package**

- Please make sure that the products are what you have ordered;
- Check if the products are damaged in transit;
- Check if the components and accessories are damaged or missing in terms of the detailed list;
- Please contact us promptly if product discrepancy, accessory missing or transit damage occurs.

# Contents

<b>1. Summarization.....</b>	<b>1</b>
<b>1.1. Basic Configuration .....</b>	<b>1</b>
<b>1.2. Introduction to Operation Panel .....</b>	<b>3</b>
1.2.1. NK105G2 Operation Panel .....	3
1.2.2. NK105G3 Operation Panel .....	5
<b>1.3. Introduction to NK105 Four Axes Control Box .....</b>	<b>8</b>
1.3.1. Terminals on Control Box When General Software Is Installed .....	9
1.3.2. Interfaces on Control Box .....	12
<b>1.4. Mechanical Dimension of Control Box and Handheld Box .....</b>	<b>12</b>
<b>2. Principle of System Signal .....</b>	<b>14</b>
<b>2.1. Binary Input Signal .....</b>	<b>14</b>
2.1.1. Binary Input .....	14
2.1.2. Binary Output .....	15
<b>2.2. Open Collector Output Signal.....</b>	<b>16</b>
<b>2.3. Differential Output Signal.....</b>	<b>16</b>
<b>2.4. Analog Output Signal .....</b>	<b>16</b>
<b>3. System Page .....</b>	<b>17</b>
<b>3.1. Operation Mode and State.....</b>	<b>17</b>
3.1.1. Operation Mode .....	17
3.1.2. Operation State .....	17
<b>3.2. Coordinate System .....</b>	<b>18</b>
3.2.1. Machine Coordinate System .....	19
3.2.2. Workpiece Coordinate System .....	19
<b>3.3. Spindle State.....</b>	<b>21</b>
<b>3.4. Manual Speed Type.....</b>	<b>21</b>
<b>3.5. Menu Page .....</b>	<b>21</b>



3.5.1.	Local Files/USB Files .....	22
3.5.2.	Operations.....	22
3.5.3.	Introduction to Parameters.....	25
3.5.4.	Parameter Upkeep (Parameter Maintenance).....	27
3.5.5.	System Upkeep.....	28
3.5.6.	Diagnosis .....	31
<b>4.</b>	<b>Machining Operations.....</b>	<b>33</b>
<b>4.1.</b>	<b>System Startup .....</b>	<b>33</b>
<b>4.2.</b>	<b>Axis Direction Adjustment .....</b>	<b>33</b>
<b>4.3.</b>	<b>Pulse Equivalent Adjustment.....</b>	<b>34</b>
<b>4.4.</b>	<b>Setup of Machine Stroke .....</b>	<b>36</b>
<b>4.5.</b>	<b>Port Polarity Adjustment .....</b>	<b>36</b>
<b>4.6.</b>	<b>Back to Machine Origin .....</b>	<b>37</b>
4.6.1.	Parameter Setup of Backing to Machine Origin.....	38
4.6.2.	Operation Mode of Backing to Machine Origin .....	38
<b>4.7.</b>	<b>Spindle Debugging .....</b>	<b>39</b>
4.7.1.	Spindle Setup .....	39
4.7.2.	Park MCS Site.....	39
4.7.3.	Spindle Stop .....	40
<b>4.8.</b>	<b>Manual Machining .....</b>	<b>41</b>
4.8.1.	Manual Selection of Manual Machining .....	41
4.8.2.	Parameter Setting of Manual Machining.....	42
<b>4.9.</b>	<b>Automatic Machining.....</b>	<b>43</b>
4.9.1.	WCS Selection .....	43
4.9.2.	Load File .....	43
4.9.3.	Set Workpiece Origin .....	44
4.9.4.	Start Machining .....	45
<b>4.10.</b>	<b>Adjustment during Automatic Machining.....</b>	<b>45</b>
4.10.1.	Feedrate Override Adjustment .....	45
4.10.2.	Spindle Speed Adjustment .....	45
4.10.3.	Machining Pause and Jiggle .....	45

4.10.4.	Continuing Machining after Pause .....	46
4.10.5.	Soft Limit Handling .....	46
4.10.6.	Hard Limit Handling.....	46
<b>5.</b>	<b>Machining Operation of NK105G3F .....</b>	<b>48</b>
<b>5.1.</b>	<b>Manual Machining .....</b>	<b>48</b>
5.1.1.	Mode Selection of Manual Machining .....	48
5.1.2.	Parameter Setting of Manual Machining.....	48
<b>5.2.</b>	<b>Automatic Machining.....</b>	<b>48</b>
5.2.1.	Load File .....	48
5.2.2.	WCS Selection .....	49
5.2.3.	Set Workpiece Origin .....	49
5.2.4.	Start Machining .....	49
<b>5.3.</b>	<b>Adjustment during Automatic Machining.....</b>	<b>49</b>
5.3.1.	Feedrate Override Adjustment .....	49
5.3.2.	Spindle Speed Adjustment .....	50
5.3.3.	Machining Pause and Jiggle .....	50
5.3.4.	Soft/Hard Limit Handling .....	50
5.3.5.	E-stop Handling.....	50
<b>6.</b>	<b>System Update .....</b>	<b>51</b>
<b>6.1.</b>	<b>Software Update .....</b>	<b>51</b>
<b>6.2.</b>	<b>System Mirror Update.....</b>	<b>51</b>
<b>7.</b>	<b>References.....</b>	<b>53</b>
<b>7.1.</b>	<b>System Parameters.....</b>	<b>53</b>
7.1.1.	Parameters of Operator's Access .....	53
7.1.2.	Parameters of Manufacturer's Access .....	56
<b>7.2.</b>	<b>Driver Parameters and Wiring Diagrams .....</b>	<b>60</b>
7.2.1.	Driver parameters .....	60
7.2.1.1.	Parameter Setting of YASKAWA $\Sigma$ -II Servo Driver .....	60
7.2.1.2.	Parameter Setting of DELTA ASDA-A Servo Driver .....	61
7.2.1.3.	Parameter Setting of DELTA ASDA-A2 Servo Driver.....	63
7.2.1.4.	Parameter Setting of PANASONIC MINAS_A4 Servo Driver .....	65

7.2.1.5.	Parameter Setting of FUJI FALDIC- $\beta$ Servo Driver .....	66
7.2.1.6.	Parameter Setting of STONE GS Servo Driver .....	67
7.2.1.7.	Parameter Setting of MITSUBISHI MR-E Servo Driver .....	69
7.2.2.	Wiring Diagram of NK105G2F/G3F and Driver .....	71
7.2.2.1.	Wiring Diagram of NK105 and Differential Input Stepping Driver .....	71
7.2.2.2.	Wiring Diagram of YASKAWA $\Sigma$ -II Servo Driver .....	72
7.2.2.3.	Wiring Diagram of DELTA ASDA Servo Driver.....	72
7.2.2.4.	Wiring Diagram of PANASONIC MINAS_A4 Servo Driver .....	73
7.2.2.5.	Wiring Diagram of MITSUBISHI MR-E Servo Driver .....	74
7.2.2.6.	Wiring Diagram of FUJI FALDIC- $\beta$ Servo Driver .....	74
7.2.2.7.	Wiring Diagram of STONE GS Servo Driver .....	75
<b>8.</b>	<b>Software License Agreement .....</b>	<b>76</b>



# 1. Summarization

---

Independently-developed by Weihong and based on embedded industrial control platform, the four axes integrated CNC system NK105G2F/G3F provides a whole set of solutions to engraving machines.

The integrated CNC system NK105G2F/G3F is composed of a host system and an operation panel. Also called control box, the host system integrates system control card, terminal board and other parts, and connects with the operation panel via a 15-pin extension cable.

The up and down ends at the back of the control box are used to inlay terminals while the left side includes an USB interface and a DB15 interface. The DB15 interface is for connection with the operation panel, while the USB interface for external connection with USB equipment (e.g. USB flash drive).

Also called handheld box, the concise and portable operation panel is connected with the host system via a 15-pin extension cable, so it can work independently without the distribution box to facilitate machine tool control. And its moving distance is only restricted by the length of extension cable.

## 1.1. Basic Configuration

NK105G2F/G3F system is composed by handheld box and control box. Refer to following table for details.

Table 1 Basic configuration

System \ Components	Handheld box specification	Control box specification
NK105G2F	NK105G2 handheld box	NK105 four axes control box
NK105G3F	NK105G3 handheld box	NK105 four axes control box

See Fig. 1-1 for picture of NK105 four axes control box.




Fig. 1-1 Picture of NK105 four axes control box

See Fig. 1-2 for picture of NK105G2 handheld box. Note that apart from different keypads, NK105G3 handheld box is similar with that of NK105G2.



Fig. 1-2 Picture of NK105G2 handheld box

## 1.2. Introduction to Operation Panel

Operation panel offers a convenient way to conduct system operations, e.g., setting parameters, adjusting axis movement direction and feeds, etc.

### 1.2.1. NK105G2 Operation Panel

The operation panel of NK105G2F is NK105G2 panel. See Fig. 1-3 for the layout of NK105G2 panel keys.





Fig. 1-3 Panel keys of NK105G2

#### ◆ Function Information of Each Single-key

NK105G2F operation panel is both light and concise. With a single-key or combination key, all the operations can be realized. The usage of each single-key is: press a key lightly to complete the called function and then release the key, except for the mode shift key which becomes effective when released. See Table 2 for the function information of each single-key.

Table 2 Single-key function table

Key icon	Key name	Function
	Override+	Increase of feedrate override; input of number 7; increase of spindle gear with the help of the auxiliary key when the spindle port has input.











Key icon	Key name	Function
	Y+	Positive movement of Y axis; input of number 8; switching between MCS and WCS with the help of the auxiliary key
	Z/A+	Positive movement of Z/A axis; input of number 9
	X-	Negative movement of X axis; input of number 4; homing all the axes with the help of the auxiliary key
	Spindle ON/ OFF	Start or stop of spindle under manual mode; input of number 5; backing to workpiece origin with the help of the auxiliary key
	X+	Positive movement of X axis; input of number 6
	Override-	Decrease of feedrate override; input of number 1; decrease of spindle gear with the help of the auxiliary key when the spindle port has input
	Y-	Negative movement of Y axis; input of number 2
	Z/A-	Negative movement of Z/A axis; input of number 3
	Speed switchover	Switching between jog/rapid jog speed in jog mode; input of number 0; tool measurement with the help of auxiliary key
	Clearing	XY clearing; input of minus; Z/A clearing with the help of auxiliary key
	Menu	Entering menu page; input of decimal point; entering image update page at the time of system start-up
	Start	Start key; breakpoint resume with the help of the auxiliary key
	Up	Suspend processing; up direction key
	ESC	Stop processing; cancellation of various selections, inputs and operations
	Shift	Auxiliary key; switching between stepping mode and jog mode under machining page
	Down	Down direction key
	OK	Entering jog/rapid jog speed adjustment page under menu page; confirmation of various selections, inputs and operations

### ◆ Function Information of Combination Key

The usage of combination key: press the auxiliary key first, and then the second; release the two keys simultaneously after the corresponding function is called. See Table 3 for function of combination key.



Table 3 Combination key function table

Key icon	Function
Shift + 	Increase of spindle gear
Shift + 	Switching between WCS and MCS
Shift + 	Homing all the axes
Shift + 	Backing to workpiece origin
Shift + 	Decrease of spindle gear
Shift + 	Moveable tool measurement
Shift + 	Z/A clearing
Shift + 	Breakpoint resume
Shift + 	Entering help page
Shift + 	Jiggle at pause

### 1.2.2. NK105G3 Operation Panel

The operation panel of NK105G3F is NK105G3 panel. See Fig. 1-4 for the layout of NK105G3 panel keys.




Fig. 1-4 Panel keys of NK105G3

### ◆ Function Information of Each Single-key

The operation panel of NK105G3F is both light and concise. With a single-key or combination key, all the operations can be realized. The usage of each single-key: press a key lightly to complete the called function and then release the key, except for the mode shift key which becomes effective when released. See Table 4 for the function information of each single-key.

Table 4 Single-key function table

Key icon	Key name	Function
	Start	Start key; breakpoint resume with the help of the auxiliary key
	Pause	Pause during machining
	Stop	Stop machining
	Down	Down direction button; switching between A-axis and Z-axis
	Spindle ON/OFF	Start or stop of spindle under manual mode
	Menu	Entering menu page; entering image update page at the time of system start-up; entering help page with the help of the auxiliary key
	ESC	Esc key; returning to the previous page
	XY clearing	XY clearing; X clearing with the help of the auxiliary key











Key icon	Key name	Function
	Z/A clearing	Z/A clearing; Y clearing with the help of the auxiliary key
	Shift	Auxiliary key; switching between stepping mode and jog mode under machining page
	Override+	Increase of feedrate override; increase of spindle gear with the help of the auxiliary key when the spindle port has input
	Override-	Decrease of feedrate override; decrease of spindle gear with the help of the auxiliary key when the spindle port has input
	Back to workpiece origin	XY axes backing to workpiece origin; XY axes backing to fixed point with the help of the auxiliary key; input of number 0
	X-	Negative movement of X axis; input of number 4
	X+	Positive movement of X axis; input of number 6
	Y+	Positive movement of Y axis; input of number 8; switching between MCS and WCS with the help of the auxiliary key
	Y-	Negative movement of Y axis; input of number 2
	Z/A+	Positive movement of Z/A axis; input of number 9; tool measurement executed with the help of the auxiliary key
	Z/A-	Negative movement of Z/A axis; input of number 3
	Speed switch	Switching between jog speed and rapid jog speed in jog mode; input of number 5
	Positive	Positive movement of A-axis; input of number 7; homing all the axes with the help of the auxiliary key
	Negative	Negative movement of A-axis; input of number 1

◆ **Function Information of Combination Key**

The usage of combination key: press the auxiliary key first, and then the second; release the two keys simultaneously after the corresponding function is called.

Table 5 Combination key function table

Key icon	Function
+	Breakpoint resume

Key icon	Function
Shift + 	Entering help page
Shift + 	X clearing
Shift + 	Y clearing
Shift + 	Increase of spindle gear
Shift + 	Decrease of spindle gear
Shift + 	XY axes backing to fixed point
Shift + 	Homing all the axes
Shift + 	Switching between MCS and WCS
Shift + 	Moveable tool measurement
Shift + 	Jiggle function

## 1.3. Introduction to NK105 Four Axes Control Box

NK105 terminals are inlaid at the up and down ends of the control box. The detailed wiring diagram is shown in Fig. 1-5, when general software is installed.




Fig. 1-5 NK105 four axes control box

### 1.3.1. Terminals on Control Box When General Software Is Installed

The detailed explanation of terminal pin signals is as shown in Table 6 and Table 7.

Table 6 Output signals

Silk-printed name	Corresponding signal	Remark
GY01(ZD-)	Negative differential signal of Z-axis direction	ZD+ and ZD- are differential pair signals of Z-axis direction.

Silk-printed name	Corresponding signal	Remark
GY02(ZD+)	Positive differential signal of Z-axis direction	
GY03(ZP-)	Negative differential signal of Z-axis pulse	ZP+ and ZP- are differential pair signals of Z-axis pulse.
GY04(ZP+)	Positive differential signal of Z-axis pulse	
GY05(YD-)	Negative differential signal of Y-axis direction	YD+ and YD- are differential pair signals of Y-axis direction.
GY06(YD+)	Positive differential signal of Y-axis direction	
GY07(YP-)	Negative differential signal of Y-axis pulse	YP+ and YP- are differential pair signals of Y-axis pulse.
GY08(YP+)	Positive differential signal of Y-axis pulse	
GY09(XD-)	Negative differential signal of X-axis direction	XD+ and XD- are differential pair signals of X axis direction.
GY10(XD+)	Positive differential signal of X-axis direction	
GY11(XP-)	Negative differential signal of X-axis pulse	XP+ and XP- are differential pair signals of X-axis pulse.
GY12(XP+)	Positive differential signal of X-axis pulse	
GY13(GREEN)	Green signal output	
GY14(RED)	Red signal output	
GY15(YELLOW)	Yellow signal output	
GY16(SPIN)	Spindle-on output	
GY17(SCOOL)	Spindle coolant output	
GY18(OIL)	Auto lube output	

Silk-printed name	Corresponding signal	Remark
GY19	Workpiece cooling output	
GY20	Spindle reverse output	
GY21	Reserved output	
GY22	Reserved output	
GY23(AP+)	Positive differential signal of A-axis pulse	AP+ and AP- are differential pair signals of A-axis pulse.
GY24(AP-)	Negative differential signal of A-axis pulse	
GY25(AD+)	Positive differential signal of A-axis direction	AD+ and AD- are differential pair signals of A-axis direction.
GY26(AD-)	Negative differential signal of A-axis direction	
SAVCOM	Analog voltage output	
SAV		
+24V OUT	+24V output	For connection with 24V power supply

Table 7 Input signals

Silk-printed name	Corresponding signal	Remark
GND	Power GND or COM port	The two GND of power port are connected with power GND and machine common ground point respectively, while those of other ports can be used as COM signals.
+24V IN	+24V DC power input	Connected with +24V DC power supply
GX01(XORG)	Machine origin signal of X-axis	For external connection with mechanical, photoelectrical or proximity switch.
GX02(XLM+)	Positive limit signal of X-axis	
GX03(XLM-)	Negative limit signal of X-axis	
GX04(YORG)	Machine origin signal of Y-axis	
GX05(YLM+)	Positive limit signal of Y-axis	
GX06(YLM-)	Negative limit signal of Y-axis	
GX07(ZORG)	Machine origin signal of Z-axis	
GX08(ZLM+)	Positive limit signal of Z-axis	
GX09(ZLM-)	Negative limit signal of Z-axis	

Silk-printed name	Corresponding signal	Remark
GX10(AORG)	Machine origin signal of A-axis	
GX11(ALM+)	Positive limit signal of A-axis	
GX12(ALM-)	Negative limit signal of A-axis	
GX13	Reserved input 0	
GX14	Reserved input 1	
GX15	E-stop alarm signal input	Connected with E-stop button on the machine tool
GX16	Tool sensor signal input	

### 1.3.2. Interfaces on Control Box

There are two interfaces on the NK105 four axes control box, namely input interface of +24V power and USB interface, which are for external connection with 24V power and USB device respectively. See following for details.

◆ **Input interface of +24V power**

The +24V power input interface is for external connection with 24V power. And its pin definition is as shown in Fig. 1-6, in which is connected to the grounding copper plate of machine tools, namely to earth.




Fig. 1-6 Pin definition of +24V power input interface


◆ **USB interface**

The USB interface is used for externally connection with USB device (e.g., USB flash drive).


## 1.4. Mechanical Dimension of Control Box and Handheld Box

The integral thickness of NK105G2F/G3F host system is 218.3mm, with terminals embedded at its up and down ends. See Fig. 1-7 for dimensional drawing of the control box and Fig. 1-8 for dimensional drawing of the handheld box.





Dimensional drawing



Cut-out drawing

Fig. 1-7 Dimensional drawing and cut-out drawing of NK105G2F/G3F control box




Fig. 1-8 Dimensional drawing of NK105 handheld box

## 2. Principle of System Signal

The signal types of NK105G2F/G3F system can be divided into the following 4 types: binary input signal, open collector output signal, differential output signal and analog output signal.

### 2.1. Binary Input Signal

Binary input signal is active low and supports NO and NC input signals (through modifying input port polarity in the software). Conducting to GND (i.e. grounding signal) in NO connection means signal detected, and disconnecting with GND in NC connection means signal detected.

#### 2.1.1. Binary Input

◆ **Connection of Binary Input and External Circuit**

The wiring method between binary input signal and a mechanical switch is shown in Fig. 2-1.




Fig. 2-1 Connection of mechanical switch and binary input

Binary input signal can be connected with a photoelectric switch or a proximity switch of NPN (NO or NC type). Its joining method is as below.




Fig. 2-2 Binary input of NPN type connecting with photoelectric switch or proximity switch

◆ **Power Requirement**

It is recommended to adopt DC24V/4.5A switch power for relays on the terminal board. If there are a great many DC 24V relays controlled by binary output signal, you can appropriately expand the power source capacity or add extra power (forcibly sharing ground with external power supply). Z axis brake and solenoid valve also need DC 24V instead of external power to the greatest extent to reduce the interference to CNC device by solenoid valve, etc.

## 2.1.2. Binary Output

◆ **Signal characteristics**

The internal equivalent circuit of binary output is shown in Fig. 2-3.




Fig. 2-3 Equivalent circuit of binary output interface

◆ **Technical parameters**

Supply voltage: 24V DC power.

Current: the binary output is OC (open-collector) output, whose maximum allowable sucked current is 500mA.

◆ **Connection of Binary Output and External Circuit**

The connection of solid-state relay and binary outputs is shown in Fig. 2-4.




Fig. 2-4 Connection of solid-state relay and binary output

## 2.2. Open Collector Output Signal

The output ports on the control box are open collector output, with maximum output current 500mA.

## 2.3. Differential Output Signal

Differential signal refers to two equivalent signals with opposite phases sent by driving end, and the voltage difference of these two signals is used for deciding whether the logical status of differential signal is "0" or "1".

Pulse command format of controlling driver motion is pulse + direction, negative logic. And this signal adopts differential signal transmission mode.

## 2.4. Analog Output Signal

SVC is controllable voltage output of 0~10V and externally connected with analog voltage frequency command inputs of inverter. Therefore, altering the controllable voltage leads to inverter frequency change and a change of inverter frequency will change the spindle speed.




Fig. 2-5 Electric circuit of analog output signal

## 3. System Page

Manual operation mode is activated by default when the system is started. Default interface is machining page, on which axis, coordinate, operating state, spindle state, manual speed as well as operation mode are displayed, as shown Fig. 3-1. Besides, tips for operation will be shown on bottom part of the page.




Fig. 3-1 Machining page

### 3.1. Operation Mode and State

#### 3.1.1. Operation Mode


All of the operation modes are listed below and a good understanding of them is vital for proper operation.

##### ◆ Auto Mode

Under automatic operation mode, the machine tool generates motions according to the file loaded in advance. Therefore, the machining file must have been loaded.

##### ◆ Manual Mode

To meet the requirements of manual motion under different situations, the system provides “Jog” and

“Stepping” modes, which can be switched freely by pressing .

- Jog mode: this mode is fit for tuning machine coordinates roughly without concrete step-size.
- Stepping mode: this mode is applicable to tuning machining coordinates accurately.

#### 3.1.2. Operation State

All of the operation states are listed below; operation mode and operation state together decide the state of the machine tool.

◆ **IDLE State**

Idle state is the most common state. Under this state, the machine has no motion to output, but is ready to accept any new task.

◆ **ESTOP State**

This is an abnormal state. When there is an error in the hardware of the machine tool, the system will enter into this state and implement the predetermined protection actions, such as closing spindle motor and cooling pump. Under this state, the machine tool is locked and cannot carry out any new action.

◆ **Running State**

When the machine tool is implementing any action, the system enters into Running State.

◆ **Pause State**



When the machine tool is running, if the key of “pause during machining” is pressed, the system will enter into PAUSE state and wait for further instruction. At this time, pressing the “Start” key will make the system enter into “Running” state, while pressing the “Stop/Cancel” key will make the system stop.

◆ **LOCK State**

During soft limit operation, the system turns into lock state, an internal state.

## 3.2. Coordinate System

Machine coordinate system (MCS) and workpiece coordinate system (WCS) are included, which can be

switched by combination key  + . Workpiece coordinate system is adopted in Fig. 3-1, with number 1~6 in front of axis name referring to WCS G54~G59 correspondingly. If machine coordinate system (MCS) is adopted, number in front of the axis is absent, while an asterisk mark “\*” will appear after the axis returned to the machine origin.

Coordinate system is a terminology to describe the motion of a machine tool. For the sake of unification, standard coordinate system adopts the right-hand rule. See Fig. 3-2.




Fig. 3-2 A coordinate system conforming to right-hand rule

For milling machines, the direction of machine axes is decided by both the type of machine tool and the layout of each component. The basic coordinate axes of milling machines are X-axis, Y-axis, and Z-axis:

—Z-axis is coincidental with spindle axis and the direction of the cutter moving away from workpiece is its positive direction (+Z).

—X-axis is perpendicular to Z-axis and parallel to the clamped surface of workpiece. For the single column vertical milling machine, if the user faces the spindle and looks in the column direction, right moving direction is its positive direction (+ X).

—X-axis, Y-axis and Z-axis constitute a coordinate system adhering to the right-hand rule.

### 3.2.1. Machine Coordinate System

Machine coordinate system is a set of fixed right-hand coordinate system. Its coordinate origin is always fixed with respect to a certain position on the machine tool. Therefore, at any time, a certain point in space can be exclusively fixed by the machine coordinate system.

The machine coordinate system requires the machine available of the homing function, or this concept will only appear in the software.

### 3.2.2. Workpiece Coordinate System

As a set of right-hand coordinate system for the programmer, workpiece coordinate system is used in programming. To establish it, the programmer can select a given point on the workpiece as the origin (also called program origin). The origin of workpiece coordinate system (namely the workpiece origin) is fixed with respect to a certain point on the workpiece, while variable with respect to the machine origin. The origin of workpiece coordinate system should be selected to facilitate simple programming, easy dimension conversion and small machining errors.

Workpiece offset corresponds to WCS G54, G55, G56, G57, G58 and G59. After the system is started, the default WCS is G54, and the relation between workpiece offset and machine coordinate system is as shown in Fig. 3-3.




Fig. 3-3 The relation between workpiece offset and machine coordinate system

One, two or several workpiece offsets can be used in one machining program. As shown in Fig. 3-4, three workpieces are installed on the worktable, so each workpiece has a workpiece origin corresponding to the G code of workpiece coordinate system. To drill a hole on each of the workpiece, with calculation depth as Z-0.14, the programming example is as follows.




Fig. 3-4 Example figure

```

O1801
N1 G20
N2 G17 G40 G80
N3 G90 G54 G00 X5.5 Y3.1 S1000 M03           (Use G54)
N4 G43 Z0.1 H01 M08
N5 G99 G82 R0.1 Z-0.14 P100 F8.0
N6 G55 X5.5 Y3.1                             (Switch to G55)
N7 G56 X5.5 Y3.1                             (Switch to G56)
N8 G80 Z1.0 M09
N9 G91 G54 G28 Z0 M05                         (Switch to G54)
N10 M01
...

```

Program segments N3~N5 are for the first workpiece, within G54 WCS; program segment N6 drills the hole for the second workpiece of the same batch within G55 WCS; program segment N7 drills the third




hole for the third workpiece of the same batch within G56 WCS.



Applicable to all WCSs, public offset is used to adjust the workpiece origin of X, Y and Z axes, without changing the offset value of G54~G59.

Workpiece offset, tool offset and public offset meet the following expression:




$$\text{Workpiece coordinate} = \text{Machine coordinate} - \text{Workpiece offset} - \text{Tool offset} - \text{Public offset}$$

### 3.3. Spindle State


Including spindle speed gear and spindle stop. In idle state, press  to switch. In machining state,

press combination key to  or  increase or decrease the gear, which is divided into 11 gears from 0.5s to 1.5s with speed increasing sequentially.




Slightly different from NK105G2F system, you can press  to switch between spindle start and stop; and in machining state, press combination key  or  to increase or decrease the spindle speed gear.

### 3.4. Manual Speed Type

Manual speed is divided into manual high speed (also called rapid manual speed) and manual low speed (also called manual speed), which can be switched by pressing . Refer to chapter 5.1.2 for details about speed setting methods.

### 3.5. Menu Page

Press  to enter the menu page. There are altogether 8 parameter items in the menu but the LCD can only show 4 of them at a time, as shown in Fig. 3-5.




Fig. 3-5 Menu page

Press [Up] and [Down] keys to select the desired item and then press [OK] to enter the corresponding sub-menu.

### 3.5.1. Local Files/USB Files

Local file list page or USB file list page is as shown in Fig. 3-6, in which load, delete or copy can be executed. Only one file can be loaded to the system at a time. If several files are selected at the same time, a prompt dialog will appear in loading.





Fig. 3-6 File list page



After  is pressed to execute “③Copy”, a dialog box will pop up asking for confirmation; press [OK] to start copying; if the file is large, the system page will display “Copy Progress...”; wait patiently and do not press any key on the operation panel until copy completed.

### 3.5.2. Operations

The sub-menus under [Operations] are as shown in Fig. 3-7.




Fig. 3-7 Submenus under [Operations]

Press the “Menu” key →3. Operations, and the press [OK] to enter its page, in which select the desired menu item by the “Up” and “Down” key. Following is the [Operation] page.





Fig. 3-8 [Operations] page

◆ **Back REF Point**

Return to the machine origin. For details, see chapter 4.6.

◆ **Rect Machining**

The system offers rectangle milling wizard; after setting parameters successfully, press the “Up” and “Down” keys to select [Load Now], and then press [OK] to load the machining file; and then you can

press  to start machining.

You can also select “2. Load the Last”, and then press [OK] to load the last rectangle milling and return to

the machining page, and then press  to start machining.

Parameters “X Init” and “Y Init” decide the initial position of machining plane; “Height” and “Width” decides the size of machining plane; two kinds of machining mode are available: “Horiz. Mill” (the feed direction of tool is parallel to X axis) and “Long. Mill” (the feed direction of tool is parallel to Y axis); “EachDpth” is the tool machining depth each time; generally, the value of “EngrDpth” (the total depth of several millings) is set bigger than that of “EachDpth”; if the value of “EachDpth” is equal to or bigger than that of “EngrDpth”, only one milling will finish the machining; “NoseGap” means the distance between two adjacent lines, whose value should be set smaller than that of “ToolDia” to avoid missing millings.



After setting parameters and moving the cursor to “Load Now”, you still need to press [OK] to load the machining file.

If the input value of “EngrDpth” is too big, the system will send the warning information “Too many file layers generated, continue?”, as shown in Fig. 3-9. You can press [ESC] to back to modify the value; or press [OK] to load the file anyway, the system staying in the page shown in Fig. 3-9. At this time, if you press a key, its function will not be executed until this dialog box disappears, so it is not allowed to press any key under this state. You can wait patiently until the file is successfully loaded, or you can power off and re-power on the system.




Fig. 3-9 Warning dialog when parameters not properly set

#### ◆ Select Line No.

This page shows the loaded file information, like total line No., start line No. and end line No. The default setting of “StartLine” is the breakpoint position of the current file, and “EndLine” the last line. With this function, you can select any blocks to be processed. After these values are set, press the “Up” or “Down” key to select “Execute Now”, and then press [OK] to start machining instantly.



The default line No. of “StartLine” is the breakpoint line No. under this page.

#### ◆ Machining Info

After this item is selected and [OK] is pressed, the system will analyze the file currently loaded automatically, like calculating the needed time for file machining and the machining range of each axis. The page of analytic result is as shown in Fig. 3-10.

<b>Time: 0: 1: 42</b>		
<b>X :</b>	108	205
<b>Y :</b>	20	117
<b>Z :</b>	0	5

Fig. 3-10 Analytic result of machining

#### ◆ Park MCS Site

For details, refer to chapter 4.7.2.

### ◆ Select WCS

Press “Menu”→ 3. Operations→ 6. Select WCS, and then press [OK] to enter the page shown in Fig. 3-11, displaying the 6 WCSs from G54 to G59.




Fig. 3-11 WCS selection page

After pressing the “Up” and “Down” keys to select the corresponding WCS, press [OK] to confirm the selection. After confirmation, the number before X/Y/Z/A axis will change accordingly, WCSs of G54~G59 corresponding to 1~6 respectively.

### ◆ Array Process

Array machining (array process), i.e. array machining of graphics, is available in NK105G2F/G3F. After selecting a file and specifying rows, columns and row/ column space, press “Load Now” to generate and load the array file. Before starting machining, you can turn to “Machining Info” under “Operations” to see the machining range of the array file.

Operation steps are as follows:

Menu→ Operations→ Array Process→ Load the desired single-workpiece machining file, and set parameters like Rows, Columns, RowSpace, ColSpace and Delay→ Select Load Now and press OK→ Press Start to start array machining. The generated array file can be found under the source file path.



- 1) This function is only available for tool path files of text format, like txt, nc and u00.
- 2) Codes, like G92, M17 and G65, and #variables, like #1 and #2, cannot appear in the tool path file.
- 3) Codes, like M30, M2, when included in the tool path file, will be removed automatically from the newly generated array file.
- 4) Call of a sub-program in the PUBLIC is not allowed in the tool path file.

## 3.5.3. Introduction to Parameters

For details of parameter contents, refer to chapter 7.1.

For parameter modification method, it can be divided into two types.

### ◆ Input of Numeric Value

After entering the parameter modification page, directly input the desired number, and then press [OK] to save it or press [ESC] to return to the previous page. Only when [OK] is pressed can the modification be saved after parameter modification each time.

For example: the modification method for the parameter “REFP Speed” is as follows.

Speed (mm/min)	
X Axis:	1800.000
Y Axis:	1800.000
Z Axis:	1500.000

Fig. 3-12 Modification page of “REFP Speed”

Press “Menu”→ 5. Mfr Param→ 5. REF. PointSet→ 1. REFP Speed, and then press [OK] to enter the page as shown in Fig. 4 3, and then press the “Up” and “Down” keys to select the axis speed parameter to be modified. When the cursor is on an item, press [OK] and enter the new parameter value directly and then press [OK] to save it.



If you switch to another parameter without saving the input value during parameter modification, this new value will not be saved and the original value will be restored.

#### ◆ Selection of Parameter Value

Select the parameter value by directly pressing the “UP” or “Down” key.

For example: the modification method for the parameter “REFP Dir” is as follows.

Homing Direction	
X Axis:	Negative
Y Axis:	Positive
Z Axis:	Positive

Fig. 3-13 Modification page of “REFP Dir”

Press “Menu”→ 5. Mfr Param→ 5. REF. PointSet→ 2. REFP Dir, and then press [OK] to enter the page as shown in Fig. 3-13, and then press the “Up” and “Down” keys to select the axis direction parameter to be modified. When the cursor is on an item, press the [OK] key to enter the interface as shown in Fig. 3-14, the arrow indicating the current parameter value. Press [Up] or [Down] key to select the desired parameter value, and then press the [OK] key to confirm the modification.

Direction of X	
•	Positive
▷	Negative

Fig. 3-14 Selection dialog

### 3.5.4. Parameter Upkeep (Parameter Maintenance)

Press the “Menu” key→ 6. Param Upkeep, and then press [OK] to enter the page, in which select a submenu by pressing the “Up” and “Down” keys.

The submenus under this page are as shown in Fig. 3-15.




Fig. 3-15 Submenu list of parameter upkeep

#### ◆ Backup Parameter

Press [OK] to confirm backing up the parameters. No matter whether the parameter backup is successful or failed, a prompt will be displayed.

#### ◆ Restore Backup

It is used to restore the backup parameters. If the parameters have not been backed up, “Backup File Not Found!” will be displayed.

If the recovery is successful, a prompt of rebooting the system will be displayed, as shown in Fig. 3-16. At this time, you can press [OK] to reboot the system directly, or [ESC] to return to the previous page.




Fig. 3-16 Prompt dialog of system reboot

#### ◆ Factory Params

The action of ex-factory parameter recovery is to clear all the data and parameters interiorly set stored in the system memory chip. It is necessary to perform this action when there are messy codes in the interior file or after upgrade finishes.

Operate following the prompts displayed on the screen. After recovery is successful, a cue to reboot the system will be displayed on the screen, as shown in Fig. 3-16. At this time, you can press [OK] to restart the system, or [ESC] to back to the previous page.

The action of ex-factory parameter recovery won't clear the parameters backup file. Therefore, if this action is carried out accidentally and all the interior parameters are cleared, you can restore the backup parameters by “Restore Backup”.



Modification to this item will not become effective until the system is rebooted.

### ◆ Export Parameters

When software or hardware fault occurs, you can export parameters to an USB flash drive for backup.

### ◆ Import Parameters

Import the parameters in the USB flash drive to the system, avoiding repeatedly setting parameters. After import is successful, the system will display a prompt of system reboot as shown in Fig. 3-17.




Fig. 3-17 Prompt dialog of successful parameter import

## 3.5.5. System Upkeep

Also called system maintenance. Press “Menu”→ 7. System Upkeep, and then press [OK] to enter its page, in which select a submenu by pressing the “Up” and “Down” keys.

The submenus under this page are as shown in Fig. 3-18.




Fig. 3-18 Submenu list of system upkeep

### ◆ Language

Currently, the system supports two kinds of language: Chinese and English, which can be switched in the following page.






Fig. 3-19 Chinese-English selection page

#### ◆ Export Log

A Log.txt will be generated after the log is exported to an USB flash drive. After log export finishes, “Log Exported Successfully” will be displayed on the screen. Press [OK] or [ESC] to return to the previous page.

#### ◆ System Update

After the cursor is on the “System Update” item, press [OK] for confirmation, after which a dialog will pop up asking whether to update the system. After [OK] is pressed again, a dialog as shown in Fig. 3-20 will pop up.




Fig. 3-20 Prompt dialog after successful system update

Press [OK] to reboot the system. After the system displays “USB Available Now!”, press [OK] to enter the system update page, as shown in Fig. 3-21.




Fig. 3-21 System update page

Select a corresponding operation in this page by pressing the “Up” and “Down” keys. “Update public” is to update the Public.dat file; “Delete parameter” is to delete the configuration file in BOOT, which must be executed before “Update system”; “Start system” is to start the original system without upgrading it; “Update system” means deleting the original system and upgrading the system by the new application file in the USB flash drive. Refer to Chapter 6 for the details of system update.

At this time, you can select “Start system” and then press [OK] to exit from system update page, or select “Update system” and then press [OK] to exit from system update page and enter the machining page by booting the new system.

#### ◆ Export Backup

The software will be exported to the USB flash drive for backup, with its backup folder named “backup”.

### ◆ Import Parameter

This menu item is used to import the parameter file (file name: settings.dat) in the USB flash drive into the system. Generally, the parameter file is under the root directory of the USB flash drive. If it is not in the root directory, search for it in the “backup” folder.

### ◆ Version Number

It is used to view the version number of BOOT loader.

### ◆ Register

Move the cursor to “4. Register”, and then press [OK] to enter registration code input page, as shown in Fig. 3-22.




Fig. 3-22 Registration code input page

Register by entering the registration code in this page. Select a letter (end-around) by pressing the “Up” and “Down” keys, and then press [OK] for conformation; for the input of a number, press the corresponding number key.

### ◆ Help

After the cursor is on the item “5. Help”, press [OK] to enter the “Help Message Show Delay” parameter setting page as shown in Fig. 3-23. The value of this parameter is an integer within the range of -1, 1~999999S (-1S meaning no help message popping up automatically).




Fig. 3-23 Help setting page

### ◆ Reboot

After the cursor is on this item, press [OK] to eject its dialog box asking “Sure To Reboot System”, press [OK] to reboot the system.

### ◆ Exit

After the cursor is on this item, pressing [OK] will eject a dialog box, in which pressing [OK] will exit from the system. And then the LCD goes blank. If you want to enter the system again, you need to power off and re-power the system.

### ◆ Delete Log

After the cursor is on this item, pressing [OK] will eject a dialog box, in which pressing [OK] will delete the system log.

◆ **Disk Space**

The menu item is used for viewing the capacity and used space of the system disk.

◆ **Delete Info**

This menu item is used for clearing temporary files in the system to release space.

### 3.5.6. Diagnosis

Press “Menu”→ 8. Diagnosis, and then press [OK] to enter its page, in which select a submenu by pressing the “Up” the “Down” keys.

The submenus under this page are as shown in Fig. 3-24.




Fig. 3-24 Submenu list of system diagnosis



LED diagnosis is only available in NK105G3F.

◆ **System Info**

In this page, you can view the software version, control card No., remaining time and registered times. If an item is wrong, after you pressing [OK] for confirmation, an error prompt “Failed to Read Registration Info” will be displayed. At the same time, the other items cannot be read, either.

◆ **Port List**

For details, see chapter 4.5.

◆ **Keypress Diag**

This menu item is used to check whether panel keys work normally. After entering the test page, the system will display a prompt “Press a key”. Pressing any key at this time will show the name of the pressed key on the screen, as shown in Fig. 3-25. If the pressed key is damaged and out of work, the

screen will display nothing or a wrong key name. Pressing “ESC” will exit from this page.




Fig. 3-25 Keypress diagnosis page

◆ **Import Diag**

This page is only for viewing the polarities of the input ports, instead of changing them.

◆ **Output Diag**

This page is only for viewing the polarities of the output ports displayed by running lights, instead of changing them. The corresponding relation among system output terminal No., terminal board ports and signals is listed in Chapter 4.5.

◆ **LED Diag**

This page is only for checking the work conditions of the LEDs on the NK105G3F handheld box.

In the LED diagnosis page, press K1. If the LEDs work regularly, all of them should become light. Press [ESC] to give up diagnosis and return to the previous menu.

## 4. Machining Operations

---

### 4.1. System Startup

The system interface is as shown in Fig. 4-1 after power on.




Fig. 4-1 System start-up interface

After the system is started, "Back to REF. Point" will be prompted, as shown in Fig. 4-2. Press [ESC] to cancel this operation. You need to adjust the following related parameters sequentially: port polarity (see Chapter 4.5), pulse equivalent (see Chapter 4.3), axis output direction (see Chapter 4.2) and machine stroke (see Chapter 4.4) before homing all the axes.




Fig. 4-2 Prompt to home all the axes after system started

### 4.2. Axis Direction Adjustment

Firstly confirm the positive direction of each axis according to the coordinate system adhering to the right-hand rule before starting machine debugging.

After fixing the positive direction of each axis following the right-hand rule, manually operate the machine to check if the axes move correctly. If the direction is opposite, modify the parameter "Axis OutpDir". Take X-axis as an example, manually move the X-axis, only to find it moves oppositely. To solve this problem, you just need to change the value of X axis in the parameter "Axis OutpDir" from "Positive (Negative)" to "Negative (Positive)".

Press the "Menu" key → 5. Mfr Param → 2. Axis OutpDir, and then press the [OK] key to enter the interface as shown below.

*Axis Output Dir	
X Axis:	Negative
Y Axis:	Positive
Z Axis:	Positive

Fig. 4-3 Modification interface of “Axis OutputDir”



Parameters with sign “\*” in front take effect after restart the software, while parameters without the sign take effect immediately after modification.

### 4.3. Pulse Equivalent Adjustment

Pulse equivalent is the moving distance of the worktable or rotation degree of the rotary axis per pulse sent by the CNC device, i.e. the minimum distance controlled by the CNC system. This item can be calculated in terms of information of screw pitch, electronic gear ratio, mechanical deceleration ratio, etc.

The smaller the pulse equivalent is the higher the machining precision and surface quality will be. At the meanwhile, the setting value of pulse equivalent decides the max. feed speed (feed rate), and the relationship between pulse equivalent and max. feed speed is as shown below:

$$\text{Max. feed speed (mm/min)} = \text{Pulse equivalent (mm/p)} \times \text{Hardware frequency (p/s)} \times 60 \text{ (s/min)}$$

The hardware frequency of NK105G2F/G3F is 320KHz; when pulse equivalent is 0.001mm/p, the max. feed speed of machine tool is 19.2m/min.

Lower pulse equivalent should be set under the condition of meeting the demand of feed speed.

◆ **Pulse Equivalent of Linear Axis**

The calculation of pulse equivalent varies with different motor systems.

1) Stepping motor

$$\text{Pulse equivalent} = \frac{\text{Screw pitch}}{\frac{360}{\text{Stepping angle}} \times \text{Subdivision} \times \text{Mechanical deceleration ratio}}$$

Hereinto, mechanical deceleration ratio= rotary speed input in reducer / rotary speed output =teeth number of driven gear / teeth number of driving gear.

For instance, the selected screw lead of X-axis for a certain type machine tool is 5mm, and the stepping angle of stepping motor is 1.8°, with “10” subdivision and “1:1” deceleration ratio. Thus, the pulse equivalent of X-axis is:

$$\text{Pulse Equivalent} = \frac{5\text{mm}}{\frac{360}{1.8} \times 10 \times 1} = 0.0025\text{mm/p}$$

2) Servo Motor

$$\text{Electronic gear ratio } \frac{B}{A} = \frac{\text{Encoder resolution}}{\frac{\text{Screw pitch}}{\text{Pulse equivalent}}} \times \text{Mechanical deceleration ratio}$$

Electronic gear ratio: if a servo motor makes one circle per every 5000 pulse commands sent by the system, setting electronic gear ratio of the servo motor can make the servo rotate twice with the same amount of pulse commands (please refer to parameter setting of each servo brand).

Please see the servo motor label plate and then refer to the corresponding manual to confirm its encoder resolution. A label plate of YASKAWA SGMSH type motor is as shown below, and the 4th character in motor type is the serial encoder specification, so the resolution of this motor is  $2^{17}$ , i.e. 131072.




Fig. 4-4 Name plate of servo motor encoder resolution

For instance: (an example of YASKAWA) the screw pitch of a certain type machine is 5mm, with 17 bit encoder resolution, “0.0001mm/p” pulse equivalent and “1:1” deceleration ratio.

$$\text{Electronic gear ratio} = \frac{PN202}{PN203} = \frac{2^{17}}{5 / 0.0001} \times 1 = \frac{131072}{5 / 0.0001} \times 1 = \frac{8192}{3125}$$

◆ Pulse Equivalent of Rotary Axis

The pulse equivalent of rotary axis refers to the rotation degree of the axis clamping the workpiece per pulse. The rotary degree of workpiece per revolution of motor is equal to screw pitch.

1) Stepping motor

$$\text{Pulse equivalent} = \frac{360}{\frac{360}{\text{Stepping angle}} \times \text{Subdivision} \times \text{Mechanical deceleration ratio}}$$

2) Servo motor

$$\text{Electronic gear ratio } \frac{B}{A} = \frac{\text{Encoder resolution} \times \text{Pulse equivalent}}{360} \times \text{Mechanical deceleration ratio}$$

## 4.4. Setup of Machine Stroke

Machine stroke refers to the valid motion stroke of a machine tool. In the parameter “MachineStrok”, the valid motion range of the three axes (X/Y/Z) can be set. Because this system regards the machine tool dimensions as the reference for soft limit, their values should be consistent with the actual dimensions of the machine tool. Otherwise, limit overrun or axis crash may occur.

If file machining range exceeds the machine tool’s dimensions, there will be a message box prompting machining is out of range, as shown in Fig. 4-5. You can press [OK] or [ESC] to return to the main page, and then manually move the machine tool to release limit.




Fig. 4-5 Soft limit prompt

Modification to this parameter becomes valid after system reboot.

## 4.5. Port Polarity Adjustment

The polarities of input/output ports in the software are specified in terms of the switch type: the polarity of a normally closed switch is “P”; the polarity of a normally open switch is “N”. The corresponding relation between system port No. and ports on the terminal board is as shown in Table 8.

The steps to modify port polarity are as following: press “Menu”→ 8. Diagnosis→ 2. Port List, and then press [OK] to enter the interface as shown in Fig. 4-6. At this time, you can press the “Up” or “Down” key to move the cursor to the desired port, and then press the “Shift” key to change its polarity. After its polarity change, press [OK] to save the modification.

IN	GX01	▪	P
IN	GX02	○	N
IN	GX03	○	N
IN	GX04	○	N

Fig. 4-6 Modification interface of port polarity

Table 8 Corresponding signals of system input ports

System port No.	Terminal name	Corresponding signal	Remark
0	GX01(XORG)	Machine origin signal of X axis	For external connection with mechanical, photoelectrical or proximity switch.
1	GX02(XLM+)	Positive limit signal of X axis	
2	GX03(XLM-)	Negative limit signal of X axis	



System port No.	Terminal name	Corresponding signal	Remark
3	GX04(YORG)	Machine origin signal of Y axis	
4	GX05(YLM+)	Positive limit signal of Y axis	
5	GX06(YLM-)	Negative limit signal of Y axis	
6	GX07(ZORG)	Machine origin signal of Z axis	
7	GX08(ZLM+)	Positive limit signal of Z axis	
8	GX09(ZLM-)	Negative limit signal of Z axis	
9	GX10(AORG)	Machine origin signal of A-axis	
A	GX11(ALM+)	Positive limit signal of A-axis	
B	GX12(ALM-)	Negative limit signal of A-axis	
C	GX13	Extended input	
D	GX14	Extended input	External connection with E-stop button on the machine tool
E	GX15	E-stop alarm signal	
F	GX16	Tool sensor signal	

Table 9 Corresponding signals of system output ports

System port No.	Terminal name	Corresponding signal	Remark
0	GY13(GREEN)	Green signal output	
1	GY14(RED)	Red signal output	
2	GY15(YELLOW)	Yellow signal output	
3	GY16(SPIN)	Spindle on output	
4	GY17(SCOOL)	Spindle coolant output	
5	GY18(OIL)	Auto lube output	
6	GY19	Workpiece cooling output	
7	GY20	Spindle reverse output	
8	GY21	Reserved output	
9	GY22	Reserved output	

## 4.6. Back to Machine Origin

Origin of Machine Coordinate System (the inherent coordinate system of a machine tool), also called machine origin, mechanical zero, or home, is fixed after design, manufacturing and debugging before the machine tool leaving factory. Only after backing to machine origin can such operations as soft limit, setting fixed point and tool change be enabled. Therefore, after startup of CNC system, it is necessary to home all the axes. This system will remind to back to machine origin after start-up.

If homing can't be executed due to home switch fault, it is necessary to set the parameter "Back REF First" to "No".

### 4.6.1. Parameter Setup of Backing to Machine Origin

The parameter “REF. PointSet” includes the setting of “REFP Speed”, “REFP Dir” and “Retract Dist”.

Press “Menu”→ 5. Mfr Param→ 5. REF. PointSet, and then press the [OK] key to enter the setting interface of backing to machine origin, in which press the “Up” or “Down” key to select the corresponding parameter to be modified.

- “REFP Speed”: it is the speed of rough positioning during backing to machine origin, i.e. the motion speed of an axis towards the home switch during rough positioning. The value of this parameter should be set in accordance with the integral structure of a machine tool. And too fast speed can cause missing steps, damage to the machine tool or to the home switch due to axis crash.
- “REFP Dir”: it is the direction of rough positioning during backing to machine origin, i.e. the motion direction of an axis towards the home switch during rough positioning. This parameter is decided by the motor direction and installation position of the home switch; at the same time, it is also related with the defined attribute of the input level and the attribute of the home switch.
- “Retract Dist”: this parameter is decided by the machine tool itself. After arriving at the machine origin, the machine tool will move some distance away from the machine origin to get out of the signal sensitive zone of the home switch. Its value is recommended as half of the screw pitch.

### 4.6.2. Operation Mode of Backing to Machine Origin

After system start-up, pressing [OK] in the dialog box shown in Fig. 4-7 will home all the axes.




Fig. 4-7 Prompt dialog box of backing to machine origin

This method can only home all the axes. If you want to execute single axis backing to machine origin, refer to the following steps.

Press the “Menu” key→ 3. Operations→ 1. Back REF Point, and then press the [OK] key to enter the setup interface of backing to machine origin, in which press the “Up” or “Down” key to select the desired mode. And then press the [OK] key to execute backing to machine origin in the selected way. It is recommended to execute “Z Home” firstly. If “X Home” or “Y Home” is executed firstly, a message as shown below will be displayed on the LCD prompting to execute “Z Home” firstly. To see all the information, press the “Up” and “Down” keys.




Fig. 4-8 Dangerous prompt for operation of backing to machine origin

At this time, you can press the [OK] key to enter the machining page and execute backing to machine origin for the selected axis, or press [ESC] to cancel and return to the previous page.

## 4.7. Spindle Debugging

This system can control spindle motor through parameters of “Spindle Gears”, “ON/OFF Delay”, “Initial Gear” and “Max. Spdl Speed”. Spindle speed can also be changed during machining under the condition that the interface board and inverter have been well connected.

### 4.7.1. Spindle Setup

Press the “Menu” key→ 5. Mfr Param→ 6. Spindle Set, and then press the [OK] key to enter the spindle setup interface, in which press the “Up” or “Down” key to select the corresponding parameter for modification.

#### ◆ ON/OFF Delay

Since it takes some time for the spindle to reach the rated rotary speed or stop completely, tool damage or a scrap may happen if machining starts before the spindle reaching the rated rotary speed or other actions are performed before the spindle stopping completely. This parameter set the delay time for the spindle to reach the set spindle speed or stop completely when turned ON or OFF.

#### ◆ Spindle Speed

It specifies the spindle speed during auto machining, with its value no more than “Max. Spdl Speed”.

#### ◆ Max. Spdl Speed

It refers to the max. Rotary speed of the spindle, with its value consistent with the setting of inverter.

Modification to this parameter becomes effective after reboot.

### 4.7.2. Park MCS Site

Press the “Menu” key→ 3. Operations→ 5. Park MCS Site, and then press the [OK] key to enter the interface of “Park Mode” and “Park Site”, as shown in Fig. 4-9. The position of the spindle after the end of machining can be set here.



Fig. 4-9 Park MCS site interface

Select “Park Mode”, and then press [OK] to enter the interface as shown below.



Fig. 4-10 Park mode selection

Press the “Up” or “Down” key to select the desired item, and then press the [OK] key to accomplish the selection and return to the previous page. If “To park site” is selected and confirmed, input or select the park site under “2. Park Site”.

After selecting “Select Site”, press the [OK] key, and then press [OK] again to set current position as the park position. The system will then back to the main page automatically. At this time, you can press the “Start” key to start machining directly.



Current position cannot be set under “Selecting Site”; you need to set the current position of the spindle in advance.

### 4.7.3. Spindle Stop

Press the “Menu” key → 4. Oper Param → 10. SpindleStop, and then press the [OK] key to enter the setting interface of “Spindle Stop”, in which press the “Up” or “Down” key to select the corresponding parameter for modification. See Fig. 4-11 for the three modes of spindle stop.




Fig. 4-11 Spindle stop setting interface

## 4.8. Manual Machining

Manual machining refers to manipulating a machine tool by the direction keys of the three axes on the panel. At the same time, parameters including the operation speed and step length can also be adjusted according to the requirements of operation.

After backing to the reference point, the system will enter into the manual state automatically, the screen display as shown in Fig. 4-12.

<b>1X</b>	<b>0.000</b>	<b>Idle</b>
<b>1Y</b>	<b>0.000</b>	<b>SOff</b>
<b>1Z</b>	<b>0.000</b>	<b>Slow</b>
<b>Jog</b>		<b>100%</b>

Fig. 4-12 Manual machining interface




Chapters 4.8, 4.9 and 4.10 are the machining operations of NK105G2F, while Chapter 5 introduces the machining operations of NK105G3F in details.







### 4.8.1. Manual Selection of Manual Machining

To satisfy the requirements of manual motion under different situations, this system provides two kinds of manual motion modes: “Jog” and “Stepping”, which can be switched by pressing the “Shift” key. The current motion mode is displayed at the bottom of the LCD.

#### ◆ Jog Motion Mode

There is no concrete data control under this mode. You can press an axis direction key









(, , , , , ) to move the machine tool accordingly under this mode. The machine tool will not stop until the direction key is released. For the motion speed, it is decided by the current type of speed (jog speed and rapid jog speed). This motion mode is suitable for coarse tuning of the position of machine coordinate.

#### ◆ Stepping Motion Mode

Under this motion mode, the machine tool will move accordingly after an axis direction key



(, , , , , ) is pressed. This motion mode is suitable for fine tuning of the position of machine coordinate.


### 4.8.2. Parameter Setting of Manual Machining

Basic parameters of manual machining include: rapid jog speed (i.e. “High” shown in the machining page), jog speed (i.e. “Slow” shown in the machining page), XY step, Z step and A step.

Table 10 Parameters for manual machining

Parameter	Meaning	Setting range
<b>MSpd (High)</b>	Two types of speed under manual machining, deciding the axis motion speed during manual machining.	0.06~Max. speed of machine tool
<b>MSpd (Slow)</b>		0.06~Rapid jog speed
<b>Step X/Y/Z/A</b>	The motion distance of the corresponding axis each time an axis direction key of X/Y/Z/A is pressed.	0.001~10000mm

The max. speed of a machine tool is related with the setting of pulse equivalent. For the concrete expression, see Chapter 4.3.

Jog speed (Slow) and rapid jog speed (High) are switched by pressing .

The concept of stepping (also called gridding in some other systems) is introduced for the accuracy of machining and debugging. When the system is in the stepping mode, step is the motion distance of the corresponding axis each time an axis direction key of X/Y/Z/A is pressed.

Under the main page, press the [OK] key to enter the parameter setting page of manual machining, as shown in Fig. 4-13.




Fig. 4-13 Manual parameter setting page

Press “Up” or “Down” to select the desired parameter, and then press [OK] for confirmation after modification. Note that modification should be within the parameter range.


Current file name is displayed at the bottom of the LCD. Press “Up” or “Down” to move the cursor to the file name, and then press [OK] to enter the file list of C disk, as shown in Fig. 4-14. You can only load these files, unable to delete or copy them under this page.



Fig. 4-14 File list page



If there is no file in the C disk, the prompt “File Not Found, Show USB File?” will be displayed; press [OK]

to enter the file list of USB flash drive.

To switch between USB file list and C file list, press .

## 4.9. Automatic Machining

### 4.9.1. WCS Selection

WCS and MCS are switched through the combination key  + . And their screen display is as shown in Fig. 4-15.

<table border="0" style="width: 100%;"> <tr><td><b>X</b></td><td><b>0.000</b></td><td><b>Idle</b></td></tr> <tr><td><b>Y</b></td><td><b>0.000</b></td><td><b>SOff</b></td></tr> <tr><td><b>Z</b></td><td><b>0.000</b></td><td><b>Slow</b></td></tr> <tr><td><b>Jog</b></td><td></td><td><b>100%</b></td></tr> </table>	<b>X</b>	<b>0.000</b>	<b>Idle</b>	<b>Y</b>	<b>0.000</b>	<b>SOff</b>	<b>Z</b>	<b>0.000</b>	<b>Slow</b>	<b>Jog</b>		<b>100%</b>	<table border="0" style="width: 100%;"> <tr><td><b>1X</b></td><td><b>0.000</b></td><td><b>Idle</b></td></tr> <tr><td><b>1Y</b></td><td><b>0.000</b></td><td><b>SOff</b></td></tr> <tr><td><b>1Z</b></td><td><b>0.000</b></td><td><b>Slow</b></td></tr> <tr><td><b>Jog</b></td><td></td><td><b>100%</b></td></tr> </table>	<b>1X</b>	<b>0.000</b>	<b>Idle</b>	<b>1Y</b>	<b>0.000</b>	<b>SOff</b>	<b>1Z</b>	<b>0.000</b>	<b>Slow</b>	<b>Jog</b>		<b>100%</b>
<b>X</b>	<b>0.000</b>	<b>Idle</b>																							
<b>Y</b>	<b>0.000</b>	<b>SOff</b>																							
<b>Z</b>	<b>0.000</b>	<b>Slow</b>																							
<b>Jog</b>		<b>100%</b>																							
<b>1X</b>	<b>0.000</b>	<b>Idle</b>																							
<b>1Y</b>	<b>0.000</b>	<b>SOff</b>																							
<b>1Z</b>	<b>0.000</b>	<b>Slow</b>																							
<b>Jog</b>		<b>100%</b>																							
MCS	WCS																								

Fig. 4-15 Screen display of WCS and MCS

Number 1~6 in front of X/Y/Z in WCS indicates G54~G59 respectively, while there is no number before X/Y/Z in MCS. A sign “\*” will appear after each axis in MCS after the completion of backing to machine origin.

Press the “Menu” key→ 3. Operations→ 6. Select WCS, and then press [OK] to enter the setup page, in which press the “Up” and “Down” keys to select the desired WCS. After selection, the contents in the main page will change accordingly. For instance, after “G55 WCS” is selected, the number in front of each axis will change to 2, as shown in Fig. 4-16.

<b>2X</b>	<b>0.000</b>	<b>Idle</b>
<b>2Y</b>	<b>0.000</b>	<b>SOff</b>
<b>2Z</b>	<b>0.000</b>	<b>Slow</b>
<b>Jog</b>		<b>100%</b>

Fig. 4-16 Main page under WCS G65

### 4.9.2. Load File


#### ◆ Load Ordinary File

Press “Menu” to enter the menu page→ press the “Up” and “Down” keys to select “Local Files” or “USB Files”→ press [OK] to enter the corresponding file list page→ press [OK] to select the desired

machining file → press  to load the selected file.

### ◆ Load an ENG File with Tool Selection Function

Find the desired ENG file following the steps above-mentioned to load an ordinary file, and then press

[OK] to select the ENG file to be machined, and then press  to automatically enter the tool selection page as shown in Fig. 4-17.




Fig. 4-17 Tool selection page

Number of tools: the number of tools in this ENG file


Tool No.: current tool No., selected by pressing the “Up” and “Down” keys

Cutter: selected by pressing the “Up” and “Down” keys, displaying tool sequence number and name

After parameters are set, press [OK] to load the file; after loading, the system will return to the machining page automatically.



### 4.9.3. Set Workpiece Origin

Workpiece origin is the zero of X, Y, and Z/A in the machining file. Before machining, you must set workpiece origin to determine its actual position.



Manually move the X and Y axes to the desired origin position, and then press  for XY clearing, i.e. to confirm the position of XY workpiece origin.

For Z/A workpiece origin, there are two ways to set it:

- Method one is the same as that to set XY workpiece origin. Manually move the Z/A axis to the

desired origin position. And then press  +  for Z/A clearing, i.e. to confirm the position of Z/A workpiece origin.



- Method two takes advantages of tool measurement. Press  +  to execute movable tool measurement. After measurement, coordinate of Z/A axis is the workpiece origin of Z/A axis.



#### 4.9.4. Start Machining

Press the start key  to start automatic machining in the machining page.

Prompts like feedrate override and feed rate are scrolled on the LCD during file machining.



## 4.10. Adjustment during Automatic Machining

### 4.10.1. Feedrate Override Adjustment





Feedrate override can be increased or decreased by pressing  or  during file machining. And the feed rate changes with the feedrate override. The relation between actual feed rate and feedrate override is as follows:

$$\text{Actual feed rate} = \text{Feed rate} \times \text{Feedrate override}$$

The least unit of feedrate override is 0.1. Namely, override increases (decreases) by 0.1 after each press

of  or ; at the same time, the feedrate override displayed on the LCD increases (decreases) by 10%. The range of feedrate override is within 0%~120%. In addition, the display of feed rate value changes with the feedrate override.

### 4.10.2. Spindle Speed Adjustment




Spindle speed are adjusted by pressing  +  or  + , and divided into 11 gears from 0.5s to 1.5s with speed increasing sequentially.

### 4.10.3. Machining Pause and Jiggle

If machining is found not in position exactly, suspend the machining and then execute manual jiggle. Suspend machining by pressing the “Pause” key in machining, “Paus” displayed at the top right corner of the LCD while the machine tool stopping moving; as for the spindle, whether it stops or not is decided by the setting of the parameter “SOff at Pause”. Whether the spindle stops or not, at this time, the three

axes can be jigged, and the system is in “Stepping” mode by default. Each press of an axis direction key will make the corresponding axis move a specified step.


The operation steps are as follows:

- 1) Press  in the process of machining, and then press  +  to enter the jiggle page.
- 2) Press “↑” or “↓” to select a step size from “0.01”, “0.02”, “0.05”, “0.10”, “0.20”, “0.50” and “1.00”.
- 3) Press one of “4”, “6”, “2”, “8”, “3” and “9” to execute jiggle on the desired axis in the corresponding direction.
- 4) Press “Start” to resume machining after jiggle.



If hard limit, soft limit or E-stop occurs in jiggle, the system will stop jiggle, give a limit prompt or an alarm, and return to the main page.

### 4.10.4. Continuing Machining after Pause

When the system is in the state of pause, pressing the start key  will continue machining from the pause position, running status at the top right corner of the screen changing from “Paus” to “Run”; at the same time, the machine tool continues machining.

### 4.10.5. Soft Limit Handling

Soft limit occurs when an axis exceeds the setting range of “MachineStroke” during machining, and the system will display a limit dialog as shown below.




Fig. 4-18 Soft limit dialog

Press [OK] or [ESC] to exit from this warning dialog and return to the machining page, and then manually move the limit axis towards the reverse direction to release limit. After soft limit occurs, the system prohibits the limit axis from moving towards the limit direction.

### 4.10.6. Hard Limit Handling

The system detects hard limit periodically under the main page. When hard limit occurs, its prompt dialog

is as shown in Fig. 4-19.




Fig. 4-19 Hard limit dialog

At this time, press [OK] to return to the main page under “Jog” mode, with “Limit Rls.” displayed at the bottom right corner of the LCD, as shown in Fig. 4-20. Or you can press [ESC] to directly back to the main page under “Jog” mode.




Fig. 4-20 Prompt interface of limit release

Move the machine tool away from the limit position, “Limit Rls.” disappearing. The main page returns to its normal state.

## 5. Machining Operation of NK105G3F

### 5.1. Manual Machining

Manual machining refers to manipulating a machine tool by the direction keys of the three axes on the panel. At the same time, parameters including the operation speed and step length can also be adjusted according to the requirements of operation.

After backing to the reference point, the system will enter into the manual state automatically, the screen display as shown in Fig. 5-1.

1X	0.000	Idle
1Y	0.000	SOff
1Z	0.000	Slow
Jog		100%

Fig. 5-1 Manual machining interface


#### 5.1.1. Mode Selection of Manual Machining

Refer to chapter 4.8.1 for details.

#### 5.1.2. Parameter Setting of Manual Machining

Refer to chapter 4.8.2 for details.

Where:

Press  to switch between jog speed (manual low speed) and rapid jog speed (manual high speed).

Press  to switch between USB file and C file list.

### 5.2. Automatic Machining

Automatic machining refers to that the system processes system files and the files in the USB flash drive in terms of instructions, also called file machining. All the parameters of machine tool and system should be set correctly before automatic machining starts.

#### 5.2.1. Load File

For details, refer to chapter 4.9.2.

Where:

To load an ordinary file, press  to load the selected file.






To load an ENG file with tool selection function, press  to automatically enter the tool selection page.

## 5.2.2. WCS Selection


Refer to chapter 4.9.1 for details.



## 5.2.3. Set Workpiece Origin

Workpiece origin is the zero of X, Y, Z and A in the machining file. Before machining, you must set workpiece origin to determine its actual position.

Manually move the X and Y axes to the desired origin position, and then press  for XY clearing, i.e. to confirm the position of XY workpiece origin. You can also press  +  and  +  to execute X clearing and Y clearing separately.

For Z workpiece origin, there are two ways to set it:

➤ Method one is the same as that to set XY workpiece origin. Manually move the Z axis to the desired origin position. And then press  for Z clearing, i.e. to confirm the position of Z workpiece origin.

➤ Method two takes advantages of tool measurement. Press  +  to execute mobile tool measurement. After measurement completed, the coordinate of Z axis is Z workpiece origin.

## 5.2.4. Start Machining



Refer to chapter 4.9.4 for details.

# 5.3. Adjustment during Automatic Machining





## 5.3.1. Feedrate Override Adjustment

For details, refer to chapter 4.10.1.

Where:

Press  or  to increase or decrease the feedrate override.

### 5.3.2. Spindle Speed Adjustment

Spindle speed are adjusted by pressing combination key  +  or  + , and divided into 11 gears from 0.5s to 1.5s with speed increasing sequentially.

### 5.3.3. Machining Pause and Jiggle

Refer to chapter 4.10.3 for details.

Where:



Press  +  to enter the jiggle page.

### 5.3.4. Soft/Hard Limit Handling

Refer to chapter 4.10.5 and chapter 4.10.6 for details.

### 5.3.5. E-stop Handling

When E-stop occurs, the system will stop machining, and give an alarm as shown in Fig. 5-2, the “ALM” indicator on the panel ON. Before executing any other operations, remove this alarm by turning the E-stop button clockwise.

After E-stop alarm is removed, home all the axes, and then press  +  to execute breakpoint resume, i.e. to resume machining from the stop position when E-stop occurs.

1X	15.617	Estp
1Y	551.107	SOff
1Z	9.900	Slow
Jog	<b>ESTOP2</b>	

Fig. 5-2 E-stop alarm



In E-stop state, all the other keys are invalid except the “Menu” key. You can press the “Menu” key to enter the menu page and make desired changes.

## 6. System Update

NK105G2F/G3F can be used directly since the software has already been well installed before delivered. In case of breakdown, update the system.

### 6.1. Software Update


Software update is included in the process of system image update. If there is no need updating the system image, directly update the software following the below steps:

- 1) Store the software application to be updated under the root directory of an USB flash drive, and then insert the USB flash drive into the USB interface of NK105 control box. (The software application is composed of five file folders—"CHN", "Config", "ENG", "Font", and "NewNK200", which should all be under the root directory of the USB flash drive.)
- 2) Power on NK105, press "Shift" to enter the menu page, select "7. System Upkeep" and "3. System Update" in turn, and operate according to the tips on the LCD until "USB Available Now!" appears. Press "OK" to enter the system update interface, and then select "Delete parameter". After parameter files are deleted, select "Update system" to start updating the software. After update completed, the new software will be rebooted automatically.



Parameters should be restored to factory setting after each software update, unless the update software is totally the same as the old software (e.g. the same version). If "Delete parameter" is not selected in the process of update, it is a must to restore ex-factory parameters after software updated by following the below steps: after the system is rebooted, press "Shift" to enter the menu page; and then select "6. Param Upkeep" and "3. Factory Params" sequentially, and then operate according to the tips on the LCD.

### 6.2. System Mirror Update

- 1) Store the system image (NK105.nb0) and the software application to be updated under the root directory of an USB flash drive (above 1G), and then insert the USB flash drive into the USB interface of the NK105 control box. (The software application is composed of five file folders—"CHN", "Config", "ENG", "Font", and "NewNK200", which should all be under the root directory of the USB flash drive)
- 2) Power on NK105, and then long press the "Menu" key  until entering the update selection interface. Press "1" to select "1: Update menu", and then press 3 to select "3: OS" in the new pop-up

page to start updating the system image.

- 3) Note that this process is a little long, about 3 minutes. After completed, "USB Available Now!" will be displayed on the LCD. Press "OK" to enter the system update interface, and then select "Update system" to start updating the software. After update completed, the new system will be rebooted automatically.

The steps of EBOOT and FPGA update are similar to those of image update. The file for FPGA update is fpga105.dat, while that for EBOOT update is EBOOT.nb0. They should also be placed under the root directory of an USB flash drive. After entering the update selection interface and pressing "1" ("1: Update menu"), you can start FPGA update by pressing "1" ("1: FPGA"), or EBOOT update by pressing "2" ("2: EBOOT").

During image updating, all system files (including tool path files) will be deleted and cleared.



Since image update clears all the old files, it is strongly recommended to do backup before image update.



## 7. References

### 7.1. System Parameters

#### 7.1.1. Parameters of Operator's Access

##### ◆ Parameters Related with Velocity

Parameter	Meaning	Setting range
<b>G00 Speed</b>	G00 speed, which can be set in this parameter or in the program file	Related with the specific machine tool G00 speed < Max. velocity of machine tool
<b>Gxx Speed</b>	Gxx speed	Related with the specific machine tool
<p>The max. velocity of a machine tool is related with the setting of pulse equivalent. For the detailed expression, see Chapter 4.3.</p> <p>The relation between actual feed rate and feedrate override is: Actual feed rate= Feed rate × Feedrate override</p> <p>Jog speed and rapid jog speed are set in the manual speed setup page; G00 speed ≥ machining speed, and rapid jog speed ≥ jog speed &gt; 0.06</p>		

##### ◆ Parameter Related with Machining

Parameter	Meaning	Setting range
<b>Back REF First</b>	Whether homing all the axes before machining is required or not	Yes: Required No: Not required
<b>Lifts on Pause</b>	Lifting amount at pause	0~10000 mm
<b>Step Length</b>	#variables customization	
<b>Cycle Process</b>		
<b>Cycle Process</b>	Whether to enable cycle process	Yes: Enabled No: Disabled
<b>Cycle Times</b>	Cycle machining times, valid when "Cycle Process" is set to "Yes"	1~9999
<b>Cycle Interval</b>	Interval between two adjacent cycles	0~3600000
<b>S_Off in Intev</b>	Whether to stop spindle in the interval	Yes: Stop No: Not stop
<b>G73_G83 Retract</b>	Retract or spacing amount of G73_G83 command	0~1000000 mm
<b>Ratio On MANU</b>	Whether manual operation setting is influenced by feedrate override	Yes: Influenced No: Not influenced
<p>Homing all the axes before machining can prevent machining deviation and ensure position accuracy. It is recommended to set "Back REF First" to "Yes" to disable a machine tool to run automatically if backing to machine origin is not executed before machining. When the home switch cannot work</p>		

Parameter	Meaning	Setting range
	normally, "Back REF First" can be set to "No".	
	G73_G83Retract: the retract amount after each feed under G73 command; under G83 command, the distance between the feed plane where the cutter changes from G00 to Gxx and the previous peck depth.	
	Step length: custom #variable, convenient for operators to change step length in the program file. There are 8 groups of step length in total from the first group #STEP0 to the eighth group #STEP7 respectively. For instance, G01X=#STEP2 refers to the X axis moving the third group step length under G01 command.	

◆ Parameters Related with Offset

Parameter	Meaning	Setting range
<b>Public Offset</b>	Aiming at all the WCSs, used for adjusting workpiece origin of X, Y, Z and A axes	-10000~10000 mm
<b>Work Offset</b>	D-value of WCS origin and MCS origin.	-10000~10000 mm
The relation of workpiece offset, tool offset and public offset is as following: Workpiece coordinate = Machine coordinate - Workpiece offset – Tool offset – Public offset		

◆ Spindle Parameters

Parameter	Meaning	Setting range
<b>Spindle Stop</b>		
<b>SOff at pause</b>	Whether to stop spindle at pause	Yes: Stop; No: Not stop
<b>SOff at Stop</b>	Whether to stop spindle at stop	Yes: Stop; No: Not stop
<b>SOff at End</b>	Whether to stop spindle when machining completed	Yes: Stop; No: Not stop
<b>ProcessEndTip</b>	Whether to turn on the red light indicator as a sign of the completion of machining	Yes: On; No: Off
This group of parameters sets whether to stop spindle under various forms of stop state.		

◆ File Parameters

Parameter	Meaning	Setting range
<b>Dxf Params</b>		
<b>Lifting Height</b>	It sets the tool lifting height of Z axis during rapid traverse when a DXF file is being processed.	0~99999 mm
<b>Process Depth</b>	It specifies the machining depth for 2D files.	-99999~0 mm
<b>1st Point as 0</b>	It sets whether to set the first point as workpiece origin when a DXF file is processed.	Yes: Valid; No: Invalid
<b>Shape Process</b>	The system will not process the next shape until the current shape is finished.	Yes: Valid; No: Invalid
<b>Bottom Process</b>	Valve operation is enabled only when [3D cutting] is on the workpiece surface.	Yes: Valid; No: Invalid
<b>Metric Size</b>	It forcibly sets a dxf file using metric size.	Yes: Metric size No: Imperial size
<b>Eng Params</b>		

Parameter	Meaning	Setting range
<b>Lifting Height</b>	It sets the tool lifting height of Z axis during rapid traverse when an ENG file is being processed.	0~99999 mm
<b>ToolChangeTip</b>	It sets whether to pause and prompt tool change when tool change command is encountered during ENG file machining.	Yes: Valid; No: Invalid
<b>Cycle Times</b>	It sets the cycle times to process an Eng file.	0~100000
<b>Deep Hole Mode</b>	Mode selection for deep hole machining	0: Reciprocating chip removal 1: High-speed reciprocating chip removal
<b>Retract Amount</b>	Retract amount after each feed in high-speed reciprocating chip removal mode	0~99999999 mm
<b>Select ToolNo.</b>	If this parameter is set to "Yes", the machining will be executed in terms of the specified tool No. in the machining file and only this file will be processed.	Yes: Valid; No: Invalid
<b>Plt Params</b>		
<b>Lifting Height</b>	It sets the tool lifting height of Z axis during rapid traverse when a PLT file is being processed.	0~99999 mm
<b>Plt Unit</b>	Normally, 1plt=40.195mm, which can be enlarged or diminished by setting this parameter.	0.001~99999
<b>Tool step</b>	The value should be confirmed in terms of the tool diameter and make the adjacent tool paths overlap for a full machining.	0.0001~99999 mm
<b>Processing Depth</b>	It specifies the machining depth for 2D files.	-99999~0 mm
<p>DXF parameters are for the translation of DXF files. In DXF file machining, the system treats the action of tool lifting as the separate mark for the adjacent shapes, If there is no tool lifting, the system will consider only one shape is being processed. If tool lifting occurs, it indicates the machining of a complete shape is finished. For example, process several circles adjacent to each other. The depth of each circle is 10mm, and each feed depth of Z axis is 2mm. If the parameter "Shape Process" is set to "Yes", the machine tool will process the current circle 5 times, and then lift the tool, and then go to process the next circle. If it is set to "No", the machine tool will process the current circle once, then lift the tool, and then go to process the next circle. After all the circles are processed once, this process will be re-executed 4 times to finish machining all the shapes.</p> <p>ENG parameters are for the translation of ENG files.</p> <p>PLT parameters are for the translation of PLT files. PLT is a format of 2D machining files defined by an American company—Hewlett Packard (HP), usually used in embossment and advertising carving. At the same time, PLT is also a kind of unit. Normally, 1plt=40.195mm, which can be enlarged or diminished by setting the parameter "PLT Unit".</p>		

◆ Parameters Related with Tool Change

Parameter	Meaning	Setting range
ATC Capacity	Capacity of tool magazine	1~20
Current ToolNo.	Tool No. currently used	1~Value of ATC Capacity
Tool Offset	Modification to the tool offset along each axis	X/Y/Z: -10000~10000 mm
ToolChangeTip	Whether to send prompt when there is tool change command in the file	Yes: Valid; No: Invalid
X/Y/Z Cali Coor	The machine coordinate (X/Y/Z) of tool presetter in fixed tool measurement	/
CaliToolHeigh	The required tool lifting height after the end of tool measurement	0.001~9999 mm

◆ Ignore Command

Parameter	Meaning	Setting range
Ignore F Code	Whether to enable the feedrate command in the machining file	Yes: Enable the feed rate in the system No: Enable the feed rate in the machining file
Ignore S Code	Whether to enable the spindle command in the machining file	Yes: Enable the spindle command in the system No: Enable the spindle command in the machining file

## 7.1.2. Parameters of Manufacturer's Access

◆ Parameters Related with Velocity

Parameter	Meaning	Setting range
Decel. Dist.	To protect tools, the machine tool will decelerate (at [Approach Speed]) when approaching the target position during positioning. This parameter is used to specify the distance from the decelerating position to the target position.	0~999mm
Approach Speed	It is the feed speed of the tool when approaching workpiece during positioning (the distance between the tool and workpiece is smaller than deceleration distance).	Jump speed ~ Machining speed
Sgl Axis Acc.	Description of the acceleration/ deceleration capability of each feed axis, in "mm/s <sup>2</sup> "	0.001~100000.0mm/s <sup>2</sup>
Max. Turn Acc.	The max. acceleration of feed motion on adjacent axes	0.001~100000.0 mm/s <sup>2</sup>
Jerk	The change rate of acceleration of single axis (acceleration's acceleration)	0.001~100000.0 mm/s <sup>3</sup>
Max. Speed	It specifies the max. speed of X, Y, Z and A axes.	0.06~100000.0 mm/min

Parameter	Meaning	Setting range
<b>ShortSegSpdLmt</b>	Whether to enable speed limit for short segments	Yes: Valid; No: Invalid
<b>SpdLmt Length</b>	The max. length of short segments	0.001~100000mm
<b>EnbPlungeRate</b>	Whether to enable the downward cut speed under G01 downward cut	Yes: Enabled No: Disabled
<b>PlungeCutSpd</b>	The downward cut speed of Z axis under G01 downward cut	0~Max. Speed of Z axis
<b>Ref Cir Radius</b>	See below for explanation.	0.001~100000.0 mm
<b>Ref Cir. Speed</b>	Reference circle is the reference for the machining of circular workpiece. The max. speed of reference circle refers to the max. speed of machine in machining this circle without obvious vibration.	Min. speed of arc machining ~ Machining speed
<b>Jump Speed</b>	The max. speed for the stepper motor at start-up without acceleration	[Approach Speed]~Machining speed
<p>After the installation of a machine tool, you can make the machine process a circle, in which vibration will occur due to centrifugal force. The higher the speed is, the stronger the vibration will be. Gradually increase the feed speed to see the state of vibration of the machine tool until the max. circular speed is achieved, i.e. the max. speed of the machine tool without strong vibration. This circle is regarded as the reference circle, and its max. speed is the max. speed of reference circle. Max. centripetal acceleration “a” can be calculated in terms of the reference circle radius and its max speed. The formula is as follows: <math>V_0</math> and <math>R_0</math> are the speed and radius of the reference circle respectively, while <math>V_x</math> and <math>R_x</math> are the speed and radius of an arc to be processed. After <math>R_x</math> is confirmed, when the arc machining speed is larger than <math>V_x</math> calculated, the system will limit the arc machining speed automatically to ensure it is within the debugging value, i.e. the vibration will not be stronger than that during ex-factory debugging.</p> $a = \frac{V_0^2}{R_0} = \frac{V_x^2}{R_x}$		

#### ◆ Parameters Related with Machine Tool Debugging

Parameter	Meaning	Setting range
<b>Axis OutpDir</b>	The motion direction of each axis	Positive; Negative
<b>MachineStroke</b>	The valid motion stroke of a machine tool, i.e. the valid machining range of a machine tool in X/Y/Z/A axis	Set according to the actual machine tool
<b>Pulse Equiv.</b>	The worktable stoke per pulse sent by the CNC device or the rotary degree of a rotary axis, i.e. the least distance the CNC system can control	0.00009~999.0 mm/p
<b>REF. PointSet</b>		
<b>REFP Speed</b>	The speed of rough positioning in backing to machine origin	0.001~Max. speed of machine tool

Parameter	Meaning	Setting range
REFP Dir	The direction of rough positioning in backing to machine origin	Positive; Negative
Retract Dist	The additional motion distance after fine positioning stage in backing to machine origin, to move out of the machine origin signal sensitive zone	0~10000 mm
Sign of BK REF	Whether to eliminate the sign of backing to machine origin after E-stop	Yes: Eliminate No: Not eliminate



If you can ensure that the axis position will not deviate after E-stop, you can set the parameter “Sign of BK REF” to “No”, so you can continue machining without backing to machine origin after E-stop is obviated. Otherwise, you need to set this parameter to “Yes” to ensure machining accuracy.

### ◆ Spindle Parameters

Parameter	Meaning	Setting range
<b>Spindle Set</b>		
ON/OFF Delay	The wait time for the spindle to reach normal rotary speed or stop completely after turned ON or OFF	0~60000 ms
Spindle Speed	The spindle speed during auto machining	0~[Max. Spdl Speed]
Max. Spdl Speed	Max. spindle speed	Spindle speed~999999 mm/min

### ◆ Parameters Related with Y Rotary Axis

Parameter	Meaning	Setting range
Y AsRotaryAxis	Whether Y axis is set as rotary axis	Yes: Valid; No: Invalid
Rotary Y Pulse	The pulse equivalent of Y axis when it is set as rotary axis	0~100 mm/p
mm As Unit	It sets the measure unit for the rotary axis.	Yes: in mm No: in deg
Rev. WorkRadius	The length of Y axis in CAM programming is the value of workpiece radius $\times 2 \times \pi$ . The value of this parameter changes with the radius of workpiece.	0~1000000mm
Rotary Takeoff	The takeoff speed of the rotary axis	0~1000000 mm/s
Rotary Y Acc.	The acceleration of the rotary axis, with unit as $\text{rad/s}^2$	0.001~100000.0 $\text{rad/s}^2$
Max. RotaryVel.	Max. rotary speed	0.06~6000000 r/min

### ◆ Parameters Related with Lubrication Setting

Parameter	Meaning	Setting range
EnableAutoLube	Whether to open lubrication pump automatically at	Yes: Valid

Parameter	Meaning	Setting range
	fixed period	No: Invalid
<b>Time Interval</b>	Time interval between two adjacent lubes	0~34560000 s
<b>Duration</b>	Duration time to release lubrication oil each time	0~34560000 s

◆ **Parameters Related with Algorithm**

Parameter	Meaning	Setting range
<b>Enable S Algo</b>	Whether to adopt S-type algorithm	Yes: Valid; No: Invalid
<b>Arc Increment</b>	Whether to adopt arc increment mode In arc increment mode, the coordinates of the circle centre are relative to the starting point. Otherwise, they are relative to workpiece origin.	Yes: Valid; No: Invalid
<b>Forward LookSeg</b>	Used to set the max. look-ahead segments when calculating connection speed	0~10000

◆ **Parameters Related with Compensation**

Parameter	Meaning	Setting range
<b>Backlash Set</b>		
<b>CompensationON</b>	Whether to enable backlash compensation	Yes: Valid; No: Invalid
<b>AxisBacklash</b>	The backlash compensation amount of X, Y and Z axes, valid only when "CompensationOn" is set to "Yes"	0~1000000 mm
Generally, the spindle is secured to a screw whose outer wire and inner wire on the outer wire cannot be completely matched, backlash compensation compensates the clearance between the screw of last direction that the spindle needs to finish after reversing its moving direction.		

◆ **Other Operations**

Parameter	Meaning	Setting range
<b>Smoothing Time</b>	The larger the value is, the smoother the workpiece surface will be, but too large value will affect the dimension of workpiece. 0.01 is recommended for a mold machine, and 0.03 for a woodworking machine.	0.0~0.064 ms
<b>G00 Feed 100%</b>	Whether to enable 100% feedrate override for G00	Yes: Valid; No: Invalid
<b>Safety Height</b>	Calculated with respect to workpiece origin. The horizontal movement at this height is considered to be safe, used in breakpoint resume and backing to workpiece origin.	0~5000 mm
<b>CalibThickness</b>	The thickness of the tool presetter.	0~Worktable range

## 7.2. Driver Parameters and Wiring Diagrams

### 7.2.1. Driver parameters

Driver parameters listed in this chapter can only make a machine tool motion normally, not perfectly. To get a better machining result, you need to read through the servo driver documentation of the corresponding brand and change the parameter setting according to the specific machine tool.

#### 7.2.1.1. Parameter Setting of YASKAWA $\Sigma$ -II Servo Driver

Para. No.	Function	Value	Description
Fn010	Set password (to prevent arbitrarily modification to parameters)	0000	Set [0000]: modification to user parameters [PnXXX] and part of auxiliary function parameters [FnXXX] permitted; Set [0001]: modification to user parameters [PnXXX] and part of auxiliary function parameters [FnXXX] prohibited.
Un00C	Pulse counter of input command	LXXXX (Hexadecimal system)	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection in order to determine whether there is electrical interference.
Pn000	Direction selection Control mode selection	0010	Bit 0: Set 0, "CCW" is forward rotation (viewed from the load end of screw ball); Set 1, the rotation direction of the motor is reversed. Bit 1: Set 1, position control mode (calculate pulse instruction all the time).
Pn200	Select pulse instruction mode	0005	Bit 0: Set 5, select the instruction input mode as "pulse + direction", negative logic. Bit 3: Set 0, input differential signal into filter.
Pn50A	Selection function	8100	Bit 1: Set 0, Servo ON /S-ON, input from 40th pin; Set 7, Servo ON all the time. Bit 3: Set 8, positive rotation not used and signal input (P-OT) prohibited.
Pn50B	Selection function	6548	Bit 0: Set 8, reverse rotation not used and signal input (N-OT) prohibited.



Para. No.	Function	Value	Description		
Pn50F	Selection function	0300	Set it when servo motor with brakes. Bit 2: Set 3, brake interlock signal “/BK” is output from CN1-29, CN1-30 to control 24V relay for brake		
Pn50E	Selection function	0211	Set it when servo motor with brakes To avoid of CN1-29 and CN1-30 being used for other function and leading to brake ineffective, “3” is not allowed to appear in the 4 digits.		
Pn506	Servo off, time delay of brake when motor stops	Depended	Set it when motor with brakes Default setting is “0”, setting unit is 10ms.		
Pn201	Encoder cycle-divided ratio (Pulse output No. per motor cycle by encoder after cycle-divided)	Right-side	Gain Encoder	Type	Encoder Pulse No. per Motor Circle (pulses/ revolution)
				A	13bit 2048
				B	16bit 16384
				C	17bit 32768
Pn202	Electronic gear ratio (numerator)	Need Calculation	Pn202 = pulse No. of each encoder circle × 4 × mechanical deceleration ratio. Pn203 = (screw pitch/ pulse equivalent).		
Pn203	Electronic gear ratio (denominator)	Need Calculation	Typical value: pitch 5mm, encoder 17-bit, deceleration ratio 1:1, pulse equivalent 0.001mm, Pn202=16384; Pn203=625. Pitch 5mm, encoder 17-bit, deceleration ratio 1:1, pulse equivalent 0.0005mm, Pn202=8192; Pn203=625.		

### 7.2.1.2. Parameter Setting of DELTA ASDA-A Servo Driver

Para. No.	Function	Format & Range	Value	Description
P0-02	Driver status display		02	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection in order to determine whether there is electrical interference.

Para. No.	Function	Format & Range	Value	Description
P1-00	External pulse input type	ZYX	002	X=2: pulse + direction; Z=0: positive logic
P1-01	Control mode setup	ZYX1X0	0000	Z=0: during control mode switching, DIO is maintaining the set value. Since switching control mode is not used, Z=0. Y=0: forward rotation (CCW) (in terms of load), Y=1, the rotation direction is reversed; X1X0=00: position control mode
P1-32	Motor stop mode selection	YX	00	Y=0: when there is no servo enabled, motor dynamic brake occurs; Y=1: motor is free. X=0: motor stops instantly, X=1: motor stops with deceleration.
P1-44	Electronic Gear Ratio (Numerator) (N1)	1~32767	Need calculation	N1/M= encoder pulses× 4× pulse equivalent× mechanical deceleration ratio / pitch. Representative value: encoder pulses=2500, pitch=5mm, pulse equivalent=0.001, deceleration ratio=1, calculation as below: N1/M= 2500×4×0.001/5 = 2 / 1, N1=2, M=1;
P1-45	Electronic Gear Ratio (Denominator) (M)	1~32767	Need calculation	When the multi-electronic gear ratio is not used, P2-60~ P2-62 are not required.
P2-10	Digital Input Pin DI1	X2X1X0	101	X1X0=01: digital input (DI1=SON) corresponds to 9th pin of CN1. X2 = 1: set DI1 input as NO (normally open) a-contact point.
P2-15	Digital Input pin DI6	X2X1X0	100	Default factory setting of DI6 and DI7 are NC (normally closed) limit signal input pins; driver can't run without being connected to pin 32 and pin 31 of CN1. X2=1: set DI6 and DI7 inputs as NO (normally open) a-contact points; X1X0=00, limit signal input of the driver is not used.
P2-16	Digital Input Pin DI7	X2X1X0	100	

Para. No.	Function	Format & Range	Value	Description
P2-17	Function setting for digital input pin DI8	X2X1X0	100	External E-stop input is not used.
P2-21	Function setting for digital output pin DO4	X2X1X0	108	DO4 corresponds to pin 1 & pin 26, used as clamping-position brake signal of Z-axis; X2=1: set DO4 output as NO (normally open) a-contact point; X2=0: set DO4 output as NC (normally closed) b-contact point; X1X0=08: set pin 1 and pin 26 as BK+ and BK- respectively.
P2-22	Function setting for digital output pin DO5	X2X1X0	007	DO5 corresponds to pin 28 & pin 27, used as servo alarm signal. X2=0: set DO5 output as NC b-contact point. X1X0=07: set pin 28 and pin 27 as ALRM+ and ALRM- respectively.
P2-51	Servo ON (SON) setup		0	0: Servo ON must be triggered by numerical input signal. 1: when servo is powered, if there is no alarm signal, servo will be on automatically. Set 1 when there is no SON signal line.

### 7.2.1.3. Parameter Setting of DELTA ASDA-A2 Servo Driver

Para. No.	Function	Format & Range	Value	Description
P0-02	Driver status display		02	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection in order to determine whether there is electrical interference.
P1-00	External pulse train input type	ZYX	002	X=2: pulse + direction; Z=0: positive logic

Para. No.	Function	Format & Range	Value	Description
P1-01	Set control mode	ZYX1X0	0000	Z=0: during control mode switching, DIO is maintaining the set value. Since switching control mode is not used, Z=0; Y=0: forward rotation (CCW) (from the view of load); Y=1: the rotation direction is reversed. X1X0=00: position control mode
P1-44	Electronic Gear Ratio (Numerator)(N1)	1~32767	Need calculation	N1/M= mechanical deceleration ratio $\times$ 4 $\times$ encoder pulses $\times$ pulse equivalent / pitch. Representative value: encoder pulses=2500, pitch =5mm, pulse equivalent=0.001, deceleration ratio = 1, calculation as below:
P1-45	Electronic Gear Ratio (Denominator)(M)	1~32767	Need calculation	$N1 / M = 2500 \times 4 \times 0.001 / 5 = 2 / 1$ , N1=2, M=1; When the multi-electronic gear ratio is not used, P2-60 ~P2-62 are not required.
P2-10	Digital Input Pin 1 (DI1)	X2X1X0	101	X1X0=01: digital input (DI1 = SON) corresponds to 9 <sup>th</sup> pin of CN1. X2=1: set DI1 input as NO (normally open) a-contact point.
P2-15	Function setting for digital input pin DI6	X2X1X0	100	Default factory setting of DI6 and DI7 is NC (normally closed) limit signal input; driver can't run without being connected to pin 32 and pin 31 of CN1. X2=1: set DI6 and DI7 input as NO a-contact points. X1X0=00, limit input of driver is not used.
P2-16	Function setting for digital input pin DI7	X2X1X0	100	
P2-17	Function setting for digital input pin DI8	X2X1X0	100	External E-stop input is not used.

Para. No.	Function	Format & Range	Value	Description
P2-21	Function setting for digital output pin DO4	X2X1X0	108	DO4 corresponds to pin 1 & pin 26, used as clamping-position brake signal of Z-axis; X2=1: set DO4 output as NO (normally open) a-contact point; X2=0: set DO4 output as NC (normally closed) b-contact point; X1X0=08: set pin 1 and pin 26 as BK+ and BK- respectively.
P2-22	Function setting for digital output pin DO5	X2X1X0	007	DO5 corresponds to pin 28 & pin 27, used as servo alarm signal. X2=0: set DO5 output as NC b-contact point. X1X0=07: set pin 28 and pin 27 as ALRM+ and ALRM- respectively.

#### 7.2.1.4. Parameter Setting of PANASONIC MINAS\_A4 Servo Driver

Para. No.	Function	Value	Description
Pr01	LED initial status	12	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection in order to determine whether there is electrical interference.
Pr02	Select control mode	0	0: position mode 1: velocity mode 2: torque mode
Pr40	Select command pulse input	1	1: input through difference exclusive circuit
Pr42	Select command pulse input mode	3	Set command pulse input mode: command pulse + command direction, negative logic
Pr48	The 1st numerator of the command pulse frequency	Need calculation Range:	Typical values: pitch 5 mm, encoder resolution 10000, deceleration ratio 1:1, pulse equivalent 0.001 mm: Pr48=10000

Para. No.	Function	Value	Description
	multiplication	1~10000	Pr4B= pitch 5mm/ pulse equivalent 0.001mm=5000 So, Pr48/Pr4B=10000/5000=2/1
Pr4B	Denominator of the command pulse frequency multiplication	Need calculation Range: 1~10000	

After the parameters are set, writing mode of EEPROM has to be selected. Please refer to the following steps:

- ① Press [MODE] button → Select [EEPROM]→ Enter mode [EE\_SET];
- ② Press SET button, showing [EEP —];
- ③ Keep pressing UP direction key for approx. 3 seconds, then [EEP ——] will be displayed, and then writing starts until [Start] is displayed.

After the parameters are saved, the display of [Finish] means successful modification. If [Reset] is shown, alteration will be validated only after the driver is restarted. If [Error] occurs, the write-in is a failure, and another setting is needed.

### 7.2.1.5. Parameter Setting of FUJI FALDIC-β Servo Driver

Para. No.	Name	Value	Description
01	Command pulse numerator $\alpha$	Need calculation 1~32767	Command pulse numerator and denominator are also equal to those of the electronic gear ratio. $\alpha / \beta = \text{encoder resolution} \times \text{pulse equivalent} \times \text{mechanical deceleration ratio} / \text{screw pitch}$ . Typical value: encoder resolution 65536, pitch 5mm, pulse equivalent 0.001, mechanical deceleration ratio 1, $\alpha / \beta = 65536 \times 0.001 / 5 = 8192 / 625$ , So $\alpha = 8192$ , $\beta = 625$ .
02	Command pulse denominator $\beta$	Need calculation 1~32767	
03	Pulse string input form	0	Set the input mode of pulse string as: instruction + symbol, that is 'pulse + direction'.
04	Direction of rotation switch	0 or 1	Set 0: Positive direction: Forward rotation (CCW); Set 1: Positive direction: Reverse rotation (CW).
10	CONT1 signal	1	CONT1 is distributed as RUN (i.e. SON); if not













Para. No.	Name	Value	Description
	distribution		distributed, CONT1 will be auto ON if there is no alarming when powered.
11	CONT2 signal distribution	2	CONT2 is distributed as RST (i.e. servo alarming clearance CLR). When 12, 13, 14 are 0, that is CONT3, CONT4 and CONT5 can't be distributed as OT (over-travel) or EMG (external emergency stop).
15	OUT1 signal distribution	1	Set 1, OUT1 is distributed as a-contact point of alarming output; Set 2, OUT1 is distributed as b-contact point of alarming detection.
27	Parameter write-protection	0 or 1	Set 0, write-enable. Set 1, write-protected.
74	CONT Always ON 1	1	Its initial value is 0, and it is set "1" here to enable servo (RUN).



FUJI servo has no braking signal wire, so instead of setting the parameters related to braking you only need to provide 24V brake power to pin Br (lead wire 5 and 6) of motor with braking.

### 7.2.1.6. Parameter Setting of STONE GS Servo Driver

Para. No.	Para. Name	Value	Description
F0f	Electronic gear ratio numerator	2	Electronic gear ratio of position mode: $4 \times \text{pulse frequency fed back by motor encoder} = \text{command pulse frequency} \times F0f / F10$ ; value of $F0f / F10$ must be within 1/100~100. (calculated with pitch as 10mm)
F10	Electronic gear ratio denominator	1	
F00	Control mode selection	2	0: external speed running mode; make sure the value and direction of motor speed according to the external analog -10V ~ +10V signal of CN2-16, 17; 1: internal speed running mode; make sure the value and direction of motor speed according to the setting of

Para. No.	Para. Name	Value	Description																							
			<p>parameter F33, F35, F37, F39 and the port status of CN2-9, CN2-25;</p> <p>2: position pulse running mode; receive the input of external position command pulse and direction level signal;</p> <p>3: jog mode; make sure the motor speed in terms of parameter setting of F3b, and control the rotation direction by the direction keystroke ▼ and ▲;</p> <p>4: torque mode; make sure the value and direction of motor torque according to the external analog -10V ~ +10V signal of CN2-43, 1;</p> <p>5~10: mixed mode; select mode according to the port input status of CN2-24:</p> <table border="1" style="margin: 10px auto;"> <thead> <tr> <th rowspan="2">F00 Value</th> <th colspan="2">CN2-24 Interface Status</th> </tr> <tr> <th>OFF (Mode One)</th> <th>ON (Mode Two)</th> </tr> </thead> <tbody> <tr> <td>5</td> <td>Position Pulse Mode</td> <td>External Speed Running Mode</td> </tr> <tr> <td>6</td> <td>Position Pulse Mode</td> <td>Internal Speed Running Mode</td> </tr> <tr> <td>7</td> <td>Position Pulse Mode</td> <td>Torque Mode</td> </tr> <tr> <td>8</td> <td>Internal Speed Running Mode</td> <td>External Speed Running Mode</td> </tr> <tr> <td>9</td> <td>Internal Speed Running Mode</td> <td>Torque Mode</td> </tr> <tr> <td>10</td> <td>External Speed Running Mode</td> <td>Torque Mode</td> </tr> </tbody> </table>	F00 Value	CN2-24 Interface Status		OFF (Mode One)	ON (Mode Two)	5	Position Pulse Mode	External Speed Running Mode	6	Position Pulse Mode	Internal Speed Running Mode	7	Position Pulse Mode	Torque Mode	8	Internal Speed Running Mode	External Speed Running Mode	9	Internal Speed Running Mode	Torque Mode	10	External Speed Running Mode	Torque Mode
F00 Value	CN2-24 Interface Status																									
	OFF (Mode One)	ON (Mode Two)																								
5	Position Pulse Mode	External Speed Running Mode																								
6	Position Pulse Mode	Internal Speed Running Mode																								
7	Position Pulse Mode	Torque Mode																								
8	Internal Speed Running Mode	External Speed Running Mode																								
9	Internal Speed Running Mode	Torque Mode																								
10	External Speed Running Mode	Torque Mode																								
F2e	Pulse input mode selection	2	<p>Command pulse string mode selection of position mode:</p> <p>1- single pulse string positive logic</p> <p>pulse: 12, 27 </p> <p>direction: 13, 28 </p> <p>2 - single pulse string negative logic</p> <p>pulse: 12, 27 </p> <p>direction: 13, 28 </p> <p>3 - double pulse strings positive logic</p> <p>CCW: 12, 27 </p> <p>CW: 13, 28 </p> <p>4 - double pulse strings negative logic</p> <p>CCW: 12, 27 </p> <p>CW: 13, 28 </p> <p>5 - quadrature pulse positive logic</p> <p>phase A: 12, 27 </p> <p>phase B: 13, 28 </p> <p>6 - quadrature pulse negative logic</p> <p>phase A: 12, 27 </p> <p>phase B: 13, 28 </p>																							



### 7.2.1.7. Parameter Setting of MITSUBISHI MR-E Servo Driver

Para. No.	Code	Function	Value	Description
0	*STY	Select control mode and regenerative fittings	X0X0	Bit 0: set 0: select position control mode. Bit 1, select motor series: 0: HC-KFE; 1: HC-SFE; Bit 3, select regenerative apparatus, set 0: not use. Bit 4, select motor power.
1	MBR	Function selection 1	001X	Bit 0: input signal filter. If external input signal causes chattering due to noises, etc., input filter is used to suppress it. Bit 1: CN1-12 function selection, set "1": electromagnetic brake interlock (MBR); set "0": zero speed detection signal.
3	CMX	Electronic gear numerator	Need calculation	$CMX/CDV = \text{command unit} \times \text{servo motor resolution} \times \text{mechanical deceleration ratio} / \text{pitch of screw}$ .
4	CDV	Electronic gear denominator	Need calculation	E.G., pitch 5 mm, encoder resolution 10000, deceleration ratio 1:1, pulse equivalent 0.001 mm, $CMX/CDV = 10000 \times 0.001 / 5 = 2/1$ ; When pulse equivalent = 0.0005mm, $CMX/CDV = 1/1$ . Electronic gear ratio range: 1/50 ~ 500
18	*DMD	Status display selection	00XX	3: cumulative command pulses E: load inertia When the parameter is set [3], monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection to determine if there is electrical interference.
21	*OP3	Function selection 3 (command pulse format selection)	0001	Set pulse command input form: pulse train+ sign, negative logic


Para. No.	Code	Function	Value	Description
41	*DIA	Signal input SON-ON, LSP-ON and LSN-ON automatically selection	0110	Bit 0: Servo-ON selection. [0]: servo on by external input; [1]: servo on all the time inside. Bit 1: last signal of positive rotation range (LSP): [1]: auto servo on inside, without external wiring. Bit 3: last signal of negative rotation range (LSN) : [1]: auto servo on inside and no need of external wiring.



Regarding parameters with the symbol “\*” in front, when changed, they will be effective after re-power on the driver.

## 7.2.2. Wiring Diagram of NK105G2F/G3F and Driver

### 7.2.2.1. Wiring Diagram of NK105 and Differential Input Stepping Driver



**Note: twisted pair adopted for differential signal**

Fig. 7-1 Wiring of NK105 four axes control box and differential input stepping driver

### 7.2.2.2. Wiring Diagram of YASKAWA $\Sigma$ -II Servo Driver




Fig. 7-2 Wiring diagram of NK105 and YASKAWA  $\Sigma$ -II servo driver



Wirings of X axis, Y axis, and Z axis are the same. Only Z axis has two brake signal lines which can be connected to relay to control brake.

### 7.2.2.3. Wiring Diagram of DELTA ASDA Servo Driver




Fig. 7-3 Wiring diagram of NK105 and DELTA ASDA\_A servo driver




Fig. 7-4 Wiring diagram of NK105 and DELTA ASDA\_AB servo driver



Wirings of X axis, Y axis, and Z axis are the same. Only Z axis has two brake signal lines which can be connected to relay to control brake.

### 7.2.2.4. Wiring Diagram of PANASONIC MINAS\_A4 Servo Driver




Fig. 7-5 Wiring diagram of NK105 and PANASONIC MINAS\_A4 servo driver



Wirings of X axis, Y axis, and Z axis are the same. Only Z axis has two brake signal lines which can be connected to relay to control brake.

### 7.2.2.5. Wiring Diagram of MITSUBISHI MR-E Servo Driver




Fig. 7-6 Wiring diagram of NK105 and MITSUBISHI MR-E servo driver



Wirings of X axis, Y axis, and Z axis are the same. Only Z axis has two brake signal lines which can be connected to relay to control brake.

### 7.2.2.6. Wiring Diagram of FUJI FALDIC-β Servo Driver




Fig. 7-7 Wiring diagram of NK105 and FUJI FALDIC-β servo driver



Wirings of X axis, Y axis, and Z axis are the same, and the brake of Z axis is internally controlled.

### 7.2.2.7. Wiring Diagram of STONE GS Servo Driver




Fig. 7-8 Wiring diagram of NK105 and STONE GS servo driver



Wirings of X axis, Y axis, and Z axis are the same. Only Z axis has two brake signal lines which can be connected to relay to control brake.

## 8. Software License Agreement

---

### **Important—Read Carefully before Using This Product:**

The term “Software Product” includes all copies of the licensed software and its documentation. This license agreement is a legal agreement between You (either an individual, a legal entity or any affiliated companies or other entities) and Weihong Electronic Technology Co., Ltd. (hereinafter referred to as Weihong Company). By installing, copying, or otherwise using the Software Product, you agree to be bound by the terms and conditions of this license. Unless otherwise stated in this agreement, you shall not use, copy, revise, rent, or transfer the Software product or any part of the Software Product for any other purposes.

### **Description of Further Rights and Restrictions:**

1. You may install for use one copy of the Software Product on a single machine;
2. You may make a copy of the Software Product for archive or backup purposes and the copy is to be used on this machine only;
3. You may transfer the Software Product and the license agreement to a third party, provided that the third party accepts the terms and conditions stated in this agreement, with prior express permission from Weihong Company;
4. When transfer confirmed, you shall transfer all the copies of the original documents and the supplementary documents to the third party or destroy all the copies un-transferred.
5. You can use the Software Product on a network server or intranet server only if it is stipulated in explicit terms that you are allowed to use the Software Product on a network server or intranet server, or you have purchased license for each node and terminal using the Software Product;
6. You may NOT sublicense, assign or transfer the license agreement;
7. You may NOT or direct any third party to reverse engineer, decompile or disassemble the Software Product;
8. You may NOT copy or transfer the Software Product or any part of the Software Product unless otherwise expressly stated in this agreement;
9. The license agreement shall be terminated automatically upon you transfer the Software Product or copies of all or part of the Software Product to a third party.

### **Intellectual Property Rights Notice:**

The Software Product and all intellectual property rights therein (including but not limited to any all copyrights, patents, trademarks, and publicity rights) are owned by Weihong Company. The Software Product is protected for Weihong Company on the basis of copyright law and international treaty provisions as well as on the basis of other laws and agreements regarding intellectual property. You are not allowed to remove the copyright statement made in the Software Product, and guarantee that you shall copy the copyright statement in all copies of the Software Product or of any part of the Software Product. You are obliged to stop any form of illegal copying of the Software Product and accompanying



materials.

**After-sales Guarantee:**

Weihong Company guarantees that for 90 days from the date of shipment the software carrier will be free from defects in materials and workmanship. When such a defect has been confirmed, our only responsibility is to replace the software carrier. This remedy is your exclusive remedy. This after-sales guarantee is invalid for any carrier defect caused by accidents, abuses or maloperation. The replaced software carrier enjoys the remaining guarantee time of the original software carrier or of a 30-day guarantee time, whichever is longer.

Except as the after-sales guarantee made above, the Software Product does not enjoy any other form of after-sale guarantee.

**Limitation of Liability:**

The above guarantee, whether made explicitly or by implication, constitutes the entire contents of the guarantee, including guarantee for the commerciality and applicability of special application aim. Whether you follow other terms in this agreement or not, Weihong Company, as well as its agents and sales staff, will not be responsible for any profits loss, availability loss, business break-off or any forms of indirect, special, accidental or inevitable damage or claim made by any third party, generated from the using of the Software Product, even if Weihong Company has been informed of the possible occurrence of such events in advance.

**Termination:**

This license may be terminated by Weihong Company at any time once you violate any terms or conditions made in this agreement. Once the license is terminated, you are obliged to destroy all the copies of the Software Product or return them to Weihong Company.

**Applicable Law:**

*Copyright Law, Regulations for the Protection of Computer Software, Patent Law and other relevant laws and regulations.*

Now, we affirm that you have already read through this agreement and understood it thoroughly and agreed to comply with all of the terms and conditions of this agreement strictly.

Weihong Electronic Technology Co., Ltd.