

This is the kit for Collision Prevention sensor, installation guide at:

<https://www.youtube.com/shorts/p6XmN4BXpt0>



Note:

1. Install sensor on left and UV light on right.
2. Connect to the 2<sup>nd</sup> white port from right (as shown on video above), it's the port for NO signal of collision.
3. This kit only for PrintExp system, F2-1800 single printhead system.