


## FLOW SWITCH WIRING FOR LASER RD6445G MB



- To bypass the switch, put a joining wire between the switch Water Protection (WP) and the Ground (GND), then use the Laser interface to pulse. If the CO2 tube is working well, it will pulse.