

MATE-A8 Control System Fast Manual




A. Input Designs



B. Choose a Design




C. Set color changing order




D. Manual Color-Changing



E. Idling



F. Manual modification method




G. Return to start point



H. Return to stop point



I. Manual Trimming



J. Set cyclic embroidery

 → 【Emb. asst. Para】 → 【To Do Cyclic Emb.】 change to "Yes" → 

K. Setting another start

 → 【Setting Another Start】 → 

L. Add applique design

 → Click to choose a design →  → 【Input Color Line】 →  Add applique design

M. Positioning idling

 → Positioning idling → 

N. Design border operation

 → Design border operation → 


O. Manual frame moving

Direction Key: , , , ; Speed Shift of Manual Frame-moving: 

P. Let Needle Down

 →  Needle Down → 

Q. Speed up、Speed down

 :  : Speed down  : Speed up

R. Turn the Main Shaft to 100 Manually

 →  Goto 100 → 