

MT单头系统操作界面内容介绍

一、正常进入, 按确定键 →	※设置菜单Setup Menu→	打印设置Print Setup→	方向Dir→	单向、双向(可选)
			速度Speed→	标准、高速(可选)
			羽化Soften→	关、低、双(可选)
		吸风Fan Setup→	1-16(可调)	
		对比度LCD Contrast→	1-16(可调)	
		自动清洗Auto Clean→	开、关(可选)	
		设备地址Device Address→	密码为16753	
		空纸报警Warn Paper→	开、关(可选)	
		墨站设置Station Setup→	墨站原点Station Pos(靠左右移动, 以离开墨站并微靠墨站挡块为准)	
			闪嘴位置Spurt Pos(闪嘴在墨站原点)	
	刮嘴位置Wipe Pos(靠左右移动, 以完成刮墨为定点)			
	小车封头位置Car Cap Pos(靠左右移动, 以喷头与墨站贴合为准)			
	打印闪嘴位置Print Spurt Pos(0为关, 1为1Pass打印闪嘴一次)			
		靠左右移动, 以喷头左边为起始, 闪嘴在海绵上)		
※语言Language→	简体中文. ENGLISH			
	喷嘴测试Nozzle Test			
	自动清洗Clean Nozzle			
	手动清洗Manual Clean			
	刮嘴Wipe Nozzle			
	冲墨Flush			
	封头Cap Head			
	自动装墨Inking			
	略			
	※出厂设置Restore Default→ 恢复出厂设置(是、否、可选)			
※设备维护Maintenance→	墨站Station: CAP型、双升降型TwoLift、单升降型OneLift、升降型Lift			
	刮片Wiper: 弹出Pop, 固定Fixed; 电机Motor, 升降Lift; 电机Motor, 固定Fixed; 弹出Pop, 升降Lift.			
	打印宽度PrintWidth: 192cm(值可调)			
	光源类型RasterType: B、A、P、O、N、M、L、K、J、I、H、G、F、E、D、C			
	小车电机CarMotor: DC、伺服Servo			
	走纸电机PaperMotor: 步进Step、伺服Servo			
	刮片转向WiperDir: 正向Normal、反向Reverse			
	走纸转向PaperDir: 反向Reverse、正向Normal			
	小车转向CarDir: 正向Normal、反向Reverse			
	加速距离Accdis: 40mm(最大值300mm)			
※设备信息Dev. Mgr	略			
	二、同时按上下左右键, 并开机→			
	墨站Station: CAP型、双升降型TwoLift、单升降型OneLift、升降型Lift			
	刮片Wiper: 弹出Pop, 固定Fixed; 电机Motor, 升降Lift; 电机Motor, 固定Fixed; 弹出Pop, 升降Lift.			
	打印宽度PrintWidth: 192cm(值可调)			
	光源类型RasterType: B、A、P、O、N、M、L、K、J、I、H、G、F、E、D、C			
	小车电机CarMotor: DC、伺服Servo			
	走纸电机PaperMotor: 步进Step、伺服Servo			
	刮片转向WiperDir: 正向Normal、反向Reverse			
	走纸转向PaperDir: 反向Reverse、正向Normal			
小车转向CarDir: 正向Normal、反向Reverse				
加速距离Accdis: 40mm(最大值300mm)				
走纸速度PaperSpeed: 145(最大值, 可调)				
LED类型LEDType: B、A				
自动清洗AutoClean: 闪嘴Spit、清洗Clean				
清洗设置MaintCFG: 进入Entry→				
注: 此部分内容数值均为可调, 但不建议调整				
短抽开ms: 100				
抽余墨次数: 1				
抽余墨次数关ms: 200				
抽余墨次数开ms: 1500				
闪嘴频率: 0				
闪嘴次数: 27				
抽墨维持s: 15				
长抽次数: 0				
长抽次数关ms: 600				
长抽次数开ms: 820				
短抽次数: 1				
短抽次数关ms: 300				
短抽次数开ms: 100				
※出厂设置Restore Default→	Print Debug: ON、*** (老化功能, 不联机空打为6Pass)			
	Spit Test: ON; SDRAM Test: ON; PHI: OX00; DAI: OX00; DAC: 100(X64)			
	Car: Pos-46; 《; 》; 25IPS; 35IPS; 45IPS; 55IPS			
	Ink Motor: ON; Ink Motor2: ON; Valva: ON; Fan Motor: ON; Wiper: UP; Media: ↓↑;			
	Wiper BF: For Ward、Backward			
	Cap: UP、Down			
	Wiper Sensor: ON; Car Sensor: ON			
	CLR Password: 0			
	三、开机自检时, 同时按上下左右键, 并开机→			
	Print Debug: ON、*** (老化功能, 不联机空打为6Pass)			
Spit Test: ON; SDRAM Test: ON; PHI: OX00; DAI: OX00; DAC: 100(X64)				
Car: Pos-46; 《; 》; 25IPS; 35IPS; 45IPS; 55IPS				
Ink Motor: ON; Ink Motor2: ON; Valva: ON; Fan Motor: ON; Wiper: UP; Media: ↓↑;				
Wiper BF: For Ward、Backward				
Cap: UP、Down				
Wiper Sensor: ON; Car Sensor: ON				
CLR Password: 0				

代理商须知