

深圳市睿法睿  
(FWH20-S10C智能单摆)


序号	料号	名称
1	1.01.01.02.0059	三合一单摆通用电机组件(带电机、电机线、振镜镜夹组件)
2	2.01.01.01.0898	三合一单摆通用电机组件
3	2.01.01.01.0046	振镜镜夹组件(带镜片)
4	3.03.01.01.0005	三合一通用单摆电机(插拔式)
5	3.01.09.01.0157	电机线(DB)10m
6	3.02.01.01.0006	准直镜片
7	3.02.02.01.0001	聚焦镜片(焊接)
8	3.02.02.01.0015	聚焦镜片(清洗)
9	3.02.02.01.0021	聚焦镜片(清洗)
10	3.02.03.01.0001	保护镜片(通用)
11	3.11.01.01.0007	外角丝嘴0.8
12	3.11.01.01.0008	外角丝嘴1.0

13	3.11.01.01.0009	外角丝嘴1.2
14	3.11.01.01.0010	外角丝嘴1.6
15	3.11.01.01.0001	内角丝嘴0.8
16	3.11.01.01.0002	内角丝嘴1.0
17	3.11.01.01.0003	内角丝嘴1.2
18	3.11.01.01.0004	内角丝嘴1.6
19	3.11.01.01.0006	平角丝嘴
20	3.11.01.01.0012	切割丝嘴
21	3.05.02.01.0007	弹性密封圈
22	3.05.02.01.0001	弹性密封圈
23	3.07.01.01.0089	喷管
24	1.01.01.03.0007	智能送丝管组件5米
25	1.01.01.03.0033	石墨送丝管组件3.5米
26	3.07.02.01.0011	导丝嘴
27	3.07.02.01.0012	导丝嘴

28	3.07.02.01.0013	导丝嘴
29	3.07.02.01.0014	导丝嘴
30	3.07.02.01.0037	送丝轮
31	3.07.02.01.0003	送丝轮
32	3.07.01.01.0593	喷管-焊缝清洗
33	1.01.02.02.0012	清洗保护套组件
34	2.01.01.01.0297	单送丝支架组件
35	2.01.01.01.0486	送丝支架2组件(带螺丝)
36	2.01.01.01.0608	送丝支架1组件(带螺丝)
37	2.01.01.01.0499	锁嘴组件
38	2.01.01.01.0953	准直压盖组件 (D16*50)
39	2.01.01.01.0812	聚焦镜片压盖组件 (D20*F150)
40	2.01.01.01.0815	聚焦镜片压盖组件 (D20*F800/F1000)
41	2.01.01.01.0811	保护镜压盖组件 (D20*2)
42	2.01.01.01.0521	准直抽屉组件

43	2.01.01.01.0313	聚焦抽屉组件F150
44	2.01.01.01.0251	聚焦抽屉 F400/F800/F1000共用组件
45	2.01.01.01.0166	保护镜座抽屉组件2
46	2.01.01.01.0165	保护镜座抽屉组件1

智能科技有限公司耗材  
摆手持焊接头(单送丝四合一)



型号	单位	备注	图片
H03-49A (焊接式)	套		
H08-314A (插拔式)	套		
H03-85A	个	反射镜片27*14*2	
SS-RF-1064-3KW (D19) 端子插拔式	个		
DB9母插头镀金, 另外一端为 PH2.0 6P (2*4) 母端	套		
D16*F50	片		
D20*F150	片		
D20*F800	片		
D20*F1000	片		
D20*2	片		
FCS-08	个		
FCS-10	个		

FCS-12	个		
FCS-16	个		
FAS-08	个		
FAS-10	个		
FAS-12	个		
FAS-16	个		
FS-01	个		
FC-20	个		
16.5*12*2.3	个	准直镜组件	
20.5*16*2.3	个	聚焦组件+保护组件共用	
H03-046B	个	聚焦F150	
SS-07 (D1.6)	套	包含SS-015B连接件	
SS-31 (D1.6)	套	包含SS-015B连接件	
SS-004-0.8	个		
SS-004-1.0	个		

SS-004-1.2	个		
SS-004-1.6	个		
V0.8-V1.0 V型槽	对		
1.2 -1.6 V型线槽	对		
H03-196B (F150)	个		
H03-57A	套		
S03-21A	套		
H08-159A	套		
H08-204A	套		
H08-174A	套		
H08-335A	套	用在准直镜	
H08-280A	套	用在聚焦镜	
H08-283A	套	用在聚焦镜	
H08-279A	套	用在保护镜	
H08-179A (不含镜片)	套	用在准直镜	

H03-160A (不含镜片)	套	用在聚焦镜	
H08-079A (不含镜片)	套	用在聚焦镜	
H08-063A (不含镜片)	套	用在保护镜	
H08-062A (不含镜片)	套	用在保护镜	





