

Operation Introduction

1. Connect Machine and Computer with USB line
2. Process “Machine-Reset.exe” progress as follows:

Press “**Recover**” button



3. Contact support for remote assistant, which will help you download the settings to the machine